This project will show how the Arduino can be used to drive an LED grid display. The display is shown file "LED\_Controller.PDF" and is similar to that seen in lots of older equipment. The important thing to notice about the grid, is that the row lines are connected to multiple the LED's and the columns are also connected to multiple LED's. Thus to turn on a certain LED, we need to activate the column and the row for that LED. The implication of this is that we cannot arbitrarily turn on LEDs that aren't in the same row or column. The solution to this is to scan through the columns and depending upon which column we are on, we will turn on the rows matching the LED's we want on. Thus on a standard time basis (4 milliseconds) one of the column pairs are activated along with the appropriate rows. After each time interval, we move to the next column pair.

So to facilitate this a library was written that would hold the data for each column and rows. The library is in Appendix A, as a header file and a cpp file. We will discuss in class the format of classes and how this works, but it is not anticipated that many of you will ever have to write such code.

The other thing to observe about the system is the large number of pins that need to be driven to run the LED grid (5 lines for the columns, and 24 rows). We don't have anywhere near that many pins, and if we did we would probably not want to commit them to this one display. Thus a board was built that used hardware buffers to hold the bits which turn on the columns and rows. The hardware buffers are set up to take in data serially over and SPI bus. The schematic of this is on the second page of the file "LED\_Controller.PDF" and is rather busy. I will try and point out the pertinent parts in class.

As part of this work, code was written to support an SPI transfer. Instead of using the built in hardware on the Arduino for the SPI, this code was done to allow the Analog pins to be used as the SClk and SDin signals. Also, having our own code allows us to do 32 bit transfer, instead of doing multiple 8 or 16 bit transfers.

For the timing of writes to the display, TimerOne to set to run an Interrupt Service Routine to send the data over on a 4 millisecond basis. This allows the other parts of the program to ignore this action, and if they want to have an LED appear as on, they simply set that bit in the array inside DisplayData.

In order to demonstrate the display, a clock was set up and the time displayed on the LED grid. It is shown in binary, which makes it some what NERDY and hard to read. In fact, it helps if you mask off the other parts of the display and only show the LED's that are the clock numbers.


Finally, a clock that cannot be set is rather worthless. Thus a facility for setting the clock was added, employing the button and encoder. This code is also part of the Morse Code Transmitter.

#### Arduino Code:

```
// libraries
#include <LiquidCrystal.h>
// Defines for LCD
LiquidCrystal LcdDriver(11, 9, 5, 6, 7, 8);
#include <TimerOne.h>
#include <DisplayData.h>
DisplayData DispData;
#include "SPI_Local.h" // Software version of SPI.
#include "ButtonDebounce.h" // Software for button debounce.
#include "EncoderMonitor.h" // Reading encoder.
#include "ClockBasics.h" // Running the clock.
void DisplayValue(int TimeValue, int Row)
       int Local = TimeValue / 10;
       for (int i = 0; i < 4; i++)
        {
               if (Local & (1 << i))</pre>
                       DispData.SetBit(Row, 4 - i);
               else
                       DispData.ClearBit(Row, 4 - i);
       }
       Local = TimeValue % 10;
       for (int i = 0; i < 4; i++)
               if (Local & (1 << i))</pre>
                       DispData.SetBit(Row - 2, 4 - i);
               else
                       DispData.ClearBit(Row - 2, 4 - i);
} // End of DisplayValue
// Displays clock on LedMatrix
void DisplayClock()
{
       // Set Hours into rows
       DisplayValue(Hours, 10);
       // Set Minutes into row
       DisplayValue (Minutes, 6);
        // Set Seconds into row
       DisplayValue(Seconds, 2);
} // End of DisplayClock
// Interrupt Service Routine to maintain Display
void ISR ServiceDisplay()
{
       Spi Transmit32(DispData.NextWord());
}
// Clock Timer Setup.
#define ONE_SECOND 1000
unsigned long ClockTimer;
int EncoderTracking;
void setup()
{
        // put your setup code here, to run once:
       DispData.Initialize();
```

```
Spi Initialize();
      // Set up timer to service LED Display.
      Timer1.initialize(4000); // Sets timer to fire every 4 millisec.
      Timer1.attachInterrupt(ISR ServiceDisplay);
      // Set up clock
      ClockTimer = millis();
      Hours = 9;
                    // Set clock close to rollovers.
      Minutes = 58;
      Seconds = 55;
      // The controls for setting the clock.
      ButtonInitialize(4); // connect to push button
      EncoderInitialize(); // Monitor encoder.
      EncoderTracking = EncoderValue;
      // LCD Setup.
      LcdDriver.begin(16, 2);
      LcdDriver.clear();
int LED State = 0;
void loop()
{
      // Check if it is time to Update the clock.
      if (millis() - ClockTimer >= ONE SECOND)
             if (clockState == CLOCK RUNNING)
                   // Don't change clock when it is being set.
                   UpdateClock();
             DisplayClock();
             LcdDriver.clear();
             SendClock(); // update clock on Lcd
             // place cursor to indicate if the clock is being set and
             // which item is being set.
             switch (clockState)
             case CLOCK_SET_HOURS:
                   LcdDriver.setCursor(0, 0);
                   break;
             case CLOCK SET MINUTES:
                   LcdDriver.setCursor(3, 0);
                   break;
             case CLOCK_SET_SECONDS:
                   LcdDriver.setCursor(6, 0);
                   break:
             case CLOCK RUNNING:
                   LcdDriver.setCursor(0, 1);
             LcdDriver.blink();
             ClockTimer += ONE SECOND;
      // Watch button and encoder to set clock
      if (ButtonTest() == 1) // Button pressed,
             SettingClock(1, 0); // So update state.
      else if ((EncoderValue - EncoderTracking) >= 4)
         // The encoder has moved by one detent
             SettingClock(0, -1); // Indicate positive travel
             EncoderTracking += 4; // and move tracking variable.
      else if ((EncoderValue - EncoderTracking) <= -4)</pre>
          // The encoder has moved by one detent in the opposite direction
             SettingClock(0, +1); // Indicate negative travel
             EncoderTracking -= 4;  // and Update Tracking accordingly
      }
}
```


I monitored the SClk and SDin lines on the display board, using the Analog Discovery. The following screen shot shows the 4 millisecond interval, and that we are only spending a small fraction of our time servicing the display.



If we zoom in on the actual transfer, we can see the that it only requires less than 35 microseconds, which is less than 1% of the 4 millisecond interval.



In an effort to show how the data is shifted into the buffers, bottom four bits of the shift registers were monitored as shown here.



#### Appendix A: Library for holding display data.

# Header in file DisplayData.h

} // End of SetBit

// End of GetBit

index = c % 5;

{

// Read back the current value of a bit.
int DisplayData::GetBit(int r, int c)

```
#ifndef DisplayData h
#define DisplayData h
#define ColumnSets 5
#define DisplayColumns 10
#define DisplayRows
// Object that is used to hold data for LED display
// Controlling the writing of bits
// and sends them out to as they need to be displayed.
class DisplayData {
private: unsigned long DisplayBits[ColumnSets], CurrColumn;
              int index;
              int bit;
public:
      void Initialize();
                                   // Sets column controls and zeros bits
      void SetBit(int r, int c); // Turns on the LED at r,c
      int GetBit(int r, int c); // Returns the value of the LED at r,c
      void ClearBit(int r, int c); // Turns off the LED at r,c
      unsigned long NextWord();
}; // Advances pointer and returns next word
// to be sent.
#endif
C-code in file DisplayData.cpp
#include <DisplayData.h>
// Object for display
// Code to initialize the structure DisplayData.
void DisplayData::Initialize()
      DisplayBits[0] = 0x01000000; // Col 1 and 6 // Each line represents a set of
      DisplayBits[1] = 0x02000000; // Col 2 and 7 // 24 led's or 2 columns of 12 led's.
      DisplayBits[2] = 0x04000000; // Col 3 and 8 // Upper bits set the pair of columns.
      DisplayBits[3] = 0x08000000; // Col 4 and 9
      DisplayBits[4] = 0x10000000; // Col 5 and 10
      CurrColumn = 0; // Current set of led's that are one.
} // End of Initialize
// Function to turn on an LED at the location of row and column (r,c).
void DisplayData::SetBit(int r, int c)
{
      unsigned long One = 1;
      index = c % 5;
      bit = r % 12 + 12 * ((c % 10) / 5);
```

DisplayBits[index] |= (One << bit); // Mask bit to one</pre>

bit = r % 12 + 12 \* ((c % 10) / ColumnSets);
return(DisplayBits[index] & (1 << bit));</pre>

```
// Function to turn off an LED at the location of row and column (r,c).
void DisplayData::ClearBit(int r, int c)
{
      unsigned long One = 1;
      index = c % 5;
      bit = r % 12 + 12 * ((c % 10) / ColumnSets);
      DisplayBits[index] &= ~(One << bit); // Mask bit to zero</pre>
} // End of ClearBit
// This function is called to move to the next pair of columns of LEDs
// and then return the 32 bits for the column pair, which should
// be sent over to the display via spi.
unsigned long DisplayData::NextWord()
      CurrColumn++; // Advance pointer
      if (CurrColumn == ColumnSets) // and wrap
             CurrColumn = 0;
      return (DisplayBits[CurrColumn]); // return current word
                                        // Turning on column and rows.
} // End of NextWord
```

### Appendix B: SPI code for 32 bit transfer, using A5 and A4 pins.

```
#ifndef SPI Local h
#define SPI_Local_h 1
// SPI support on Analog pins A5 and A4
#define SpiDataBit 5
#define SpiClkBit 4
// Set up pins as outputs.
void Spi Initialize()
{
      bitSet(DDRC, SpiDataBit);
      bitSet(DDRC, SpiClkBit);
}
// Function to transmit 32 bit number
void Spi Transmit32(unsigned long out)
{
      int k;
      for (k = 0; k < 32; k++)
             // Set Clock low
             bitClear(PORTC, SpiClkBit);
             if (out & 0x80000000) // If top bit is high,
                    bitSet(PORTC, SpiDataBit);
             else // or low
                    bitClear(PORTC, SpiDataBit);
             // Set Clock High
             bitSet(PORTC, SpiClkBit);
             // Move next bit into top bit.
             out = out << 1;
      } // End of loop through bits.
      return;
} // End of Spi Transmit32
#endif
```

## Appendix C: Clock support

```
#ifndef ClockBasics H
#define ClockBasics H
// Variable used as clock settings.
int Hours, Minutes, Seconds;
// This function is to be called every second
// to update the clock represented by the
// global variables Hours, Minutes, Seconds
void UpdateClock()
       // Check if Seconds not at wrap point.
       if (Seconds < 59)</pre>
       {
              Seconds++; // Move seconds ahead.
       }
       else
       {
             Seconds = 0; // Reset Seconds
              // and check Minutes for wrap.
             if (Minutes < 59)</pre>
                     Minutes++; // Move seconds ahead.
             else
              {
                     Minutes = 0; // Reset Minutes
                     // check Hours for wrap
                     if (Hours < 23)
                            Hours++;// Move Hours ahead.
                     else
                     {
                            Hours = 0;// Reset Hours
                     }// End of Hours test.
              } // End of Minutes test
       } // End of Seconds test
} // end of UpdateClock()
// Send Hours, Minutes and Seconds to a display.
void SendClock()
{
       // Check if leading zero needs to be sent
       if (Hours < 10)
       {
              LcdDriver.print("0");
       LcdDriver.print(Hours); // Then send hours
       LcdDriver.print(":"); // And separator
       // Check for leading zero on Minutes.
       if (Minutes < 10)</pre>
       {
             LcdDriver.print("0");
       LcdDriver.print(Minutes); // Then send Minutes
       LcdDriver.print(":"); // And separator
       // Check for leading zero needed for Seconds.
       if (Seconds < 10)</pre>
       {
             LcdDriver.print("0");
       LcdDriver.print(Seconds); // Then send Seconds
} // End of SendClock()
```

```
// States for setting clock.
enum ClockStates {
       CLOCK_RUNNING, CLOCK_SET_HOURS,
       CLOCK_SET_MINUTES, CLOCK_SET_SECONDS
ClockStates clockState = CLOCK RUNNING;
// Function that processes incoming characters to set the clock.
void SettingClock(int Button, int EncUpDown)
       // interpret input based on state
       switch (clockState)
       {
       case CLOCK_RUNNING:
              if (Button)
              {
                     clockState = CLOCK_SET_HOURS;
                     Hours = 0; // Reset clock values.
                     Minutes = 0;
                     Seconds = 0;
              }
              break;
       case CLOCK_SET_HOURS: //
              if (EncUpDown > 0)
                     Hours++;
                     if (Hours > 23)
                            Hours = 0;
              else if (EncUpDown < 0)</pre>
                     Hours--;
                     if (Hours < 0)</pre>
                            Hours = 23;
              else if (Button)
                     clockState = CLOCK SET MINUTES;
              break;
       case CLOCK_SET_MINUTES: //
              if (EncUpDown > 0)
              {
                     Minutes++;
                     if (Minutes > 59)
                            Minutes = 0;
              else if (EncUpDown < 0)</pre>
                     Minutes--;
                     if (Minutes < 0)</pre>
                            Minutes = 59;
              else if (Button)
                     clockState = CLOCK_SET_SECONDS;
              break;
       case CLOCK_SET_SECONDS: //
              if (EncUpDown > 0)
              {
                     Seconds++;
                     if (Seconds > 59)
                            Seconds = 0;
```

#endif

#### Appendix D: Button support

```
#ifndef ButtonDebounce H
#define ButtonDebounce H
// Set up pin and button state.
int ButtonPin = 4;
enum buttonStates { BS_Idle, BS_Wait, BS_Low };
buttonStates buttonState = BS_Idle;
unsigned long buttonTimer;
// Initialization code, setting up pin.
void ButtonInitialize(int pin)
{
       ButtonPin = pin;
       pinMode(ButtonPin, INPUT);
} // End of ButtonInitialize
// Function called in loop to check for button release.
// Returns a 1 on the buttons release.
int ButtonTest()
{
       // Read in the buttons current value.
       int Press = digitalRead(ButtonPin);
       int ReturnValue = 0;
       switch (buttonState)
       {
       case BS Idle: // if we are waiting for a press,
              if (Press == LOW)
                      // Once press occurs
                      buttonTimer = millis(); // record time
                      buttonState = BS Wait;
                                                    // and move to next state
              }
              break;
       case BS Wait: // button just went low
              if (Press == HIGH) // and now goes high
              {
                      buttonState = BS Idle; // return to 0 state.
              else // if still low
                      // and sufficient time has passed.
                      if (millis() - buttonTimer >= 10)
                      {
                             ReturnValue = 1; // Return 1 indicating pressed.
                             buttonState = BS Low; // move on to state two
                      }
              break;
       case BS Low:
              if (Press == HIGH)
              {
                      ReturnValue = 2; // Return 2 indicating release.
                      buttonState = BS_Idle;
              } // End of high test.
              break;
       } // End of switch on buttonState
       return ReturnValue;
} // End of ButtonRead
```

#endif

# Appendix E: Encoder support

```
#ifndef EncoderMonitor h
#define EncoderMonitor h
// Variable for keeping track of encoder change.
volatile int EncoderValue;
// Service Routine for Encoder line A
void EncoderMonitorPinA(void)
       // compare pin 3 and pin 2
       if (bitRead(PIND, 3) == bitRead(PIND, 2))
              EncoderValue--;
       }
       else
              EncoderValue++;
}// End of EncoderMonitorPinA
// Service Routine for Encoder line B
void EncoderMonitorPinB(void)
       // compare pin 3 and pin 2
       if (bitRead(PIND, 3) == bitRead(PIND, 2))
       {
              EncoderValue++; // Note this is the opposite
              // of the action in PinA.
       }
       else
       {
              EncoderValue--;
       }
} // End of EncoderMonitorPinB
// Initializes the Encoder Monitoring Code.
void EncoderInitialize()
{
       // Set encoder value to zero
      EncoderValue = 0;
       // Set up interrupts to monitor inputs from encoder.
       attachInterrupt(0, EncoderMonitorPinA, CHANGE);
attachInterrupt(1, EncoderMonitorPinB, CHANGE);
#endif
```