

ROLE CARD · OPERATOR · CREW STATION

Operator — Crew Station

A shared terminal for crews working the same operation. A PIN unlock lasts up to 24 hours (or until someone locks the station); every action is authorized by scanning YOUR badge — records always land under the scanned name.

THE STATION

- | | |
|---|---|
| 1 | First person in unlocks the station with the shared PIN. The unlock lasts up to ~24 hours — unless someone taps LOCK STATION, after which anyone re-enters the PIN. |
| 2 | Tap LOCK STATION when leaving it unattended — idle never locks it by itself. |
| 3 | After 90 seconds idle, a half-entered screen resets back to the crew board. Nothing partial is saved — just start the action again. |

JOIN, WORK, LEAVE

- | | |
|---|--|
| 1 | Tap a job, then scan your badge — the station decides: not on the roster = JOIN (clock-in); already on it = LEAVE (clock-out). |
| 2 | Badge sessions last 5 minutes. A mid-task “scan badge again” prompt is normal — scan and keep going. |
| 3 | REPORT PRODUCTION, HOLD, and COMPLETE all finish with a badge-signature scan; STEPS asks for your badge up front and records everything as “Recording as {your name}.” |
| 4 | COMPLETE clocks out the whole crew — the dialog names everyone it is closing out. Enter final pieces first if prompted. |

THE COUNTING RULE

- Crew quantities **add up** across everyone — enter only **NEW** pieces you have not reported yet. The banner “CREW TOTAL SO FAR: 37 of 50” is the shared running total; the server does not de-duplicate double reports.

WATCH OUT

TRAP — The out-of-tolerance HOLD + FILE NCR button closes everyone's open time entries. Your hours are not lost — they are saved and closed. Badge back in when the job resumes.