

ROLE CARD · OPERATOR · CREW STATION

Operator — Crew Station

A shared terminal for crews working the same operation. A PIN unlock lasts up to 24 hours (or until someone locks the station); every action is authorized by scanning YOUR badge — records always land under the scanned name.

THE STATION

- 1 First person in unlocks the station with the shared PIN. The unlock lasts up to ~24 hours — unless someone taps LOCK STATION, after which anyone re-enters the PIN.
- 2 Tap **LOCK STATION** when leaving it unattended — idle never locks it by itself.
- 3 After 90 seconds idle, a half-entered screen resets back to the crew board. Nothing you typed but did not confirm is saved — just start the action again. Pieces already tapped on **+1 PIECE** are saved for you whenever the station can reach the server — so do not re-tap them. If the board shows a notice that pieces were **not saved**, believe it: those pieces are not on the job, and a supervisor has to enter them in the office.

JOIN, WORK, LEAVE

- 1 Tap a job, then scan **your** badge — the station decides: not on the roster = JOIN (clock-in); already on it = LEAVE (clock-out).
- 2 Badge sessions last 5 minutes. A mid-task “scan badge again” prompt is normal — scan and keep going. If it is **your** badge on **that same job**, the count you keyed or tapped is carried across and saved, so never re-enter it.
- 3 If the screen says pieces belong to someone else, they do — only that operator, back on that job, can save them. Do not try to absorb them into your own count; ask them to scan, or have a supervisor record the pieces in the office.
- 4 REPORT PRODUCTION and STEPS ask for your badge **up front** and then record everything under that name (“Recording as {your name}”); HOLD and COMPLETE finish with a badge-signature scan instead.
- 5 Reporting production: tap **+1 PIECE** as each part comes off — it saves itself after about 5 seconds, and there is an **UNDO -1** button until it does. Keying a count and tapping RECORD still works for a batch. Once the lane says recorded, the fix is CORRECT OVER-COUNT, not an undo.
- 6 **COMPLETE** clocks out the **whole crew** — the dialog names everyone it is closing out. Enter final pieces first if prompted.

THE COUNTING RULE

- Crew quantities **add up** across everyone — enter only **NEW** pieces you have not reported yet. The banner “CREW TOTAL SO FAR: 37 of 50” is the shared running total; the server does not de-duplicate double reports.

WATCH OUT

TRAP — The out-of-tolerance HOLD + FILE NCR button closes everyone's open time entries. Your hours are not lost — they are saved and closed. Badge back in when the job resumes.