

ROLE CARD · RECEIVING · SUPERVISOR+

Receiving

Page: Warehouse > Receiving & Inspection tab. Lot numbers captured here are the traceability record.

RECEIVE

1	Pick the open PO, pick the line — quantity defaults to the remaining amount.
2	Receive. Enter lot numbers with care — they follow the material through every job (traceability).
3	Receiving more than the remaining quantity requires the over-receive approval checkbox.
4	Print the 4×6 receiving label from the success toast or the history row. A 409 “egress is disabled” means the admin has not enabled label printing — not a printer fault.
5	Items flagged requires inspection land in the inspection queue. Quality signs those off — receiving does not.

WATCH OUT

TRAP — Auto-print failures are SILENT by design (an incomplete or disabled print profile quietly no-ops). On your first live receive, physically confirm a label came out of the printer.