Aquifers

Today's agenda

- Finish water budgets
- Streams and stream discharge
- Aquifer systems and terminology
- Aquifer properties
- Unconfined, confined, and artesian aquifers

Types of streams


Temporal


- 1. Year-Round (Perennial)
- 2. Seasonal (Intermittent) Stream
- 3. Rain-Dependent (Ephemeral)
- a) Gaining and baseflow
- b) Losing

Stream Order


Rules:







Velocity (V) * Cross sectional area (A) = $Q(L^3/t)$



How d

F








FIGURE 2-1 Streamgaging by the USGS in 1890. SOURCE: Rabbitt (1989).

ethod








(Photograph courtesy of Michael Nolan, U.S. Geological Survey)

The current-meter method uses equipment such as (A) the Price AA current meter; (B) the Price AA current meter attached to a wading rod; and (C) the Price AA meter suspended above a heavy weight.




(Photograph courtesy of Michael Nolan, U.S. Geological Survey)

To measure velocity beneath ice, a mechanical current meter with a polymer rotor is attached to an ice rod and submerged through a hole drilled in the ice.

https://water.usgs.gov/edu/streamflow2.html

Stream Rating Curve



USGS Gages

- <u>19,740 total sites</u>
- Lots of parameters
 - Water Level/flow (stage height, Q, tide stage, etc.)
 - Water Quality (Chemistry, turbidity, EC)
 - Meteorology (Precip, Temp, Solar radiation, wind)
 - Physical Properties (e.g. ET, wave period/height, etc.)
- https://waterdata.usgs.gov/nwis/rt