

DA-Care Device Troubleshooting Guide

Laptop does not turn on

Disconnect the charger and all peripherals. Hold the power button for 15 seconds to discharge residual power. Reconnect the charger and try again. If the charging light continues to blink, request an engineer visit.

Air conditioner does not cool

Confirm cooling mode and set the target temperature at least 3 degrees below room temperature. Clean the air filter and check that the outdoor unit ventilation is not blocked. If an error code is displayed, record it before requesting service.

Refrigerator is not cold

Check that the power plug is connected and the temperature control is not set to warm. Leave clearance around the rear ventilation area. Do not repeatedly open the door for 30 minutes before checking again.

Vacuum cleaner has weak suction

Empty the dust container, remove hair from the brush, and wash or replace the filter according to its maintenance cycle. Stop use and request service if there is a burning smell or unusual noise.