

Crystallization of Benzoic Acid in a Mixed Suspension, Mixed Product Removal Crystallizer

Introduction

Crystallization is a key separation process in chemical engineering. Hundreds of millions of tons of materials are produced by crystallization yearly. Some examples of materials produced by crystallization include sodium chloride, sodium sulphates and sucrose. A main motivation for using crystallization is that separating a product from a solution by crystallizing it out of solution usually requires less energy than evaporating the solvent.

Crystallization takes place in two steps. First, a crystal nuclei must form (nucleation). Second, the nuclei grows by deposition of more crystal material (growth). The driving force for crystallization is the degree of supersaturation. Supersaturation can be achieved for example by cooling the solution. Upon cooling, the solution becomes supersaturated, and crystallization can begin. The key objective in designing and operating a crystallizer is to control the crystal size distribution. For example, in the crystallization of a pharmaceutical product, the size of the crystals formed will determine the time the product will take to dissolve in the stomach of a patient.

In this example, the crystallization of benzoic acid is modeled in an idealized continuous crystallizer known as a "mixed suspension, mixed product removal reactor". A 0D model is defined, and a population balance equation is solved to calculate the crystal size distribution and the mean particle size under different conditions. The model is based on a paper by Morris and others (Ref. 1). Figure 1 shows a sketch of the crystallizer setup.




Figure 1: Sketch of the MSMPR setup. The crystallizer is kept at a temperature below that of the feed to create supersaturation.

Model Definition

The crystallization of benzoic acid is modeled in 0D. The crystallizer and the feed vessel are both assumed to be perfectly mixed and operated in steady state. Kinetic parameters fitted to experimental data in Ref. 1 are used.

For an ideal MSMPR crystallizer, the analytical solution to the population balance equation is

$$n = n^0 \exp\left(-\frac{L}{G\tau}\right),\tag{1}$$

where n is the population density, n^0 is the nuclei population density, L is the crystal size, G is the crystal growth rate, and τ is the mean residence time. The mass-based mean crystal size distribution is found by taking the ratio of the fourth and third moments of n as defined by Equation 1. The nuclei population density is obtained from

$$n^0 = \frac{B^0}{G},\tag{2}$$

where B^0 is the nucleation rate. The nucleation rate is given by

$$B^0 = k_{\rm b} M_{\rm T}^j \Delta C^b, \tag{3}$$

where $k_{\rm b}$ is a nucleation rate coefficient, $M_{\rm T}$ is the MSMPR suspension crystal weight fraction, ΔC is the driving force for crystallization, and j and b are dimensionless parameters. The driving force for crystallization is given by

$$\Delta C = C - C^{*}(T), \tag{4}$$

where C is the benzoic acid mass fraction (g benzoic acid/kg solvent) in the MSMPR crystallizer, and $C^*(T)$ is the saturation mass fraction.

The saturation mass fraction is obtained from a polynomial expression determined experimentally for a mixture of benzoic acid in 1.5:1~(w/w) water/ethanol:

$$C^*(T) = 2.03 \times 10^{-5} T^4 + 2.97 \times 10^{-4} T^3 + 4.70 \times 10^{-2} T^2 + 1.43 T + 24.71$$
 (5)

A graphical representation of C^* is found in Figure 2.




Figure 2: The saturation mass fraction of benzoic acid as a function of temperature.

The growth rate is obtained from

$$G = k_{g} \Delta C^{g}, \tag{6}$$

where k_g is the crystal growth rate coefficient and g is a fitted kinetic parameter. In turn, the crystal growth rate coefficient is obtained from

$$k_{\rm g} = k_{\rm g0} \exp\left(-\frac{E_{\rm g}}{RT}\right),\tag{7}$$

where $k_{\rm g0}$ is the Arrhenius expression pre-exponential factor, and $E_{\rm g}$ is the activation energy for crystal growth.

Solving for the crystal concentration allows the population density to be determined. A mass balance on the crystallizer gives the equation

$$C_0 - C = M_{\mathrm{T}}. \tag{8}$$

Here, C_0 is the concentration of benzoic acid in the feed. Furthermore, the suspension crystal weight fraction is related to the nuclei population density and the growth rate through

$$M_{\rm T} = 6k_{\rm v}\rho_{\rm c}n^0(G\tau)^4,\tag{9}$$

where k_v and ρ_c are the volumetric shape factor and density of the crystals, respectively.

The crystal concentration is obtained by solving for the difference of these two definitions of $M_{\rm T}$, that is

$$M_{T,(8)} - M_{T,(9)} = 0.$$
 (10)

Equation 10 is solved for in a Global Equations node.

The steady-state mass-weighted mean crystal size, $L_{4,3}$, is calculated from the ratio of the fourth and third moments of the crystal size distribution, using the following expression:

$$L_{4,3} = \frac{0}{\infty}$$

$$\int_{0}^{\infty} nL^{3} dL$$
(11)

Results and Discussion

Crystal size distributions are determined for the experimental setup giving the largest and smallest crystal sizes, and for sweeps from low to high reactor temperature, and low to high residence time. Finally, the effect on the mean particle size of both reactor temperature, and of residence time, is examined.

CRYSTAL SIZE DISTRIBUTIONS




Figure 3: Crystal size distributions for the experimental conditions where the smallest and largest particles are produced.

Figure 3 shows the crystal size distributions for the combinations of temperature and residence time that results in production of the smallest and the largest particles. These results agree well with those from Ref. 1.




Figure 4: Crystal size distributions for increasing crystallizer temperatures.

Figure 2 shows that the saturation mass fraction of benzoic acid increases with temperature. This reduces the driving force for crystallization, ΔC . At the same time, the growth rate of the crystals increases with increasing temperature, according to Equation 6. The effect on the crystal size distribution is that the crystals that do form, grow to larger average sizes. Increasing the residence time also has a similar effect, as seen in Figure 5.




Figure 5: The effect of residence time on the crystal size distribution.

MEAN PARTICLE SIZE

Figure 6 and Figure 7 show the average crystal size for different temperatures and residence times, respectively.




Figure 6: The effect of temperature on the average particle size. The residence time is 45 min.




Figure 7: The effect of residence time on the average particle size. The crystallizer temperature is 30°C.

Notes About the COMSOL Implementation

The original paper (Ref. 1) defined crystal concentrations in both g/ml solvent and g/g solvent, but for simplicity, this model defines concentrations only in g/kg solvent. This does not affect the resulting crystal size distributions.

References

- 1. G. Morris, G. Power, S. Ferguson, M. Barrett, G.Hou, and B. Glennon, "Estimation of Nucleation and Growth Kinetics of Benzoic Acid by Population Balance Modeling of a Continuous Cooling Mixed Suspension, Mixed Product Removal Crystallizer," *Org. Process Res. Dev.*, vol. 19, pp. 1891–1902, 2015.
- 2. J.F. Richardson, J.H. Harker, and J.R. Backhurst, Coulson & Richardson's Chemical Engineering, vol. 2, 5th edition, Elsevier, 2002.

Application Library path: Chemical_Reaction_Engineering_Module/ Mixing_and_Separation/benzoic_acid_crystallization

Modeling Instructions

A 0D model using a Global Equations interface will be used to describe the crystallization process.

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click 0D.
- 2 In the Select Physics tree, select Mathematics>ODE and DAE Interfaces> Global ODEs and DAEs (ge).
- 3 Click Add.
- 4 Click Study.
- 5 In the Select Study tree, select General Studies>Stationary.
- 6 Click **Done**.

Import the parameters for the model.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- 3 Click Load from File.
- **4** Browse to the model's Application Libraries folder and double-click the file benzoic_acid_crystallization_parameters.txt.
- 5 In the Home toolbar, click Pi Parameter Case.

Define two parameter cases to simulate the conditions that give rise to the smallest and the largest crystals.

- 6 In the Settings window for Case, type Experiment Giving Largest Crystals in the Label text field.
- 7 In the Home toolbar, click Pi Parameter Case.
- 8 In the Settings window for Case, type Experiment Giving Smallest Crystals in the Label text field.
- **9** Locate the **Parameters** section. In the table, enter the following settings:

| Name | Expression | Description |
|------|------------|-----------------------------|
| Т | O[degC] | MSMPR operating temperature |
| tau | 20 [min] | Residence time |

Define a Function representing the saturation mass fraction.

Saturation Mass Fraction

- I In the Home toolbar, click f(x) Functions and choose Global>Analytic.
- 2 In the Settings window for Analytic, type Saturation Mass Fraction in the Label text field.
- **3** In the **Function name** text field, type **C_star**.
- 4 Locate the **Definition** section. In the **Expression** text field, type $2.03e-5*T^4 + 2.97e-4*T^3 + 4.70e-2*T^2 + 1.43*T + 24.71.$
- 5 In the Arguments text field, type T.
- 6 Locate the Units section. In the Function text field, type g/kg.
- 7 In the table, enter the following settings:

| Argument | Unit |
|----------|------|
| Т | degC |

8 Locate the **Plot Parameters** section. In the table, enter the following settings:

| Plot | Argument | Lower limit | Upper limit | Fixed value | Unit |
|-----------|----------|-------------|-------------|-------------|------|
| $\sqrt{}$ | Т | -15[degC] | 40[degC] | 0 | K |

9 Click To Create Plot.


RESULTS

Saturation Mass Fraction

I In the **Settings** window for **ID Plot Group**, type Saturation Mass Fraction in the **Label** text field.

- 2 Click to expand the **Title** section. In the **Title** text area, type Saturation Mass Fraction.
- 3 Locate the Plot Settings section.
- 4 Select the **y-axis label** check box. In the associated text field, type C^{*}(T) (g/kg).
- 5 In the Saturation Mass Fraction toolbar, click Plot.

The saturation mass fraction increases with temperature. Decreasing the temperature is a key driving force for crystallization.



To simplify the model setup, import the required variable expressions from a separate file.

DEFINITIONS

Variables 1

- I In the Home toolbar, click **a= Variables** and choose **Local Variables**.
- 2 In the Settings window for Variables, locate the Variables section.
- 3 Click Load from File.
- **4** Browse to the model's Application Libraries folder and double-click the file benzoic_acid_crystallization_variables.txt.

Define the global equation that will be solved to obtain the benzoic acid mass fraction.

GLOBAL ODES AND DAES (GE)

Global Equations I (ODEI)

- I In the Model Builder window, under Component I (compl)>Global ODEs and DAEs (ge) click Global Equations I (ODEI).
- 2 In the Settings window for Global Equations, locate the Global Equations section.
- **3** In the table, enter the following settings:

| Name | f(u,ut,utt, t) (l) | Initial value (u_0) (1) | Initial value (u_t0) (1/s) | Description |
|------|-----------------------|----------------------------|-------------------------------|----------------------------|
| С | M_T_MB- M_T_MR | C_star(T) +1[g/kg] | 0 | Benzoic acid mass fraction |

- 4 Locate the Units section. Click Define Dependent Variable Unit.
- **5** In the **Dependent variable quantity** table, enter the following settings:

| Dependent variable quantity | Unit |
|-----------------------------|------|
| Custom unit | g/kg |

- 6 Click Define Source Term Unit.
- 7 In the Source term quantity table, enter the following settings:

| Source term quantity | Unit |
|----------------------|------|
| Custom unit | g/kg |

STUDY I: EXTREME CASES

- I In the Model Builder window, click Study I.
- 2 In the Settings window for Study, type Study 1: Extreme Cases in the Label text field.

Parametric Sweep

- I In the Study toolbar, click Parametric Sweep.
- 2 In the Settings window for Parametric Sweep, locate the Study Settings section.
- 3 From the Sweep type list, choose Parameter switch.
- 4 Click + Add.
- 5 In the Study toolbar, click **Compute**.

Plot the crystal size distributions for the experiments giving the smallest and the largest crystals .

RESULTS

Grid 1D: Extreme Cases

- I In the Results toolbar, click More Datasets and choose Grid>Grid ID.
- 2 In the Settings window for Grid ID, type Grid 1D: Extreme Cases in the Label text field.
- 3 Locate the Parameter Bounds section. In the Name text field, type L.
- 4 Locate the Data section. From the Dataset list, choose Study 1: Extreme Cases/Parametric Solutions 1 (sol2).
- 5 Locate the Parameter Bounds section. In the Maximum text field, type L_max.

CSD for Extreme Cases

- I In the Results toolbar, click \sim ID Plot Group.
- 2 In the Settings window for ID Plot Group, type CSD for Extreme Cases in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Grid ID: Extreme Cases.
- 4 Click to expand the **Title** section. From the **Title type** list, choose **Manual**.
- 5 In the Title text area, type Volume-based Mean Crystal Size Distribution.
- 6 Locate the Plot Settings section.
- 7 Select the **y-axis label** check box. In the associated text field, type Crystal Size Distribution (%).
- **8** Locate the **Axis** section. Select the **x-axis log scale** check box.
- **9** Locate the **Legend** section. From the **Position** list, choose **Upper left**.

Line Graph 1

- I In the CSD for Extreme Cases toolbar, click Line Graph.
- 2 In the Settings window for Line Graph, locate the y-Axis Data section.
- 3 In the Expression text field, type (n0 * exp(- L / (G*tau))*L^4)/ integrate((n0 * exp(- L / (G*tau)))*L^3, L, O, L_max).
- 4 From the Unit list, choose %.
- 5 Locate the x-Axis Data section. From the Parameter list, choose Expression.
- **6** In the **Expression** text field, type L.
- 7 From the **Unit** list, choose μ m.
- **8** Select the **Description** check box. In the associated text field, type Crystal size.
- 9 Click to expand the Legends section. Select the Show legends check box.

10 From the Legends list, choose Manual.

II In the table, enter the following settings:

Legends $T = 20 \deg C$, $\tan = 45 \min$ $T = 0 \setminus deg C$, $\setminus tau = 15 min$

12 In the CSD for Extreme Cases toolbar, click Plot.


Graph Marker I

- I In the Model Builder window, right-click Line Graph I and choose Graph Marker.
- 2 In the Settings window for Graph Marker, locate the Text Format section.
- 3 In the Display precision text field, type 3.
- 4 Select the **Show x-coordinate** check box.
- **5** Clear the **Show y-coordinate** check box.
- 6 Click to expand the Coloring and Style section. From the Anchor point list, choose Lower middle.
- 7 In the CSD for Extreme Cases toolbar, click Plot.

CSD for Extreme Cases

- I In the Model Builder window, under Results click CSD for Extreme Cases.
- 2 In the Settings window for ID Plot Group, locate the Axis section.
- 3 Select the Manual axis limits check box.
- 4 In the x minimum text field, type 10.
- 5 In the y maximum text field, type 90.

6 In the CSD for Extreme Cases toolbar, click Plot.



Next, we'll set up a study to calculate the effect of temperature on the crystal size. For this study, the longest residence time will be used.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies>Stationary.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 2: TEMPERATURE SWEEP

- I In the Model Builder window, click Study 2.
- 2 In the Settings window for Study, type Study 2: Temperature Sweep in the Label text field.

Step 1: Stationary

- I In the Model Builder window, under Study 2: Temperature Sweep click Step 1: Stationary.
- 2 In the Settings window for Stationary, click to expand the Study Extensions section.

- 3 Select the Auxiliary sweep check box.
- 4 Click + Add.
- **5** In the table, enter the following settings:

| Parameter name | Parameter value list | Parameter unit |
|--------------------|----------------------|----------------|
| T (MSMPR operating | range(0,1,30) | degC |
| temperature) | | |

Solution 5 (sol5)

- I In the Study toolbar, click Show Default Solver.
- 2 In the Model Builder window, expand the Solution 5 (sol5) node, then click Stationary Solver 1.
- 3 In the Settings window for Stationary Solver, locate the General section.
- **4** In the **Relative tolerance** text field, type 0.0001. Reduce the solver tolerance to avoid numerical noise in the temperature sweep results.
- 5 In the Study toolbar, click **Compute**.

RESULTS

Grid ID: Extreme Cases

In the Model Builder window, under Results>Datasets right-click Grid ID: Extreme Cases and choose **Duplicate**.

Grid ID: Temperature Sweep

- I In the Model Builder window, under Results>Datasets click Grid ID: Extreme Cases I.
- 2 In the Settings window for Grid ID, type Grid 1D: Temperature Sweep in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 2: Temperature Sweep/ Solution 5 (sol5).

CSD for Extreme Cases

In the Model Builder window, under Results right-click CSD for Extreme Cases and choose Duplicate.

CSD for Temperature Sweep

- I In the Model Builder window, under Results click CSD for Extreme Cases I.
- 2 In the Settings window for ID Plot Group, type CSD for Temperature Sweep in the Label text field.


- 3 Locate the Data section. From the Dataset list, choose Grid ID: Temperature Sweep.
- 4 From the Parameter selection (T) list, choose From list.
- 5 In the Parameter values (T (degC)) list, choose 0, 15, and 30.

Line Graph I

- I In the Model Builder window, expand the CSD for Temperature Sweep node, then click Line Graph I.
- 2 In the Settings window for Line Graph, locate the Legends section.
- 3 From the Legends list, choose Automatic.

CSD for Temperature Sweep

- I In the Model Builder window, click CSD for Temperature Sweep.
- 2 In the CSD for Temperature Sweep toolbar, click **2** Plot.



Next, we'll set up a study to calculate the effect of residence time on the crystal size. For this study, the highest temperature will be used.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.

- 3 Find the Studies subsection. In the Select Study tree, select General Studies>Stationary.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 3: RESIDENCE TIME SWEEP

- I In the Model Builder window, click Study 3.
- 2 In the Settings window for Study, type Study 3: Residence Time Sweep in the Label text field.

Step 1: Stationary

- I In the Model Builder window, under Study 3: Residence Time Sweep click Step 1: Stationary.
- 2 In the Settings window for Stationary, locate the Study Extensions section.
- 3 Select the Auxiliary sweep check box.
- 4 Click + Add.
- **5** In the table, enter the following settings:

| Parameter name | Parameter value list | Parameter unit |
|----------------------|----------------------|----------------|
| tau (Residence time) | range(15,1,45) | min |

6 In the Home toolbar, click **Compute**.

RESULTS

Grid ID: Temperature Sweep

In the Model Builder window, under Results>Datasets right-click

Grid ID: Temperature Sweep and choose **Duplicate**.

Grid ID: Residence Time Sweep

- In the Model Builder window, under Results>Datasets click Grid ID: Temperature Sweep I.
- 2 In the Settings window for Grid ID, type Grid 1D: Residence Time Sweep in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 3: Residence Time Sweep/ Solution 6 (sol6).

CSD for Temperature Sweep


In the Model Builder window, under Results right-click CSD for Temperature Sweep and choose **Duplicate**.

CSD for Residence Time Sweep

- I In the Model Builder window, under Results click CSD for Temperature Sweep 1.
- 2 In the Settings window for ID Plot Group, type CSD for Residence Time Sweep in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Grid ID: Residence Time Sweep.
- 4 In the Model Builder window, expand the CSD for Residence Time Sweep node.

Graph Marker I

- I In the Model Builder window, expand the Results>CSD for Residence Time Sweep> Line Graph I node, then click Graph Marker I.
- 2 In the Settings window for Graph Marker, locate the Coloring and Style section.
- 3 From the Orientation list, choose Vertical.
- 4 From the Anchor point list, choose Middle left.
- 5 In the CSD for Residence Time Sweep toolbar, click **Plot**.



Mean Particle Size for Different Operating Temperatures

I In the **Home** toolbar, click Add Plot Group and choose ID Plot Group.

Finally, create two plots showing the effect on average particle size of temperature, and residence time, respectively.

- 2 In the Settings window for ID Plot Group, type Mean Particle Size for Different Operating Temperatures in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 2: Temperature Sweep/ Solution 5 (sol5).
- 4 Locate the Legend section. From the Position list, choose Upper left.


Global I

- I In the Mean Particle Size for Different Operating Temperatures toolbar, click (Global. The mean particle size plots do not use a Grid dataset. For this reason, L is not defined. We will instead use the formal integration constant parameter L_int.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

| Expression | Unit | Description |
|--|------|--------------------|
| <pre>integrate(n0 * exp(- L_int / (G*tau))* L_int^4, L_int, 0, L_max) / integrate((n0 * exp(- L_int / (G* tau)))*L_int^3, L_int, 0, L_max)</pre> | um | Mean Particle Size |

- 4 Locate the x-Axis Data section. From the Parameter list, choose Expression.
- **5** In the **Expression** text field, type T.
- 6 From the Unit list, choose degC.

7 In the Mean Particle Size for Different Operating Temperatures toolbar, click **1** Plot.



Mean Particle Size for Different Operating Temperatures

In the Model Builder window, right-click

Mean Particle Size for Different Operating Temperatures and choose Duplicate.

Mean Particle Size for Different Residence Times

- I In the Model Builder window, under Results click

 Mean Particle Size for Different Operating Temperatures I.
- 2 In the Settings window for ID Plot Group, type Mean Particle Size for Different Residence Times in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 3: Residence Time Sweep/ Solution 6 (sol6).

Global I

- I In the Model Builder window, expand the Mean Particle Size for Different Residence Times node, then click Global I.
- 2 In the Settings window for Global, locate the x-Axis Data section.
- **3** In the **Expression** text field, type tau.
- 4 From the Unit list, choose min.

