

Electric Sensor

This example illustrates — in a simplified electrostatic setting — electric impedance tomography (EIT), a method used for imaging of the distribution of electrical permittivity in an object. The tomography is performed by measuring currents and voltages at the object's surface.

An application of this technique is medical diagnosis. Due to the different electrical properties of various organs and parts of the body, it is possible to obtain information on their position and movement in a noninvasive way.

This model shows how to determine from the outside the shape and the placement of small objects with different material properties inside a box. Applying a potential difference on the boundaries of the box creates a surface charge density that varies depending on the permittivity distribution inside the box.

Model Definition

This model solves Gauss' law with $\rho = 0$:

$$-\nabla \cdot (\varepsilon_0 \varepsilon_r \nabla V) = \rho$$

The box contains air with ε_r equal to 1. The different objects are made of materials with different values of the relative permittivity, ε_r : 1, 2, and 3.

To get a voltage difference, a ground condition (V = 0) is set on the bottom while the condition V = 1 is applied on the top of the box. On the side, the boundary condition used is electric insulation: $\mathbf{n} \cdot \mathbf{D} = 0$.

Results and Discussion

As seen in Figure 1, the surface charge density is higher in correspondence of materials with higher permittivity, as expected. An imaging of the figures inside the box is reproduced in the surface charge density plot.




Figure 1: Surface charge density (boundary), electric field (streamline density), and electric potential (streamline color).

Inside the geometry, the streamlines show how the electric field varies. The electric field is lower in media with larger value of the permittivity.

Application Library path: COMSOL_Multiphysics/Electromagnetics/ electric_sensor

Modeling Instructions

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

I In the Model Wizard window, click 1 3D.

- 2 In the Select Physics tree, select AC/DC>Electric Fields and Currents>Electrostatics (es).
- 3 Click Add.
- 4 Click 🗪 Study.
- 5 In the Select Study tree, select General Studies>Stationary.
- 6 Click M Done.

GEOMETRY I

Work Plane I (wbl)

- I In the Geometry toolbar, click Work Plane.
- 2 In the Settings window for Work Plane, locate the Plane Definition section.
- 3 In the z-coordinate text field, type 0.1.
- 4 Click A Go to Plane Geometry.

Work Plane I (wpI)>Rectangle I (rI)

- I In the Work Plane toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- **3** In the **Width** text field, type **0.5**.
- 4 In the Height text field, type 2.
- **5** Locate the **Position** section. In the **xw** text field, type -1.
- 6 In the yw text field, type 0.5.
- 7 Click **Build Selected**.

Work Plane I (wpI)>Rectangle 2 (r2)

- I In the Work Plane toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- 3 In the Width text field, type 1.5.
- 4 In the **Height** text field, type 0.25.
- $\begin{tabular}{ll} \textbf{5} & Locate the \textbf{Position} section. In the \textbf{xw} text field, type -1.5. \\ \end{tabular}$
- 6 In the yw text field, type 1.
- 7 Click 🖺 Build Selected.

Work Plane I (wpI)>Rectangle 3 (r3)

- I In the Work Plane toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.

- 3 In the Width text field, type 1.5.
- 4 In the Height text field, type 0.25.
- **5** Locate the **Position** section. In the **xw** text field, type -1.5.
- 6 In the yw text field, type 1.75.
- 7 Click | Build Selected.

Work Plane I (wp I)>Union I (uni I)

- I In the Work Plane toolbar, click Booleans and Partitions and choose Union.
- 2 Click in the **Graphics** window and then press Ctrl+A to select all objects.
- 3 In the Settings window for Union, locate the Union section.
- 4 Clear the Keep interior boundaries check box.
- 5 Click | Build Selected.
- 6 Click the **Zoom Extents** button in the **Graphics** toolbar.

Work Plane I (wp I)>Ellipse I (e I)

- I In the Work Plane toolbar, click Ellipse.
- 2 In the Settings window for Ellipse, locate the Size and Shape section.
- 3 In the a-semiaxis text field, type 0.5.
- 4 Locate the **Position** section. In the xw text field, type 1.5.
- **5** In the **yw** text field, type 1.5.
- 6 Click | Build Selected.
- 7 Click the Zoom Extents button in the Graphics toolbar.


Work Plane I (wp I)>Ellipse 2 (e2)

- I In the Work Plane toolbar, click Ellipse.
- 2 In the Settings window for Ellipse, locate the Size and Shape section.
- **3** In the **b-semiaxis** text field, type 0.5.
- 4 Locate the **Position** section. In the xw text field, type 1.5.
- 5 In the yw text field, type 1.5.
- 6 Click 🖺 Build Selected.

Work Plane I (wpI)>Compose I (coI)

- I In the Work Plane toolbar, click Booleans and Partitions and choose Compose.
- 2 Select the objects el and e2 only.
- 3 In the Settings window for Compose, locate the Compose section.

- 4 Clear the Keep interior boundaries check box.
- 5 In the Set formula text field, type e1+e2.
- 6 Click **Build Selected**.
- 7 Click the **Zoom Extents** button in the **Graphics** toolbar.



Extrude I (extI)

- I In the Model Builder window, under Component I (compl)>Geometry I right-click Work Plane I (wpl) and choose Extrude.
- 2 In the Settings window for Extrude, locate the Distances section.
- 3 In the table, enter the following settings:

Distances (m)


- 4 Click | Build Selected.
- 5 Click the **Come Extents** button in the **Graphics** toolbar.

Block I (blk I)

- I In the Geometry toolbar, click Block.
- 2 In the Settings window for Block, locate the Size and Shape section.

- 3 In the Width text field, type 5.
- 4 In the **Depth** text field, type 3.
- **5** Locate the **Position** section. In the **x** text field, type -2.
- 6 Click Build All Objects.
- 7 Click the **Zoom Extents** button in the **Graphics** toolbar.
- 8 Click the Transparency button in the Graphics toolbar.

This completes the model geometry.



ELECTROSTATICS (ES)

Ground I

- I In the Model Builder window, under Component I (compl) right-click Electrostatics (es) and choose Ground.
- 2 Select Boundary 3 only.

Electric Potential I

- I In the Physics toolbar, click **Boundaries** and choose **Electric Potential**.
- 2 Select Boundary 4 only.
- 3 In the Settings window for Electric Potential, locate the Electric Potential section.

4 In the V_0 text field, type 1.

MATERIALS

Material I (mat I)

- I In the Model Builder window, under Component I (comp I) right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, locate the Material Contents section.
- **3** In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic

Material 2 (mat2)

- I Right-click Materials and choose Blank Material.
- 2 Select Domain 2 only.
- 3 In the Settings window for Material, locate the Material Contents section.
- **4** In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	2	I	Basic

Material 3 (mat3)


- I Right-click Materials and choose Blank Material.
- 2 Select Domain 3 only.
- 3 In the Settings window for Material, locate the Material Contents section.

4 In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	3	I	Basic

MESH I

- I In the Model Builder window, under Component I (compl) click Mesh I.
- 2 In the Settings window for Mesh, locate the Physics-Controlled Mesh section.
- **3** From the **Element size** list, choose **Fine**.
- 4 Click **Build All**.



STUDY I

- I In the Model Builder window, click Study I.
- 2 In the Settings window for Study, locate the Study Settings section.
- 3 Clear the Generate default plots check box.
- 4 In the Home toolbar, click **Compute**.

To reproduce the plot shown in Figure 1, begin by suppressing some boundaries so that the inside of the box becomes visible.

RESULTS

In the Model Builder window, expand the Results node.

Study I/Solution I (soll)

In the Model Builder window, expand the Results>Datasets node, then click Study 1/ Solution I (soll).

Selection

- I In the Results toolbar, click hattributes and choose Selection.
- 2 In the Settings window for Selection, locate the Geometric Entity Selection section.
- 3 From the Geometric entity level list, choose Boundary.
- 4 From the Selection list, choose All boundaries.
- **5** Select Boundaries 3–5 and 38 only.
- **6** Click the **Transparency** button in the **Graphics** toolbar.

3D Plot Group 1

In the **Results** toolbar, click **3D Plot Group**.

Surface I

- I Right-click 3D Plot Group I and choose Surface.
- 2 In the Settings window for Surface, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component I (compl)>Electrostatics> Currents and charge>es.nD - Surface charge density - C/m2.
- 3 Locate the Expression section. In the Unit field, type pC/m^2.
- 4 Locate the Coloring and Style section. Click Change Color Table.
- 5 In the Color Table dialog box, select Rainbow>Cyclic in the tree.
- 6 Click OK.
- 7 In the 3D Plot Group I toolbar, click Plot.
- 8 Click the **Zoom Extents** button in the **Graphics** toolbar.

Streamline 1

- I In the Model Builder window, right-click 3D Plot Group I and choose Streamline.
- 2 In the Settings window for Streamline, locate the Streamline Positioning section.
- 3 From the Positioning list, choose Magnitude controlled.

4 Locate the **Coloring and Style** section. Find the **Line style** subsection. From the **Type** list, choose **Tube**.

Color Expression 1

- I Right-click Streamline I and choose Color Expression.
- 2 In the Settings window for Color Expression, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component I (compl)> Electrostatics>Electric>es.normE Electric field norm V/m.
- 3 Click to expand the Title section. From the Title type list, choose Automatic.
 Compare the resulting plot with that in Figure 1.