

ID Lithium-Ion Battery Model for the Capacity Fade Tutorial

Introduction

This is a template model containing the physics, geometry, and mesh of a lithium-ion battery (without any capacity fade reactions or mechanisms added). The Capacity Fade of a Lithium-Ion Battery application available in the Application Library makes use of this model setup.

The battery cell model is created using the Lithium-Ion Battery interface. A more detailed description on how to set up this type of model can be found in the model example 1D Isothermal Lithium-Ion Battery.

Model Definition

The model is set up for a graphite/NCA battery cell. The materials are available from the Battery Material Library and mainly default settings are selected. The model domains consist of:

- Negative porous electrode: Graphite (MCMB Li_xC₆) active material.
- Separator.
- Positive porous electrode: NCA (LiNi_{0.8}Co_{0.15}Al_{0.05}O₂) active material.
- Electrolyte: 1.0 M LiPF₆ in EC:EMC (3:7 by weight)

The Lithium-Ion Battery interface accounts for:

- · Electronic conduction in the electrodes
- Ionic charge transport in the electrodes and electrolyte/separator
- Material transport in the electrolyte, allowing for the introduction of the effects of concentration on ionic conductivity and concentration overpotential
- Material transport within the spherical particles that form the electrodes
- Butler-Volmer electrode kinetics using experimentally measured discharge curves for the equilibrium potential.

Application Library path: Battery_Design_Module/Batteries,_Lithium-Ion/ capacity fade seed

Modeling Instructions

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click ID.
- 2 In the Select Physics tree, select Electrochemistry>Batteries>Lithium-lon Battery (liion).
- 3 Click Add.
- 4 Click Study.
- 5 In the Select Study tree, select Preset Studies for Selected Physics Interfaces>
 Time Dependent with Initialization.
- 6 Click M Done.

ROOT

Add the model parameters from a text file.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- 3 Click Load from File.
- **4** Browse to the model's Application Libraries folder and double-click the file capacity_fade_parameters.txt.

GEOMETRY I

Interval I (i1)

- I In the Model Builder window, under Component I (compl) right-click Geometry I and choose Interval.
- 2 In the Settings window for Interval, locate the Interval section.
- 3 From the Specify list, choose Interval lengths.
- **4** In the table, enter the following settings:

Lengths (m)	
L_neg	
L_sep	
L_pos	

5 Click Build All Objects.

MATERIALS

Load the materials from the material library.

ADD MATERIAL

- I In the Home toolbar, click Radd Material to open the Add Material window.
- 2 Go to the Add Material window.
- 3 In the tree, select Battery>Electrolytes>LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery).
- 4 Right-click and choose Add to Component I (compl).
- 5 In the tree, select Battery>Electrodes>Graphite, LixC6 MCMB (Negative, Li-ion Battery).
- 6 Right-click and choose Add to Component I (compl).
- 7 In the tree, select Battery>Electrodes>NCA, LiNi0.8Co0.15Al0.0502 (Positive, Liion Battery).
- 8 Right-click and choose Add to Component I (compl).
- 9 In the Home toolbar, click 🤼 Add Material to close the Add Material window.

DEFINITIONS

Explicit selections are made in the model geometry.

Negative Electrode

- I In the **Definitions** toolbar, click **\(\frac{1}{2} \) Explicit**.
- 2 In the Settings window for Explicit, type Negative Electrode in the Label text field.
- 3 Select Domain 1 only.

Separator

- I In the **Definitions** toolbar, click 堶 **Explicit**.
- 2 In the Settings window for Explicit, type Separator in the Label text field.
- 3 Select Domain 2 only.

Positive Electrode

- I In the **Definitions** toolbar, click **\(\frac{1}{3} \) Explicit**.
- 2 In the Settings window for Explicit, type Positive Electrode in the Label text field.
- **3** Select Domain 3 only.

LITHIUM-ION BATTERY (LIION)

- I In the Model Builder window, under Component I (compl) click Lithiumlon Battery (liion).
- 2 In the Settings window for Lithium-Ion Battery, locate the Cross-Sectional Area section.
- **3** In the A_c text field, type A_cell.
- 4 Locate the Cell Settings section. Select the Define cell state of charge (SOC) and initial charge inventory check box.

SOC and Initial Charge Distribution I

- I In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click SOC and Initial Charge Distribution I.
- 2 In the Settings window for SOC and Initial Charge Distribution, locate the State-of-Charge Definition section.
- **3** From the list, choose **User defined**. In the $E_{\rm cell}^{0}$ %SOC text field, type E_cell_0SOC.
- **4** In the $E_{\rm cell}^{100}\%SOC$ text field, type E_cell_100SOC.
- 5 Locate the Initial Cell Charge Distribution section. From the Define by list, choose Cell voltage.
- **6** In the $E_{\text{cell.0}}$ text field, type E_min.

Negative Electrode Selection I

- I In the Model Builder window, click Negative Electrode Selection I.
- 2 In the Settings window for Negative Electrode Selection, locate the Domain Selection section.
- 3 From the Selection list, choose Negative Electrode.

Positive Electrode Selection I

- I In the Model Builder window, click Positive Electrode Selection I.
- 2 In the Settings window for Positive Electrode Selection, locate the Domain Selection section.
- **3** From the **Selection** list, choose **Positive Electrode**.

Separator I

- I In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click Separator I.
- 2 In the Settings window for Separator, locate the Porous Matrix Properties section.
- **3** In the ε_1 text field, type epsl_sep.

- 4 Locate the Effective Transport Parameter Correction section. From the Electrolyte conductivity list, choose User defined. In the f_1 text field, type eps1 sep^brug1 sep.
- **5** From the **Diffusion** list, choose **User defined**. In the $f_{\rm Dl}$ text field, type epsl_sep^brugl_sep.

Porous Electrode I

- I In the Physics toolbar, click Domains and choose Porous Electrode.
- 2 In the Settings window for Porous Electrode, locate the Domain Selection section.
- 3 From the Selection list, choose Negative Electrode.
- **4** Locate the **Electrode Properties** section. In the σ_s text field, type sigmas_neg.
- 5 Locate the Porous Matrix Properties section. In the ϵ_s text field, type epss_neg.
- **6** In the ε_1 text field, type epsl_neg.

Particle Intercalation 1

- I In the Model Builder window, click Particle Intercalation I.
- 2 In the Settings window for Particle Intercalation, locate the Material section.
- 3 From the Particle material list, choose Graphite, LixC6 MCMB (Negative, Liion Battery) (mat2).
- **4** Locate the **Particle Transport Properties** section. In the $r_{\rm p}$ text field, type rp_neg.
- **5** Click to expand the **Particle Discretization** section. In the $N_{\rm el}$ text field, type 5.
- 6 Select the Fast assembly in particle dimension check box.

Porous Electrode Reaction I

- I In the Model Builder window, click Porous Electrode Reaction 1.
- 2 In the Settings window for Porous Electrode Reaction, locate the Material section.
- 3 From the Material list, choose Graphite, LixC6 MCMB (Negative, Li-ion Battery) (mat2).
- **4** Locate the **Electrode Kinetics** section. In the $i_{0,ref}(T)$ text field, type ioref_neg.

Porous Electrode 2

- I In the Physics toolbar, click **Domains** and choose **Porous Electrode**.
- 2 In the Settings window for Porous Electrode, locate the Domain Selection section.
- **3** From the **Selection** list, choose **Positive Electrode**.
- **4** Locate the **Electrode Properties** section. In the σ_s text field, type sigmas_pos.
- **5** Locate the **Porous Matrix Properties** section. In the ε_s text field, type epss_pos.
- **6** In the ε_l text field, type epsl_pos.

- 7 Locate the Effective Transport Parameter Correction section. From the Electrolyte conductivity list, choose User defined. In the f_1 text field, type liion.epsl^brugl pos.
- **8** From the **Diffusion** list, choose **User defined**. In the $f_{\rm Dl}$ text field, type liion.epsl^brugl_pos.

Particle Intercalation 1

- I In the Model Builder window, click Particle Intercalation I.
- 2 In the Settings window for Particle Intercalation, locate the Material section.
- 3 From the Particle material list, choose NCA, LiNi0.8Co0.15Al0.0502 (Positive, Liion Battery) (mat3).
- **4** Locate the **Particle Transport Properties** section. In the r_p text field, type rp_pos .
- 5 Locate the Particle Discretization section. In the $N_{
 m el}$ text field, type 3.
- 6 Select the Fast assembly in particle dimension check box.

Porous Electrode Reaction I

- I In the Model Builder window, click Porous Electrode Reaction 1.
- 2 In the Settings window for Porous Electrode Reaction, locate the Material section.
- 3 From the Material list, choose NCA, LiNi0.8Co0.15Al0.0502 (Positive, Liion Battery) (mat3).
- **4** Locate the **Electrode Kinetics** section. In the $i_{0,ref}(T)$ text field, type ioref_pos.

Electric Ground 1

- I In the Physics toolbar, click Boundaries and choose Electric Ground.
- 2 Select Boundary 1 only.

GLOBAL DEFINITIONS

Default Model Inputs

Set up the temperature value used in the entire model.

- I In the Model Builder window, under Global Definitions click Default Model Inputs.
- 2 In the Settings window for Default Model Inputs, locate the Browse Model Inputs section.
- 3 In the tree, select General>Temperature (K) minput.T.
- **4** Find the **Expression for remaining selection** subsection. In the **Temperature** text field, type T.

DEFINITIONS (COMPI)

Piecewise I (pw I)

- I In the Home toolbar, click f(X) Functions and choose Global>Piecewise.
- 2 In the Settings window for Piecewise, type K in the Function name text field.
- 3 Locate the **Definition** section. From the **Smoothing** list, choose **Continuous function**.
- 4 Find the Intervals subsection. Click **Load from File**.
- **5** Browse to the model's Application Libraries folder and double-click the file capacity_fade_piecewise.txt.
- 6 Click Plot.

Variables 1

- I In the Model Builder window, right-click Definitions and choose Variables.
- 2 In the Settings window for Variables, locate the Variables section.
- 3 Click Load from File.
- **4** Browse to the model's Application Libraries folder and double-click the file capacity_fade_variables.txt.

STUDY I

Step 2: Time Dependent

- I In the Model Builder window, under Study I click Step 2: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Study Settings section.
- 3 In the Output times text field, type range(0,180, (no cycles+1)*t cycling/ t factor).