

# Heterogeneous NMC Electrode

In this example, time-dependent discharge and electrochemical impedance spectroscopy (EIS) simulations are made on a heterogeneous NMC (Nickel-Manganese-Cobalt) electrode structure.

A solid mechanics simulation is also made to study the effect of electrode expansion/ contraction on the particle and binder stresses.

# Model Definition

The model geometry is heterogeneous with regards to the electrode particles. However, since carbon filler, binder, and electrolyte are treated as a single porous conductive binder domain following a partly homogenized approach as described in Ref. 1.

Figure 1 shows the model geometry which is generated from tomography data (Ref. 2) using a Model Method. The geometry consists of one separator domain, one domain representing the porous conductive binder, and number of particle domains. How the geometry is created is documented in the Heterogeneous Electrode Geometry Generation tutorial.




Figure 1: Model geometry.

#### BATTERY MODEL

The Lithium-Ion Battery interface is used to define the electrolyte mass and charge transport, as well as the charge transport of the electrode phase, using the Battery Material Library materials NMC 111, LiNi0.33Mn0.33Co0.3302, Lithium Metal, Li, and LiPF6 in 3:7 **EC:EMC** to define the electrode and electrolyte properties, respectively.

The Transport of Diluted Species interface is used to define the diffusion of intercalated lithium within the electrode particles.

The electrochemically active electrolyte-electrode interfaces at the particle surfaces and the negative lithium foil electrode are defined using the Electrode Surface nodes in the Lithium-Ion Battery interface, using **Electrode Reaction** child-nodes to define the electrode kinetics. The surface intercalation flux of lithium at the particle surfaces are coupled to the electrochemical reactions using an **Electrode Surface Coupling** node in the Transport of Diluted Species interface.

The Electrode Surface boundary of the lithium metal electrode is grounded, whereas an **Electrode Current** boundary condition is used to set the total battery current on the current collector boundary of the NMC electrode.

The battery model is first used in a time-dependent study to perform a 2C discharge simulation from fully charged conditions.

In a second study, an EIS simulation is performed using an AC Impedance, Initial Values study at a 50% lithiation level of the NMC electrode.

#### SOLID MECHANICS MODEL

The local concentration of intercalated lithium in the particles is solved for during the discharge simulation. As the concentration levels in the particles change, the particles will either expand or contract. By coupling the strain of the particles to the local concentration levels, a stress-strain analysis of the binder and particles can be performed.

The **Solid Mechanics** interface is used to perform the stress-strain analysis, using separate Linear Elastic Material domain nodes for the separator, porous conductive binder and particle domains.

An Interpolation function is used to define the relation between strain and the intercalated lithium concentration of the NMC particles, as shown in Figure 2. This function is then

used to define the strain in the particles using an Intercalation Strain subnode to a Linear Elastic Material.




Figure 2: Strain versus intercalation level for NMC. The data was taken from Ref. 3.





Figure 3 shows the cell voltage during the 2C discharge.

Figure 3: Cell voltage during the 2C discharge.

Figure 4 shows the concentration of intercalated lithium in the particles, as well as the flux and concentration of lithium ions in the electrolyte halfway into the 2C discharge. During discharge, lithium dissolves in an anodic reaction at the lithium metal foil and is subsequently transported as ions toward the NMC particles. At the surface of the NMC materials, cathodic charge transfer occurs, and the formed lithium atoms intercalate and diffuse toward the interior of the particles.






Figure 4: Concentration of intercalated lithium in the particles, and lithium-ion flux streamlines, halfway into the 2C discharge. The color expression of the flux streamlines depict the lithium-ion concentration in the electrolyte.

Figure 5 shows the Nyquist plot from the EIS simulation. The half-circle stems from the charge transfer reaction at the NMC particles, whereas the approx 45° tail is related to the diffusion of intercalated lithium in the particles.




Figure 5: Nyquist plot of the impedance with respect to ground at the NMC current collector.

Figure 6 and Figure 7 show the stresses in the particles and porous conductive binder, respectively, halfway into the 2C discharge.




Figure 6: Particle stress halfway into the 2C discharge.




Figure 7: Binder stress halfway into the 2C discharge.

# References

- 1. A. Schmidt, E. Ramani, T. Carraro, J. Joos, A. Weber, M. Kamlah, and E. Ivers-Tiffée, "Understanding Deviations between Spatially Resolved and Homogenized Cathode Models of Lithium-Ion Batteries", *Energy Technol.* 2021, 2000881
- 2. M.Ebner, F. Geldmacher, F. Marone, M. Stampanoni, and V. Wood, "X-Ray Tomography of Porous, Transition Metal Oxide Based Lithium Ion Battery Electrodes," *Adv. Energy Mater.*, vol. 3, pp. 845–850, 2013. See also supporting information at https://onlinelibrary.wiley.com/doi/abs/10.1002/aenm.201200932
- 3. R. Koerver and others, "Chemo-mechanical expansion of lithium electrode materials on the route to mechanically optimized all-solid-state batteries," *Energy Environ. Sci.*, vol. 11, pp. 2142–2158, 2018.

**Application Library path:** Battery\_Design\_Module/Batteries,\_Heterogeneous/nmc\_electrode\_heterogeneous

#### ROOT


Start by opening the file containing the heterogeneous electrode geometry.

#### APPLICATION LIBRARIES

- I From the File menu, choose Application Libraries.
- 2 In the Application Libraries window, select Battery Design Module>Batteries, **Heterogeneous>nmc\_electrode\_geometry** in the tree.
- 3 Click Open.

#### **GEOMETRY I**

- I In the Model Builder window, expand the Component I (compl) node.
- 2 Right-click Component I (compl)>Geometry I and choose Build All.



- 3 Click the Wireframe Rendering button in the Graphics toolbar.
- 4 Click the **Zoom Extents** button in the **Graphics** toolbar.

# COMPONENT I (COMPI)

For setting up the physics, use the Lithium-Ion Battery interface and the Transport of Diluted **Species** interfaces.

#### ADD PHYSICS

- I In the Home toolbar, click open the Add Physics window.
- 2 Go to the Add Physics window.
- 3 In the tree, select Electrochemistry>Batteries>Lithium-Ion Battery (liion).
- 4 Click Add to Component I in the window toolbar.
- 5 In the tree, select Chemical Species Transport>Transport of Diluted Species (tds).

- 6 Click Add to Component I in the window toolbar.
- 7 In the Home toolbar, click 🎇 Add Physics to close the Add Physics window.

#### **GLOBAL DEFINITIONS**

Add the electrode parameters from a text file.

#### Electrode Parameters

- I In the Home toolbar, click Pi Parameters and choose Add>Parameters.
- 2 In the Settings window for Parameters, locate the Parameters section.
- 3 Click Load from File.
- 4 Browse to the model's Application Libraries folder and double-click the file nmc electrode parameters.txt.
- 5 In the Label text field, type Electrode Parameters.

### MATERIALS

Add the materials for the electrodes and electrolyte from the material library.

#### ADD MATERIAL

- I In the Home toolbar, click **Add Material** to open the Add Material window.
- 2 Go to the Add Material window.
- 3 In the tree, select Battery>Electrodes>Lithium Metal, Li (Negative, Li-ion Battery).
- 4 Right-click and choose Add to Component I (compl).
- 5 In the tree, select Battery>Electrodes>NMC 111, LiNi0.33Mn0.33Co0.3302 (Positive, Liion Battery).
- 6 Right-click and choose Add to Component I (compl).
- 7 In the tree, select Battery>Electrolytes>LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery).
- 8 Right-click and choose Add to Component I (compl).
- 9 In the Home toolbar, click **Add Material** to close the Add Material window.

#### MATERIALS

Lithium Metal, Li (Negative, Li-ion Battery) (mat I)

- I In the Settings window for Material, locate the Geometric Entity Selection section.
- 2 From the Geometric entity level list, choose Boundary.
- 3 From the Selection list, choose Lithium Foil.

NMC 111, LiNi0.33Mn0.33Co0.33O2 (Positive, Li-ion Battery) (mat2)

- I In the Model Builder window, click NMC 111, LiNi0.33Mn0.33Co0.3302 (Positive, Liion Battery) (mat2).
- 2 In the Settings window for Material, locate the Geometric Entity Selection section.
- 3 From the Selection list, choose Particles.

LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery) (mat3)

- I In the Model Builder window, click LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery) (mat3).
- 2 In the Settings window for Material, locate the Geometric Entity Selection section.
- 3 From the Selection list, choose Separator + Binder.

# LITHIUM-ION BATTERY (LIION)

- I In the Model Builder window, under Component I (compl) click Lithium-Ion Battery (liion).
- 2 In the Settings window for Lithium-Ion Battery, locate the Domain Selection section.
- 3 From the Selection list, choose Separator + Binder.
- **4** Click to expand the **Discretization** section. Reduce the discretization to use linear elements for the battery interface. This will reduce the memory requirements for solving the model. Transport of Diluted species uses linear elements by default and needs not to be altered.
- 5 From the Electrolyte potential list, choose Linear.
- 6 From the Electrolyte salt concentration list, choose Linear.
- 7 From the Electric potential list, choose Linear.

# Separator I

- I In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click **Separator 1**.
- 2 In the Settings window for Separator, locate the Electrolyte Properties section.
- 3 From the Electrolyte material list, choose LiPF6 in 3:7 EC:EMC (Liquid, Liion Battery) (mat3).

#### Porous Conductive Binder I

- I In the Physics toolbar, click **Domains** and choose Porous Conductive Binder.
- 2 In the Settings window for Porous Conductive Binder, locate the Domain Selection section.
- 3 From the Selection list, choose Porous Conductive Binder.

- 4 Locate the Electrolyte Properties section. From the Electrolyte material list, choose LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery) (mat3).
- **5** Locate the **Conductive Binder Properties** section. In the  $\sigma_s$  text field, type sigma\_s.
- **6** Locate the **Porous Matrix Properties** section. In the  $\varepsilon_s$  text field, type eps\_s\_b.
- **7** In the  $\varepsilon_1$  text field, type eps\_1\_b.
- 8 Locate the Effective Transport Parameter Correction section. From the **Electrical conductivity** list, choose **No correction**.

Internal Electrode Surface I

Use the Internal Electrode Surface node to model the electrode-electrolyte interface between the particles and the porous conductive binder domain.

- I In the Physics toolbar, click **Boundaries** and choose Internal Electrode Surface.
- 2 In the Settings window for Internal Electrode Surface, locate the Boundary Selection section.
- 3 From the Selection list, choose Particle Surfaces.

#### Electrode Reaction 1

Set the model input concentration, which is used by the active Material to calculate the equilibrium potential, to the concentration variable c solved for by the Transport of Diluted **Species** interface.

- I In the Model Builder window, click Electrode Reaction I.
- 2 In the Settings window for Electrode Reaction, locate the Model Input section.
- 3 In the c text field, type c.
- 4 Locate the Material section. From the Material list, choose NMC 111, LiNi0.33Mn0.33Co0.3302 (Positive, Li-ion Battery) (mat2).
- 5 Locate the Electrode Kinetics section. From the Kinetics expression type list, choose Lithium insertion.
- **6** In the  $i_{0,ref}(T)$  text field, type i0\_ref\_NMC.

Electrode Surface I

Use an **Electrode Surface** node to model the external lithium foil electrode.

- I In the Physics toolbar, click **Boundaries** and choose **Electrode Surface**.
- 2 In the Settings window for Electrode Surface, locate the Boundary Selection section.
- 3 From the Selection list, choose Lithium Foil.

#### Electrode Reaction 1

- I In the Model Builder window, click Electrode Reaction I.
- 2 In the Settings window for Electrode Reaction, locate the Electrode Kinetics section.
- **3** In the  $i_{0,ref}(T)$  text field, type i0\_ref\_Li.

The Electrode Surface node is grounded by default. Use an Electrode Current node to define the cell current at the positive current collector boundary.

#### Electrode Current I

- I In the Physics toolbar, click **Boundaries** and choose **Electrode Current**.
- 2 In the Settings window for Electrode Current, locate the Boundary Selection section.
- **3** From the Selection list, choose NMC Current Collector.
- **4** Locate the **Electrode Current** section. In the  $I_{\rm s,total}$  text field, type -I\_1C\*C\_rate. Set the initial values for the electric potential, both on the boundary and in the domain.
- **5** In the  $\phi_{s,bnd,init}$  text field, type mat2.elpot.Eeq\_int1(cs0/csmax).

#### Initial Values 1

- I In the Model Builder window, click Initial Values I.
- 2 In the Settings window for Initial Values, locate the Initial Values section.
- 3 In the phis text field, type mat2.elpot.Eeg int1(cs0/csmax).

#### TRANSPORT OF DILUTED SPECIES (TDS)

Now define the diffusion of intercalated lithium in the particles.

- I In the Model Builder window, under Component I (compl) click Transport of Diluted Species (tds).
- 2 In the Settings window for Transport of Diluted Species, locate the Domain Selection section.
- 3 From the Selection list, choose Particles.
- **4** Locate the **Transport Mechanisms** section. Clear the **Convection** check box.

# Transport Properties 1

- I In the Model Builder window, under Component I (compl)> Transport of Diluted Species (tds) click Transport Properties 1.
- 2 In the Settings window for Transport Properties, locate the Diffusion section.
- 3 From the Material list, choose NMC 111, LiNi0.33Mn0.33Co0.3302 (Positive, Liion Battery) (mat2).
- **4** From the  $D_c$  list, choose **Basic** (def).

#### Initial Values 1

- I In the Model Builder window, click Initial Values I.
- 2 In the Settings window for Initial Values, locate the Initial Values section.
- 3 In the c text field, type cs0.

# Electrode Surface Coupling I

- I In the Physics toolbar, click **Boundaries** and choose **Electrode Surface Coupling**.
- 2 In the Settings window for Electrode Surface Coupling, locate the Boundary Selection section.
- 3 From the Selection list, choose Particle Surfaces.

#### Reaction Coefficients I

- I In the Model Builder window, expand the Electrode Surface Coupling I node, then click Reaction Coefficients 1.
- 2 In the Settings window for Reaction Coefficients, locate the Model Inputs section.
- 3 From the  $i_{loc}$  list, choose Local current density, Electrode Reaction I (liion/beil/erl).
- **4** Locate the **Stoichiometric Coefficients** section. In the  $v_c$  text field, type 1.

#### DEFINITIONS

# Global Variable Probe - E cell

Add a probe for the cell voltage. The probe variable value will be stored in a table for every time step taken by the time-dependent solver.

- I In the Definitions toolbar, click Probes and choose Global Variable Probe.
- 2 In the Settings window for Global Variable Probe, type Global Variable Probe E cell in the Label text field.
- 3 Locate the Expression section. In the Expression text field, type liion.phis0 ec1.
- **4** Select the **Description** check box. In the associated text field, type **Cell voltage**.


#### MESH I

- I In the Model Builder window, under Component I (compl) click Mesh I.
- 2 In the Settings window for Mesh, locate the Sequence Type section.
- **3** From the list, choose **User-controlled mesh**.

#### Size

- I In the Model Builder window, under Component I (compl)>Mesh I click Size.
- 2 In the Settings window for Size, click to expand the Element Size Parameters section.

- 3 In the Maximum element size text field, type hmax.
- 4 In the Minimum element size text field, type hmin.
- 5 Click III Build All.



#### ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select Preset Studies for Selected Physics Interfaces>Lithium-Ion Battery> Time Dependent with Initialization.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

### STUDY I - BATTERY DISCHARGE

- I In the Model Builder window, click Study I.
- 2 In the Settings window for Study, type Study 1 Battery Discharge in the Label text field.

# Step 1: Current Distribution Initialization

- I In the Model Builder window, under Study I Battery Discharge click Step 1: Current Distribution Initialization.
- 2 In the Settings window for Current Distribution Initialization, locate the Study Settings
- 3 From the Current distribution type list, choose Secondary.
- 4 Locate the Physics and Variables Selection section. In the table, clear the Solve for check box for Transport of Diluted Species (tds).

# Step 2: Time Dependent

- I In the Model Builder window, click Step 2: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Study Settings section.
- **3** From the **Time unit** list, choose **h**.
- 4 In the Output times text field, type 0 0.1/C\_rate 0.5/C\_rate 0.9/C\_rate.

Solution I (soll)

- Add a stop condition to define a cutoff voltage while discharging.
- 2 In the Model Builder window, expand the Solution I (soll) node.
- 3 Right-click Study I Battery Discharge>Solver Configurations>Solution I (soll)>Time-**Dependent Solver I** and choose **Stop Condition**.
- 4 In the Settings window for Stop Condition, locate the Stop Expressions section.
- 5 Click + Add.
- **6** In the table, enter the following settings:

Stop expression	Stop if	Active	Description
comp1.liion.phis0_ec 1<3[V]	True (>=I)	1	Stop expression 1

7 Locate the Output at Stop section. Clear the Add warning check box.

#### Step 2: Time Dependent

- I In the Model Builder window, under Study I Battery Discharge click Step 2: Time Dependent.
- 2 In the Settings window for Time Dependent, click to expand the Results While Solving section.
- 3 From the Probes list, choose Manual.

Solution I (soll)

Place the electrolyte concentration dependent variable in a separate segregated group. This will decrease the memory requirements of the solver.

- I In the Model Builder window, expand the Study I Battery Discharge> Solver Configurations>Solution I (soll)>Time-Dependent Solver I>Segregated I node.
- 2 Right-click Study I Battery Discharge>Solver Configurations>Solution I (soll)>Time-Dependent Solver I>Segregated I and choose Segregated Step.
- 3 In the Settings window for Segregated Step, locate the General section.

- 4 In the Variables list, select Electrolyte salt concentration (compl.cl).
- 5 Under Variables, click **Delete**.
- 6 In the Model Builder window, under Study I Battery Discharge>Solver Configurations> Solution I (soll)>Time-Dependent Solver I>Segregated I click Segregated Step 3.
- 7 In the Settings window for Segregated Step, locate the General section.
- 8 Under Variables, click + Add.
- 9 In the Add dialog box, select Electrolyte salt concentration (compl.cl) in the Variables list.
- IO Click OK.
- II In the Settings window for Segregated Step, locate the General section.
- 12 From the Linear solver list, choose Direct, concentrations (tds).
- 13 In the Model Builder window, click Study I Battery Discharge.
- 14 In the Settings window for Study, locate the Study Settings section.
- **15** Clear the **Generate default plots** check box.
- **16** In the **Study** toolbar, click **Compute**.

#### RESULTS

The probe plot is automatically generated as shown in (Figure 3).

# Discharge voltage

- I In the Model Builder window, under Results click Probe Plot Group I.
- 2 In the Settings window for ID Plot Group, type Discharge voltage in the Label text field.
- 3 In the Discharge voltage toolbar, click Plot.

Solid Lithium Concentration and Lithium Ion Flux

- I In the Home toolbar, click Add Plot Group and choose 3D Plot Group. Start plotting the concentration and the flux for the lithium ion in the heterogeneous electrode. (Figure 4).
- 2 In the Settings window for 3D Plot Group, type Solid Lithium Concentration and Lithium Ion Flux in the Label text field.
- 3 Locate the Data section. From the Time (h) list, choose 0.25.
- 4 Locate the Plot Settings section. Clear the Plot dataset edges check box.

#### Surface 1

I Right-click Solid Lithium Concentration and Lithium Ion Flux and choose Surface.

- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the Expression text field, type c.
- 4 Locate the Coloring and Style section. Click | Change Color Table.
- 5 In the Color Table dialog box, select Aurora Aurora Borealis in the tree.
- 6 Click OK.

#### Streamline 1

- In the Model Builder window, right-click Solid Lithium Concentration and Lithium Ion Flux and choose Streamline.
- 2 In the Settings window for Streamline, click Replace Expression in the upper-right corner of the Expression section. From the menu, choose Component I (compl)>Lithium-Ion Battery>liion.Nposx,...,liion.Nposz - Positive ion flux.
- 3 Locate the Streamline Positioning section. In the Number text field, type 25.
- 4 Locate the Selection section. From the Selection list, choose Lithium Foil.
- 5 Locate the Coloring and Style section. Find the Line style subsection. From the Type list, choose Tube.

# Color Expression 1

- I Right-click Streamline I and choose Color Expression.
- 2 In the Settings window for Color Expression, locate the Expression section.
- **3** In the **Expression** text field, type c1.
- 4 Click to expand the **Title** section. From the **Title type** list, choose **Automatic**.
- 5 Locate the Coloring and Style section. Click Change Color Table.
- 6 In the Color Table dialog box, select Aurora>JupiterAuroraBorealis in the tree.
- 7 Click OK.
- 8 In the Settings window for Color Expression, locate the Coloring and Style section.
- **9** From the Color table transformation list, choose Reverse.

#### Surface 2

- I In the Model Builder window, right-click Solid Lithium Concentration and Lithium Ion Flux and choose Surface.
- 2 In the Settings window for Surface, locate the Expression section.
- 3 In the Expression text field, type 1.
- 4 Click to expand the **Title** section. From the **Title type** list, choose **None**.
- 5 Locate the Coloring and Style section. From the Coloring list, choose Uniform.

6 From the Color list, choose Gray.

Selection I

- I Right-click Surface 2 and choose Selection.
- **2** Select Boundaries 1, 2, 16, 17, and 19 only.
- 4 Click the **Zoom Extents** button in the **Graphics** toolbar.

# LITHIUM-ION BATTERY (LIION)

Now start setting up the model for the EIS simulation.

Electrode Current I

Add a harmonic perturbation to perturb the current signal around the stationary value, which is zero current at open circuit in this case.

I In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click Electrode Current I.

Harmonic Perturbation I

- I In the Physics toolbar, click 🖳 Attributes and choose Harmonic Perturbation.
- 2 In the Settings window for Harmonic Perturbation, locate the Harmonic Perturbation section.
- **3** In the  $\Delta I_{\rm s,total}$  text field, type I\_1C/100. Add a double layer capacitance at the NMC surface.

Internal Electrode Surface 1

In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click Internal Electrode Surface I.

Double-Layer Capacitance I

- I In the Physics toolbar, click 🕞 Attributes and choose Double-Layer Capacitance.
- 2 In the Settings window for Double-Layer Capacitance, locate the Double-Layer Capacitance section.
- **3** In the  $C_{\rm dl}$  text field, type C\_dl\_NMC.
- **4** Locate the **Stoichiometric Coefficient** section. In the  $v_{Li+}$  text field, type -1.

# **GLOBAL DEFINITIONS**

Electrode Parameters

Modify the initial state of charge to 50% lithiation before setting up the EIS study.

- I In the Model Builder window, under Global Definitions click Electrode Parameters.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
socinit	socmin*0+0.5	0.5	Initial lithiation level, nmc (use 0.5 for EIS study, socmin for discharge)

#### ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select Empty Study.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

#### STUDY 2 - EIS

In the Settings window for Study, type Study 2 - EIS in the Label text field.

Step 1: Frequency-Domain Perturbation

- I In the Study toolbar, click Tstudy Steps and choose Frequency Domain>Frequency-**Domain Perturbation.**
- 2 In the Settings window for Frequency-Domain Perturbation, locate the Study Settings
- 3 In the Frequencies text field, type 10^range(-2.6,0.2,5).
- 4 Click to expand the Results While Solving section. From the Probes list, choose None.
- 5 In the Model Builder window, collapse the Study 2 EIS node.
- 6 In the Study toolbar, click **Compute**.

#### RESULTS

Impedance with Respect to Ground, Nyquist (liion)

- I In the Impedance with Respect to Ground, Nyquist (liion) toolbar, click **1** Plot.
- 2 Click the **Zoom Extents** button in the **Graphics** toolbar.

#### **GLOBAL DEFINITIONS**

#### Solid Mechanics Parameters

Now set up the stress-strain model in the particles using the **Solid Mechanics** interface. Start by importing the parameters for the solid mechanics model.

- I In the Home toolbar, click Pi Parameters and choose Add>Parameters.
- 2 In the Settings window for Parameters, type Solid Mechanics Parameters in the Label text field.
- 3 Locate the Parameters section. Click Load from File.
- 4 Browse to the model's Application Libraries folder and double-click the file nmc\_electrode\_solid\_mechanics\_parameters.txt.

#### ADD PHYSICS

- I In the Home toolbar, click Add Physics to open the Add Physics window.
- 2 Go to the Add Physics window.
- 3 In the tree, select Structural Mechanics>Solid Mechanics (solid).
- **4** Click **Add to Component I** in the window toolbar.
- 5 In the Home toolbar, click and Physics to close the Add Physics window.

# SOLID MECHANICS (SOLID)

Linear Elastic Material I

- I In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Linear Elastic Material I.
- 2 In the Settings window for Linear Elastic Material, locate the Linear Elastic Material section.
- **3** From the E list, choose **User defined**. In the associated text field, type E separator.
- 4 From the v list, choose **User defined**. In the associated text field, type nu separator.
- **5** From the  $\rho$  list, choose **User defined**. In the associated text field, type rho\_separator.

Linear Elastic Material - Binder

- In the Physics toolbar, click **Domains** and choose Linear Elastic Material.
- 2 In the Settings window for Linear Elastic Material, type Linear Elastic Material -Binder in the Label text field.
- 3 Locate the **Domain Selection** section. From the **Selection** list, choose Porous Conductive Binder.

- 4 Locate the Linear Elastic Material section. From the E list, choose User defined. In the associated text field, type E binder.
- 5 From the v list, choose **User defined**. In the associated text field, type nu binder.
- **6** From the ρ list, choose **User defined**. In the associated text field, type rho\_binder.

Linear Elastic Material 3

I In the Physics toolbar, click **Domains** and choose Linear Elastic Material.

The strain in the particles depends on the concentration of intercalated lithium. First inspect the volumetric strain vs the lithiation level function, defined in the NMC material.

#### MATERIALS

NMC 111, LiNi0.33Mn0.33Co0.33O2 (Positive, Li-ion Battery) (mat2)

In the Model Builder window, expand the NMC 111, LiNi0.33Mn0.33Co0.3302 (Positive, Liion Battery) (mat2) node.

Interpolation I (dVOLdSOL)

- I In the Model Builder window, expand the Component I (compl)>Materials>NMC III, LiNi0.33Mn0.33Co0.3302 (Positive, Li-ion Battery) (mat2)> Intercalation strain (IntercalationStrain) node, then click Interpolation I (dVOLdSOL).
- 2 In the Settings window for Interpolation, click Plot.

The function plot is shown in Figure 2.

# SOLID MECHANICS (SOLID)

Linear Elastic Material - Particles

- I In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Linear Elastic Material 3.
- 2 In the Settings window for Linear Elastic Material, type Linear Elastic Material -Particles in the Label text field.
- 3 Locate the **Domain Selection** section. From the **Selection** list, choose **Particles**.
- 4 Locate the Linear Elastic Material section. From the p list, choose User defined. In the associated text field, type rho NMC.

Intercalation Strain 1

I In the Physics toolbar, click 🖳 Attributes and choose Intercalation Strain.

The volumetric strain is taken From material by default. Couple the strain to the concentration solved for by the **Transport of Diluted Species** interface as follows:

- 2 In the Settings window for Intercalation Strain, locate the Model Input section.
- **3** From the c list, choose **Concentration (tds)**.

#### Roller I

- I In the Physics toolbar, click **Boundaries** and choose Roller.
- 2 In the Settings window for Roller, locate the Boundary Selection section.
- 3 From the Selection list, choose All External Boundaries.

#### ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies>Stationary.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

### STUDY 3 - SOLID MECHANICS

- I In the Model Builder window, click Study 3.
- 2 In the Settings window for Study, type Study 3 Solid Mechanics in the Label text field.
- 3 Locate the Study Settings section. Clear the Generate default plots check box.

#### Parametric Sweep

- In the Study toolbar, click Parametric Sweep.
- 2 In the Settings window for Parametric Sweep, locate the Study Settings section.
- 3 Click + Add.
- **4** In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
t_param (Time parameter for Solid Mechanics analysis (in hours))	0.1/C_rate 0.5/C_rate 0.9/C_rate	

5 Locate the Output While Solving section. From the Probes list, choose None.

# Stationary - Solid Mechanics

- I In the Model Builder window, click Step I: Stationary.
- 2 In the Settings window for Stationary, type Stationary Solid Mechanics in the Label text field.

- 3 Locate the Physics and Variables Selection section. In the table, clear the Solve for check boxes for Lithium-Ion Battery (liion) and Transport of Diluted Species (tds).
- 4 Click to expand the Values of Dependent Variables section. Find the Values of variables not solved for subsection. From the Settings list, choose User controlled.
- 5 From the Method list, choose Solution.
- 6 From the Study list, choose Study I Battery Discharge, Time Dependent.
- 7 From the Time (h) list, choose Interpolated.
- 8 In the Time text field, type t param.

# Solution 4 (sol4)

- I In the Study toolbar, click Show Default Solver.
- 2 In the Model Builder window, expand the Solution 4 (sol4) node. By enabling the iterative solver, the memory requirements are reduced.
- 3 In the Model Builder window, expand the Study 3 Solid Mechanics> Solver Configurations>Solution 4 (sol4)>Stationary Solver I node.
- 4 Right-click Study 3 Solid Mechanics>Solver Configurations>Solution 4 (sol4)> Stationary Solver I>Suggested Iterative Solver (solid) and choose Enable.
- 5 In the Study toolbar, click **Compute**.

# RESULTS

#### Stress, Particles

- I In the Home toolbar, click Add Plot Group and choose 3D Plot Group.
- 2 In the Settings window for 3D Plot Group, type Stress, Particles in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 3 Solid Mechanics/ Parametric Solutions I (sol5).
- 4 From the Parameter value (t\_param) list, choose 0.25.
- 5 Locate the Plot Settings section. Clear the Plot dataset edges check box.

#### Slice 1

- I Right-click Stress, Particles and choose Slice.
- 2 In the Settings window for Slice, locate the Expression section.
- 3 In the Expression text field, type solid.mises.
- 4 Locate the Plane Data section. From the Plane list, choose ZX-planes.

5 In the Planes text field, type 1.

#### Selection 1

- I Right-click Slice I and choose Selection.
- 2 In the Settings window for Selection, locate the Selection section.
- 3 From the Selection list, choose Particles.
- 4 In the Stress, Particles toolbar, click Plot.

In the Model Builder window, right-click Slice I and choose Duplicate.

#### Slice 2

- I In the Model Builder window, click Slice 2.
- 2 In the Settings window for Slice, locate the Plane Data section.
- 3 From the Plane list, choose YZ-planes.
- 4 In the Planes text field, type 1.
- 5 Click to expand the Inherit Style section. From the Plot list, choose Slice 1.
- 6 Click to expand the **Title** section. From the **Title type** list, choose **None**.
- 7 In the Stress, Particles toolbar, click Plot.
- 8 Click the **Zoom Extents** button in the **Graphics** toolbar.

This plot visualizes the stress in the particles. (Figure 6).

#### Stress, Particles

In the Model Builder window, right-click Stress, Particles and choose Duplicate.

#### Stress, Binder

- I In the Model Builder window, under Results click Stress, Particles I.
- 2 In the Settings window for 3D Plot Group, type Stress, Binder in the Label text field.

#### Slice 1

In the Model Builder window, expand the Stress, Binder node.

#### Selection 1

- I In the Model Builder window, expand the Slice I node, then click Selection I.
- 2 In the Settings window for Selection, locate the Selection section.
- 3 From the Selection list, choose Porous Conductive Binder.

# Selection I

- I In the Model Builder window, expand the Results>Stress, Binder>Slice 2 node, then click Selection 1.
- 2 In the Settings window for Selection, locate the Selection section.
- 3 From the Selection list, choose Porous Conductive Binder.
- 4 In the Stress, Binder toolbar, click Plot.
- 5 Click the **Zoom Extents** button in the **Graphics** toolbar. This plots visualizes the stress in the binder domain. (Figure 7).