Safety and first use

Aurora AK-200 smart kettle. Please read this manual before first use and keep it for later. The Aurora AK-200 is a household appliance and is not meant for commercial use.

Safety

- The maximum fill level is 1.7 litres. The minimum fill level is 0.5 litres, marked by the lower line inside the kettle.
- Never switch the kettle on without water. If it runs dry, the dry-boil protection switches it off and the display shows E1.
- Place the kettle on a flat, dry surface. Never immerse the power base in water.
- The kettle is rated 2200 W at 230 V.

First use

Before the first use, fill the kettle to the maximum level, boil the water and pour it away. Repeat this twice to rinse out any production residue.

Operation

Temperature presets

Press the preset button to cycle through the five temperature presets: 70 degrees for baby milk, 80 degrees for green tea, 90 degrees for coffee, 95 degrees for black tea and 100 degrees for boiling.

Keep-warm function

Press and hold the start button for 2 seconds to switch on the keep-warm function. The kettle holds the selected temperature for 30 minutes and then switches itself off.

Child lock

To lock the controls, hold the preset button for 3 seconds until the lock symbol lights up. Repeat to unlock. The lid is opened with the release button on the handle.

Care and troubleshooting

Descaling

Descale the kettle every 4 weeks, or sooner when the ring light blinks amber. Fill it with one part white vinegar and two parts water, bring it to the boil, let it stand for 15 minutes, then rinse it well twice.

Error codes

- E1: dry-boil protection has switched the kettle off. Let it cool and add water.
- E3: the temperature sensor has failed. Do not use the kettle and contact customer service.

Reset and warranty

To reset the kettle, unplug it from the mains for 30 seconds and plug it in again. The Aurora AK-200 has a warranty of 2 years from the date of purchase; the receipt is needed for a claim.

Specifications and disposal

Specifications

- Height 24 cm, weight 1.2 kg. The mains cable is 0.75 m long and can be stored in the base.
- The body is brushed stainless steel; the lid is made of BPA-free plastic.
- One litre of water reaches the boil in about 3 minutes.

Limescale filter

The spout has a removable limescale filter. Rinse it under the tap once a week. A spare filter can be ordered with the code AF-20.

Disposal

Do not throw the kettle away with household waste. Take it to a collection point for electrical and electronic equipment.