Americas

Atlanta - 678-957-9614 Austin - 512-257-3370 Boston - 774-760-0087 Chicago - 630-285-0071 Cleveland - 216-447-0464 Dallas - 972-818-7423 Detroit - 248-848-4000 Houston - 281-894-5983 Indianapolis - 317-773-8323 Los Angeles - 949-462-9523 New York - 631-435-6000 Phoenix - 480-792-7200 Santa Clara - 408-961-6444 Toronto - 905-673-0699

Europe

Austria - Wels - 43-7242-2244-39 Denmark - Copenhagen - 45-4450-2828 France - Paris - 33-1-69-53-63-20 Germany - Munich - 49-89-627-144-0 Italy - Milan - 39-0331-742611 Netherlands - Drunen - 31-416-690399 Spain - Madrid - 34-91-708-08-90 UK - Wokingham - 44-118-921-5869

Asia/Pacific

Australia - Sydney - 61-2-9868-6733 China - Beijing - 86-10-8569-2100

Asia/Pacific (Continued)

China - Chengdu - 86-28-8665-5511 China - Chongging - 86-23-8980-9588 China - Hangzhou - 86-571-2819-3187 China - Hong Kong SAR - 852-2943-5100 China - Nanjing- 86-25-8473-2460 China - Qingdao - 86-532-8502-7355 China - Shanghai - 86-21-5407-5533 China - Shenvang - 86-24-2334-2829 China - Shenzhen - 86-755-8864-2200 China - Wuhan - 86-27-5980-5300 China - Xiamen - 86-592-2388138 China - Xian - 86-29-8833-7252 China - Zhuhai - 86-756-3210040 India - Bangalore - 91-80-3090-4444 India - New Delhi - 91-11-4160-8631 India - Pune - 91-20-3019-1500 Japan - Osaka - 81-6-6152-7160 Japan - Tokyo - 81-3-6880-3770 Korea - Daegu - 82-53-744-4301 Korea - Seoul - 82-2-554-7200 Malaysia - Kuala Lumpur - 60-3-6201-9857 Malaysia - Penang - 60-4-227-8870 Philippines - Manila - 63-2-634-9065

Singapore - 65-6334-8870 Taiwan - Hsin Chu - 886-3-5778-366

Taiwan - Kaohsiung - 886-7-213-7840

Taiwan - Taipei - 886-2-2508-8600

Thailand - Bangkok - 66-2-694-1351



Microchip Technology Inc. • 2355 West Chandler Blvd. • Chandler, AZ 85224-6199

www.microchip.com

The Microchip name and logo, the Microchip logo, and MPLAB are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries. All other trademarks mentioned herein are property of their respective companies. © 2014, Microchip Technology Incorporated, Printed in the U.S.A. All Rights Reserved. 01/14



10/28/13

PIC32 Ethernet Starter Kit II Information Sheet

The PIC32 Ethernet Starter Kit II (DM320004-2) provides a low-cost method for the development and testing of Ethernet-based applications with PIC32 devices.

This evaluation kit includes the PIC32 Ethernet Starter Kit II Development Board, the LAN8740 PHY Daughter Board, an Ethernet patch cord, and two USB cables (Standard-A to Micro-B and a Standard-A to Mini-B).

The board features a Mini-B USB port for debugging, a Standard-A USB port for the embedded host, and a Micro-AB USB Host/Device/OTG port. The PHY daughter board features an RJ-45 Ethernet port for network connectivity.

Installing MPLAB® X IDE and MPLAB XC32 C/C++ Compiler

Before you use the PIC32 Ethernet Starter Kit II, it is important to install the Microchip MPLAB[®] X Integrated Development Environment (IDE) and the MPLAB XC32 C/C++ Compiler. Both the MPLAB X IDE and the MPLAB XC32 C/C++ Compiler are free (see the following note) and are available for download at http://www.microchip.com/MPLAB and http://www.microchip.com/compilers, respectively.

Note: Standard Evaluation (Free) – All optimization levels are enabled for 60 days, but then reverts to optimization level 1 only.

Running the Demonstration Code and More Information

For the free Microchip TCP/IP demonstration code and more information, please visit the PIC32 Ethernet Starter Kit II page at: http://www.microchip.com. From the Design menu, click **Development Tools**. Then, from the Starter Kits menu, click **Starter Kits**, and then click **PIC32 Ethernet Starter Kit II**. On this page, you will find several demonstrations and code examples that will run on the starter kit.

For information on running a demonstration, please read the accompanying ReadMe.txt file for the particular demonstration.