

- -Connect display ground to Raspberry Pi ground
- -Connect display VIN to Raspberry Pi 3.3 volt.
- -Connect display CS to Raspberry Pi CE0.
- -Connect display RST to Raspberry Pi GPIO 24.
- -Connect display DC to Raspberry Pi GPIO 23
- -Connect display CLK to Raspberry Pi SCLK
- -Connect display Data to Raspberry Pi MOSI