

Aurora Mesh Wi-Fi Router - Setup Guide

The Aurora Mesh Router supports Wi-Fi 6 and covers up to 2,000 square feet per unit. For larger homes, up to 5 Aurora units can be linked together in a mesh network for extended coverage.

To set up the router, connect it to your modem using the included Ethernet cable, plug in the power adapter, and wait for the status light to turn solid blue, which takes about 90 seconds. Then download the Aurora app to complete setup.

The default network name and password are printed on a sticker on the bottom of the router. We strongly recommend changing the default password during setup using the Aurora app under Network Settings > Wi-Fi Password.

Parental controls can be enabled per device under Family Profiles in the app, allowing you to pause internet access, set bedtime schedules, and block specific website categories.

If the internet connection drops frequently, try moving the router at least 2 feet away from other electronics, and check for firmware updates under Settings > About > Check for Updates. The router updates its firmware automatically by default.