

BrewMaster Pro Coffee Machine - Care and Use

The BrewMaster Pro heats water to a consistent 200 degrees Fahrenheit for optimal extraction and supports both ground coffee and compatible single-serve pods.

Before first use, run one full brew cycle with only water and no coffee to clean the internal lines. Repeat this cleaning cycle every 60 days, or the descale indicator light will turn on automatically based on usage.

To descale the machine, fill the water tank with a mixture of one part white vinegar to two parts water, run a full brew cycle, then run two additional cycles with clean water to rinse the lines completely.

The machine will automatically power off after 30 minutes of inactivity to save energy. Press the power button once to wake it; it will be ready to brew within 15 seconds.

Do not immerse the base unit in water. The water tank, drip tray, and pod holder are dishwasher safe on the top rack only. The warranty is void if unauthorized descaling solutions other than food-grade citric acid or white vinegar are used.