

FAULTGUARD AI USER MANUAL

GENERAL GUIDE

1. System Usage: Prepare 7-column CSV data.
2. Analysis Lab: Upload your data to receive instant AI verdict.
3. Metrics: Review model accuracy and confusion matrix at the metrics page.
4. Location: The distance is estimated on a fixed 5km transmission line model.