

Chain Link Installation Guide

Woven chain link fabric fencing — posts, tensioning and gates

DOCUMENT NO. KM-IG-002	CREW 2–3 persons	EST. SPEED 40–60 m/day
---------------------------	---------------------	---------------------------

1. System Components

Component	Specification
Fabric	Chain link 50 × 50 mm, wire 2.5–4.0 mm, HDG or HDG+PVC
Line posts	Tube Ø48–60 mm, spacing ≤ 3.0 m
Terminal / corner posts	Tube Ø60–89 mm, set in concrete
Tension wire	Ø4.0 mm, bottom + optional top
Barbed arms	Optional, 3-strand, 45° outward

2. Post Setting

1. 1 Mark line; terminal posts first, then line posts at ≤ 3.0 m centers, minus fabric stretch allowance.
2. 2 Excavate terminal holes 200 mm Ø × 900 deep (1.8 m fence); line holes 150 mm Ø × 600 deep. Backfill with C20/25 concrete, crowned above grade.
3. 3 Plumb and align; brace terminal posts until concrete cures (48 h).

3. Framework & Fabric

1. 4 Fit top rail through line post loops; sleeve-joint sections with 150 mm overlap.
2. 5 Bottom tension wire, tension bars at terminals: fabric woven bar, tie wire every 150 mm to rail, hog-rings to tension wire every 450 mm.
3. 6 Stretch fabric with come-along + spread bar until diamonds lock (no racking by hand), then fix far end.

4. Quality Acceptance

- Fabric tension: no visible sag between posts under 5 kg mid-span pull
- Post plumb: ≤ 5 mm/m; top rail continuous, joints staggered
- Ground follow: fabric 25–50 mm clearance; bury 100 mm where animals dig