

Gabion Assembly Instructions

Welded & woven gabion baskets — folding, lacing, filling

DOCUMENT NO. KM-IG-003	STANDARD BASKET 2 × 1 × 1 m	FILL ROCK 150–250 mm
---------------------------	--------------------------------	-------------------------

1. Unpack & Fold

1. 1. Unfold basket on flat ground; fold four sides up, check diaphragms are perpendicular.
2. 2. Lace edges with supplied lacing wire: spiral ties at **100 mm spacing**, double twist at each corner.
3. 3. Corner stiffeners: fit 4 edge bars per basket on baskets > 1 m high.

2. Placement

Set baskets on geotextile over a compacted leveling pad. Offset vertical joints between courses by one cell (running bond). Lace each new course to the course below — never stack dry.

3. Filling

- Rock: hard, angular, frost-resistant; D50 between mesh aperture × 1.5 and cell size × 0.67 (typ. 150–250 mm for 80 × 100 mesh).
- Place by hand at exposed faces for appearance; machine-fill interior, drop height ≤ 500 mm.
- Filling tolerance ± 50 mm of lid level; slightly overfill woven types to allow settlement.

4. Closing

Tuck lid edge wires under top selvedge, then lace at 100 mm spacing. Install internal cross-tie wires (every second cell, 2 per m² of wall face) before closing courses ≥ 1 m.

Structural gabion walls > 3 m high or subject to surcharge require engineered design — contact our technical desk for free calculation support.