## Pins Definition after flashing X4R to CPPM version firmware:

X4R	CH1	<b>→</b>	CPPM (CH1~CH8)
	CH2	<b>→</b>	CH9
	CH3	<b>→</b>	CH10
	CH4	<b>→</b>	CH11

## Pins Definition after flashing X4RSB to CPPM version firmware:

8				
X4RSB	CH1	<b>→</b>	CPPM (CH1~CH8)	
	CH2	<b>→</b>	CH9	
	CH3	<b>→</b>	CH10	
	SBUS	<b>→</b>	SBUS	