Fourier Series Laboratory II

Patrycja Nazim, Adrian Król, Kamil Chaj

1 Aim of the exercise

The purpose of exercise was to experimentally familiarize with the Fourier series - an operation that allows to represent any real periodic signal by the sum of sinusoidal signals. We measured the signals generated by the independent function generator with a vector spectrum analyzer.

2 What is Fourier Series

A Fourier series is an expansion of a periodic function f(x) in terms of an infinite sum of sines and cosines. Fourier series make use of the orthogonal relationships of the sine and cosine functions. The computation and study of Fourier series is known as harmonic analysis and is extremely useful to break up an arbitrary periodic function into a set of simple terms that can be plugged in, solved individually, and then recombined to obtain the solution to the original problem or an approximation to it to whatever accuracy is desired or practical

3 Course of measurements

During our measurements we skipped first part of exercise and measured all signals in configuration for second part (Fig. 1).




Figure 1: Measurements configuration

After connecting Function Generator, Spectrum Analyzer, Oscilloscope and board with RC filters according to above configuration (Fig. 1) we set Function Generator to Amplitude to $V_{pp} = 5$ V and Frequency 1 kHz. With everything set up we proceeded with exercise and recording output of Oscilloscope and Spectrum Analyzer for signals:

- Sin wave
- Square wave 50% duty cycle
- Square wave 25% duty cycle
- Triangle wave 50% symmetry ratio
- Triangle wave 40% symmetry ratio

For Square wave 50% duty cycle and Triangle wave 40% symmetry ratio we also recorded Response for both RC Circuits (Fig. 2)



Figure 2: Measured RC Circuits

4 Method for calculating Fourier Series coefficients

All calculations are made using Matlab with Signal Processing Toolbox, source code can be found in Appendix A

First step in our calculation is generating signals that we measured during exercise. Pure signals were obtained with built-in functions of Signal Processing Toolbox and Filtered signals were evaluated using NI Multisim SPICE software.

Next step is finding first 10 coefficients of Fourier series for a signal which we calculated by taking inner product of signal with basis vector. In our calculations we used $\sin nt$, $\cos nt$ and 1 as our basis vectors.

$$a_0 = \langle s(t), 1 \rangle \tag{1}$$

$$a_n = \langle s(t), \cos n\omega t \rangle \tag{2}$$

$$b_n = \langle s(t), \sin n\omega t \rangle \tag{3}$$

During exercise we recorded Fourier series of a signal in Amplitude-Phase form so we need to convert a_n and b_n coefficients into amplitude A_n and phase φ_n

$$A_n = \sqrt{a_n^2 + b_n^2} \tag{4}$$

$$\varphi_n = \arg(a_n - jb_n) \tag{5}$$




Figure 3: example plot

Knowing first 10 coefficients we can plot approximation of a signal using one of following formulas. Example of approximation of square wave is on the second plot in Figure 3.

$$s(t) \approx \frac{a_0}{2} + \sum_{n=1}^{10} (a_n \cos(n\omega t) + b_n \sin(n\omega t))$$
 (6)

$$s(t) \approx \frac{A_0}{2} + \sum_{n=1}^{10} (A_n \cos(n\omega t + \varphi_n)) \tag{7}$$

For third and fourth plot in Figure 3 we are calculating Discrete Fourier transform for 10 oscillations of a signal using Fast Fourier transform algorithm from Signal Processing Toolbox and then plotting magnitude and argument of FT both in decibel scale on vertical axis.

5 Comparison

We are going to be comparing calculated and measured signals, their Fourier series expansion and/or Fourier transform. During comparison we will determine if Harmonic analysis is useful in signal analysis and what benefits it brings.

* Yellow signal on oscilloscope is pure signal, Blue is filtered signal

5.1 Pure signals

Starting off with first signal, Sinus, we can see that A_n coefficient for 1 kHz is approximately equal to amplitude of a signal and rest of coefficients are very small almost negligible, phase coefficient φ_n at 1 kHz is approximately -90° therefore according to eq.(7) first element of Fourier series is just $A_1 \sin \omega t$ and the rest of elements are very small, negligible.




Figure 4: Sin wave

Now moving to more interesting signal than simple sin, square wave, we can see many more components of Fourier series that are not negligible. Starting with first element which is exactly the same as in sin signal we can deduce that square signal have similar shape to sinus and is mostly odd function, but looking further on the rest of coefficient we can see that all non-zero coefficient is shifted by -90°, so square signal is built entirely from sins therefore is completely odd.




Figure 5: Square wave 50% duty cycle

Third signal is also square wave but 25% duty cycle. Looking at the most significant coefficients we can see that it is shifted by -45° therefore the signal is neither odd or even, also when looking at both coefficient there is repeating pattern. Phase of a harmonic is changing in order to negate previous, more significant harmonic.




Figure 6: Square wave 25% duty cycle

Last of pure signals is triangle wave, the signal is very similar to pure sin wave even first element is exactly the same as in sin wave, but all the difference is in harmonics with significantly smaller amplitudes that are "fine tuning" the signal.




Figure 7: Triangle wave 50% symmetry ratio

5.2 RC filters

simple Low-pass and High pass filters can be build with just 2 simple electric components resistor and capacitor, the reason why it is possible is that capacitor is acting differently for low frequencies and high frequencies. From formula for impedance of capacitor $\mathbf{Z} = \frac{1}{j\omega L}$ we can see that if ω is approaching 0 impedance will go to infinity therefore we can treat if like open circuit, but when ω is approaching infinity impedance will go to 0 so capacitor will act like a wire.



Figure 8: RC filters

5.2.1 Low-pass filter

First signal that we filtered using low-pass filter and measured was square wave 50% duty cycle. Most noticeable thing in comparison of unfiltered and filtered signal is that amplitudes of harmonics with smaller frequency barely change when those with higher frequencies changed by several decibels




Figure 9: Low-pass filter response for Square wave 50% duty cycle




Figure 10: Low-pass filter response for Triangle wave 40% symmetry ratio

5.2.2 High-pass filter




Figure 11: Low-pass filter response for Square wave 50% duty cycle




Figure 12: Low-pass filter response for Square wave 50% duty cycle

6 Summary

A Source Code

GITHUB repository

% plot(t, tr)

```
lab2.m
clear all; close all; clc;
[Square50_integrator, Square50_differentiatior, Triangle40_integrator, Triangle40_differentiat
fs = 100000;
duration = 0.01;
N = fs * duration;
t = 0:1/fs:duration-1/fs;
f = 1000;
a = 2.119;
phi = 0;
a = 2.5;
phi = 0;
s = a * sin(2*pi*t*f + phi);
tr50 = a * sawtooth(2*pi*t*f + phi, 0.5);
tr40 = a * sawtooth(2*pi*t*f + phi, 0.4);
% tr50 = tr50(size(tr50, 2)/40:size(tr50, 2));
sq50 = a * square(2*pi*t*f + phi, 50);
sq25 = a * square(2*pi*t*f + phi, 25);
Final_Plots(s, 'Sin wave', 'sin');
Final_Plots(tr50, 'Triangle wave 50% symmetry ratio', 'tri50');
Final_Plots(tr40, 'Triangle wave 40% symmetry ratio', 'tri40');
Final_Plots(sq50, 'Square wave 50% duty cycle', 'sqr50');
Final_Plots(sq25, 'Square wave 25% duty cycle', 'sqr25');
Final_Plots(Square50_integrator,['Low-pass filter response for' newline 'Square wave 50% duty
Final_Plots(Square50_differentiatior,['High-pass filter response for' newline 'Square wave 50%
Final_Plots(Triangle40_integrator,['Low-pass filter response for' newline 'Triangle wave 40% s
Final_Plots(Triangle40_differentiatior,['High-pass filter response for' newline 'Triangle wave
close all;
%% converted to Final_Plot function
% figure(123);
% %sin
% subplot(4,3,1)
% plot(t,s)
% xlabel('Time (seconds)');
% xlim([0,0.002])
% ylabel('Amplitude (Volts)');
% ylim([-3,3])
% title('Time-domain sinus');
% %triangle with 50% duty cycle
% subplot(4,3,2)
```

```
% xlabel('Time (seconds)');
% xlim([0,0.002])
% ylabel('Amplitude (Volts)');
% ylim([-3,3])
% title('Time-domain triangle');
% %square with 50% duty cycle
% subplot(4,3,3)
% plot(t,sq)
% xlabel('Time (seconds)');
% xlim([0,0.002])
% ylabel('Amplitude (Volts)');
% ylim([-3,3])
% title('Time-domain square');
%
% %fft sin
% s_{fft} = fft(s);
% %fft triangle
% tr_{fft} = fft(tr);
% %fft square
% sq_{fft} = fft(sq);
%
% s_{oneSide} = s_{fft(1:N/2)};
% frequencies = fs * (0:N/2-1) / N;
% S_{magnitude} = abs(s_{oneSide}) / (N/2);
% S_phase = angle(s_oneSide) * 180/pi;
% tr_oneSide = tr_fft(1:N/2);
% Tr_magnitude = abs(tr_oneSide) / (N/2);
% Tr_phase = angle(tr_oneSide) * 180/pi;
% sq\_oneSide = sq\_fft(1:N/2);
% Sq_magnitude = abs(sq_oneSide) / (N/2);
% Sq_phase = angle(sq_oneSide) * 180/pi;
%
\% freq_of_interest = [1000, 2000, 3000, 4000, 5000, 6000, 7000, 8000, 9000, 10000, 11000];
% indices = zeros(size(freq_of_interest));
% for i = 1:length(freq_of_interest)
%
      [~, indices(i)] = min(abs(frequencies - freq_of_interest(i)));
% end
%
% subplot(4,3,4)
% plot(frequencies, db(S_magnitude));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylim([-40, 10]);
% ylabel('Magnitude');
% title('Frequency spectrum');
%
% subplot(4,3,5)
% plot(frequencies, db(Tr_magnitude));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
```

```
% ylabel('Magnitude');
% ylim([-40, 10]);
% title('Frequency spectrum');
%
% subplot(4,3,6)
% plot(frequencies, db(Sq_magnitude));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylabel('Magnitude');
% ylim([-20, 10]);
% title('Frequency spectrum');
%
% subplot (4,3,7)
% stem(frequencies(indices), S_magnitude(indices));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylabel('Magnitude');
% title('Frequency spectrum');
%
% subplot(4,3,8)
% stem(frequencies(indices), Tr_magnitude(indices));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylabel('Magnitude');
% title('Frequency spectrum');
%
% subplot (4,3,9)
% stem(frequencies(indices), Sq_magnitude(indices));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylabel('Magnitude');
% title('Frequency spectrum');
%
%
% subplot(4,3,10)
% stem(frequencies(indices), S_phase(indices));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylabel('Phase (deg)');
% ylim([-180, 180]);
% title('Phase spectrum');
%
% subplot(4,3,11)
% stem(frequencies(indices), Tr_phase(indices));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylabel('Phase (deg)');
% ylim([-200, 200]);
% title('Phase spectrum');
%
% subplot(4,3,12)
% stem(frequencies(indices), Sq_phase(indices));
```

```
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylabel('Phase (deg)');
% ylim([-200, 200]);
% title('Phase spectrum');
Final Plots.m
function [] = Final_Plots(f, name, filename)
frequency = 1000;
duration = 10/frequency;
N = size(f,2);
sampling_frequency = N/duration;
t = 0:1/sampling_frequency:duration-1/sampling_frequency;
fig = figure('Name', name);
fig.Position(3:4) = [300 500];
%% signal
subplot(4,1,1);
plot(t, f);
xlabel('Time (seconds)');
xlim([0,0.001])
ylabel('Amplitude (Volts)');
ylim([-max(f)-(max(f)*0.3),max(f)+(max(f)*0.3)])
title(join(['', name]));
grid on;
%% fourier series
X = t(1:size(t,2)/10);
% f_{short} = f(1:size(x,2));
L = 1/frequency;
dx = 2*L/(N/10-1);
x = -L:dx:L;
f_{short} = f(1:size(x,2));
subplot(4,1,2); hold on;
% plot(x, f_short, 'r*');
A0 = (1/L)*sum(f_short.*ones(size(x)))*dx;
fFS = A0/2;
for k=1:10
    A(k) = (1/L)*sum(f_short.*cos(pi*k*x*frequency))*dx;
    B(k) = (1/L)*sum(f_short.*sin(pi*k*x*frequency))*dx;
    fFS = fFS + A(k)*cos(k*pi*x*frequency) + B(k)*sin(k*pi*x*frequency);
    plot(X, fFS);
    pause(.05);
end
plot(X, fFS, 'LineWidth', 2);
hold off;
xlabel('Time (seconds)');
xlim([0,0.001])
ylabel('Amplitude (Volts)');
ylim([-max(f)-(max(f)*0.5),max(f)+(max(f)*0.5)])
title('Fourier series expansion');
grid on;
```

```
%% fft amplitude
% plot
f_fft = fft(f);
f_{oneSide} = f_{fft}(1:N/2);
frequencies = sampling_frequency * (0:N/2-1) / N;
f_magnitude = abs(f_oneSide) / (N/2);
f_phase = angle(f_oneSide) * 180/pi;
freq_of_interest = [1000, 2000, 3000, 4000, 5000, 6000, 7000, 8000, 9000, 10000, 11000];
indices = zeros(size(freq_of_interest));
for i = 1:length(freq_of_interest)
    [~, indices(i)] = min(abs(frequencies - freq_of_interest(i)));
end
% subplot(4,1,3)
% plot(frequencies, db(f_magnitude));
% xlabel('Frequency (Hz)');
% xlim([0, 11000]);
% ylim([-40, 10]);
% ylabel('Magnitude');
% title('Frequency spectrum');
%stem
subplot(4,1,3)
% stem(frequencies(indices), f_magnitude(indices), 'x'); hold on;
stem(frequencies(indices), 20*log10(f_magnitude(indices)/f_magnitude(11)), 'filled', 'LineStyl
xlabel('Frequency (Hz)');
xlim([0, 11000]);
ylabel('Magnitude (dB)');
ylim([-50,max(20*log10(f_magnitude(indices)/f_magnitude(11)))])
title('Frequency spectrum');
grid on;
%% fft phase
subplot(4,1,4)
stem(frequencies(indices), f_phase(indices), 'filled', 'LineStyle', '-');
xlabel('Frequency (Hz)');
xlim([0, 11000]);
ylabel('Phase (deg)');
ylim([-180, 180]);
title('Phase spectrum');
grid on;
%% saving img
print(join(['img/',filename]), '-depsc');
end
Import csv.m
function [Vout] = RC_circuit(frequency, N)
figure('Name', 'RC circuit');
Vpp = 5;
```

```
frequency = 1000;
T = 1/frequency;
R = 1.5e3;
C1 = 47e-4;
C2 = 10;
dt = T/(N-1);
t = 0:dt:T;
Vout = 0*t;
Vout(N/2+1:N) = Vout(N/2+1:N) + Vpp;
Vout(N/2+1:N) = Vout(N/2+1:N) + (-Vpp)*exp(-(1:N/2)/(R*C1));
Vout(1:N) = Vout(1:N) + (Vpp)*exp(-(1:N)/(R*C1));
Vout(1:N) = Vout(1:N) - Vpp/2;
plot(t, Vout);
pause(.1)
end
```