
Step 5

Initial OpenHAB configuration


Follow the steps below

1. Your OpenHAB server is running locally on your machine, so to open it use this URL "http://localhost:8080" and placed it in your favorite browser in my case, I use google chrome.

Opening it on the first time, it will ask you to create a user account. You go ahead and create one just make sure you take note of it.




Any name will work, in my case I just used "admin"



Next window will ask you your location details, you can skip and configure this later if you want.

and when you reach the below home this again confirmed that you have successfully configured your initial site configurations.

Congratulations!



This completes STEP 5 (Initial OpenHAB configuration)

Proceed to STEP 6 (KAMOTEQ enabled esp8266 NodeMCU Device Integration to OpenHAB)