
Step 6


KAMOTEQ enabled esp8266 NodeMCU Device Integration to OpenHAB

To add our newly flashed (kamoteq) esp8266 nodeMCU to the OpenHAB follow the below steps


Click Settings > (Add-ons) Bindings



Click Search on the far lower right side




Search and install HTTP Binding and JSONPATH







Then go back to the Settings again, and click Things




Click the Plus Sign (+) to add a new device (the button is on the far lower right side)




And click the HTTP binding



Then finally click HTTP URL Thing




The next page will show the configuration form for the new device




Put a proper Label for your device for later identification

For the Base URL, you got this from STEP 2 NO. 8

Example Base URL from STEP 2 no. 8



And for testing purposes, we will set the Refresh Time to 5 seconds



Once you have verified all information is correct you can go ahead and click Create Thing

To complete the new device

This completes STEP 6 (KAMOTEQ enabled esp8266 NodeMCU Device Integration to OpenHAB)

Proceed to STEP 7 (Add a new switch pin to OpenHAB)