INT 13 - Diskette BIOS Services

For more information see the following topics:

```
INT 13,0
INT 13,1
Get disk status
          Get disk status
INT 13,2 Read disk sectors
          Write disk sectors
          Verify disk sectors
          Format disk track
  Most disk BIOS calls use the following parameter scheme:
       AH = function request number
       AL = number of sectors (1-128 dec.)
       CH = cylinder number (0-1023 dec.)
       CL = sector number (1-17 dec.)
       DH = head number (0-15 dec.)
DL = drive number (0=A:, 1=2nd floppy, 80h=drive 0, 81h=drive 1)
DL = drive number (0=A:, 1=2nd floppy, 80h=C:, 81h=D:)
             Note that some programming references use (0-3) as the
             drive number which represents diskettes only.
       ES:BX = address of user buffer
  and return with:
   CF = 0 if successful
      = 1 if error
   AH = status of operation (see INT 13,STATUS)
   - INT 13 diskette read functions should be retried at least 3
     times to assure the disk motor has time to spin up to speed
   - registers DS, BX, CX and DX are preserved
```

- see <u>INT 13,STATUS</u>

1 of 1 01/24/2007 01:13 PM