

Caring for O.W. Lee Furniture & Fire Pits



Simple Tips to Keep Your New Pieces Beautiful for Years to Come

Congratulations on your new O.W. Lee outdoor furniture or fire pit! Every piece is thoughtfully designed and handcrafted to deliver lasting comfort, durability, and timeless style. With just a little routine care, your furniture will continue to look and perform beautifully season after season.

Below you'll find easy, practical care guidelines to help protect your investment.

Metal Frame & Fire Pit Maintenance

O.W. Lee metal furniture and fire pits are built to require minimal maintenance, but regular cleaning goes a long way.

Best practices:

- Keep metal frames clean and free of dirt buildup.
- Clean occasionally with mild soap and water using a soft cloth, sponge, or soft bristle brush.
- Never use power washers or harsh or abrasive cleaners.
- Never leave furniture or fire pits standing in water.
- For extended periods of non-use, consider covering or storing your furniture.
- In coastal or high-humidity areas, additional care may be required.

Touch-ups:

Small scratches, chips, or minor rust seepage/oxidation can occur over time, especially in ornate designs. These can be easily addressed with color-matched touch-up pens, available through your local retailer or the O.W. Lee factory website. Touch up promptly to help prevent corrosion.

Cushion, Sling & Padded Sling Care

O.W. Lee cushions and slings are made with premium outdoor fabrics--solution-dyed acrylic or 100% polypropylene--along with high-quality outdoor foam and fiber fills.

Protect & Repel (apply annually)

- Sunbrella® Restore - Fabric
- 303® Fabric Guard

Routine care:

- Clean regularly with mild soap and water using a sponge or soft scrub brush.
- Rinse thoroughly with a garden hose and allow to air dry.

Important do-nots:

- Never remove fabric from cushions.
- Never use gas or electric power washers.
- Never submerge cushions in water.
- Never machine wash or dry.

For stubborn stains, we recommend:

- Sunbrella® Clean - Fabric Cleaner
- Sunbrella® Extract - Stain Remover
- 303® Multi Surface Cleaner



Caring for O.W. Lee Furniture & Fire Pits (cont'd)



Porcelain & Dekton Table Tops & Hearth Tops

Everyday cleaning:

- Wipe with a damp cloth and plain water to remove dust or light dirt.
- Dry after cleaning to prevent water spots.

Deeper cleaning:

- Use all-purpose household cleaners or soapless detergents such as Spic and Span® or 409®.

For soap scum, hard water deposits, or mildew, use products recommended for porcelain or Dekton surfaces.

- Always follow the cleaner's instructions, rinse thoroughly, and wipe dry.

Porcelain tile's low water absorption makes it highly resistant to frost and outdoor conditions, but storing tops during extended periods of non-use is recommended when possible.



Transport & Moving Guidelines

- Use moving blankets to protect surfaces from scratches and chips
- Ensure adequate manpower when lifting heavy items.
- Touch up any scratches immediately using O.W. Lee touch-up pens or paint.
- Fire pits: Always remove and transport the burner pan separately

Replacement Parts & Accessories

Need replacement components? Touch-up paint, insert glides, glass, cushions, and replacement tops are available through your local O.W. Lee retailer or via O.W. Lee's online Parts Store.

With just a little routine care, your O.W. Lee furniture and fire pit will continue to deliver comfort, beauty, and performance for many years. If you ever have questions, your local retailer or the O.W. Lee team is always happy to help.

Recommended Products

Clean

- Sunbrella® Clean – Fabric Cleaner
- Sunbrella® Extract – Stain Remover
- 303® Multi Surface Cleaner

Protect & Repel

- Sunbrella® Restore – Fabric
- 303® Fabric Guard
- 303® Furniture Protectant – Frame

Touch Up

- O.W. Lee Touch Up Paint Pens and Spray



WE APPRECIATE YOUR REVIEWS! Leave a review on Google, Facebook, etc.

OWLEE.COM | (800) 776-9533 | SALES@OWLEE.COM | FOLLOW US @OWLEECASUAL