

4.8 MQTT Settings for Device

Users can get the MQTT settings of your device in this page.

MQTT settings for device	
Type	TCP
Host	47.104.81.55
Port	1883
Client Id	554332
Username	
Password	
Clean Session	YES
Qos	0
Keep Alive	60
Device Id	8765555
Subscribed Topic	MINI-02-04AA/8765555/app_to_device
Published Topic	MINI-02-04AA/8765555/device_to_app

4.9 Reboot Device

The “Reboot Device” button is used to send a reboot command to the device. After that, the gateway will reboot once.

4.10 Reset Device

The “Reset Device” button is used to send a reset command to the device. After that, the device will restore to factory settings, and the indicator will flash blue and green once.

You can also press and hold the reset button for 10 seconds to reset the gateway.

4.11 Remove Device

Select a gateway on the device list and touch the screen for three seconds to remove it. After removed, the device will disappear in the device list.