Ans: Forced Handoff I forced handoff is defined as a handoff which would normally occur but is prevented from happening, ar a handoff that should not occur but forced to happen. -> Controlling a hand off

The cell rite can assign a low handoff thrushin or all langing mobile writ in a roll langing mobile in a roll langing mobile or assign a high handoff thrushold buel to or tree required a handoff souther. The MTSO can control a handoff by making either a handoff earlier as later, after receiving: a handoff request from a cell site.

In this case, the cell site does not request a handoff but the MTSO finds that some cells are too congested while others are not. Then the MTSO can request cell sites to oreste early handoffs for those congested cells.

Mobile desisted Handoff (MAHO)

In mobile assisted handoff (MAHO), the receiver of the mobile has the ability of to monitors. The signal strength of neighbouring all during a call.

for example, the time slots in time division multiple access (TDMA) has a unique function ie single time slat is used for serving a call and the remaining time slots are used to monitor the stand strength of reighbowing cells. When the signal strength of mobile unit is weak it neguests mobile switching center to indicate about the handoff of reighbouring information about the forward and reverse setup channels of the neighbouring call. Thus, MAHO has the ability to choose the proper reighbouring all for a successful handoff.

Intersystem Glandoff of handoff in which the call initiated in one cellular system is transferred to another cellular system without any termination mean while the mobile enters the second cellular system, is referred as interesten handoff. However, the two cellular systems are controlled by two different MTSOs. The concept of intersystem

handoff is applied only by changing the enfluer and mobile.