Section 11 MOVING WORK PLATFORMS

11.1 Running Platforms

- (a) The running platform is not an elevator and shall not be used to haul other personnel or material. Any other use of a running platform shall be approved by your Superintendent/Manager. In the event that work done by another trade must be done on a running platform, it shall be done only with the permission of your Superintendent/ Manager. Any movement of a running platform shall be done by Elevator Company Personnel only.
- (b) Before hoisting or roping of a platform, the governor shall be installed and roped to the safety releasing arm and tested to ensure that the safety is operational.
- (c) Fall protection should always be utilized However, if a personal fall protection system is not utilized, the running platform shall be equipped with guardrails and toeboards. The front of the platform shall be equipped with removable guardrails until the front of the hoistway is completely enclosed.
- (d) When required the running platform shall be counterweighted for the weight of the car platform assembly and its expected load. Do not put all the counterweights in the frame and be sure they are secured.
- (e) Temporary run controls and cords shall be inspected daily. Damaged cord shall be destroyed and discarded.
- (f) Temporary run controls shall be three button control ("UP," "DOWN," "SAFETY") so that it takes activation of two buttons to run any direction, plus an emergency stop switch on a stand-alone circuit. Cords shall be fitted with strain relief and insulation shall be intact. All buttons shall function as intended.