- (o) When not in use, oxygen and acetylene cylinders shall be stored at least 20 ft (6.1 m) apart, or separated by a one-half-hour (30-minute) rated fire-resistive wall or partition at least 5 ft (1.5 m) high, and shall be secured to prevent tipping.
- (p) Empty cylinders shall be marked "MT."
- (q) Cylinders shall never be stored in gang boxes.

13.3 Soldering

- (a) Solder containing lead shall not be used.
- (b) Be careful of splatter.
- (c) Burns from hot solder are painful and may lead to infection. Treat all burns immediately.
- (d) Wear a face shield, especially if you are soldering overhead. See Section 3.2.
- (e) Keep shirt collar buttoned.
- (f) Wear a long sleeve shirt and button the cuffs.