WARNING for Air Compressor

Our Branded Air Compressor has operated based under recommended maintenance & inspection chart of our brand.

So please you should have to prefer to use only our recommended spare parts for follow-up machines.

Safety & best Life and its causes to prevent an accident & Liable under warranty as per our industrial rules & regulation.

MAINTENANCE AND INSPECTION CHART

Sr. No.	Maintenance Operation	Daily	Weekly	200 Hr. Monthly	500 Hr. – 2 Month	1000 Hr. – 6 Month	2500 Hr. – 1 Year
1	Air Receiver-Metal Testing						*
2	Pressure Gauge Calibration				*		
3	Drain condensate Manual	*					
4	Motor Bearings check and lubricate						*
5	Pipe & Fitting						
6	Piston & Cylinder					*	*
7	Piston ring						*
8	Compressor air leaks		*				
9	Compressor of cylinder cooling fins		*				
10	Cleaning of exterior side of in-tar cooler		*				
11	Operate safety valves manually		*				
12	Belt tension & Damage			*			
13	Looseness of bolts, Nut or Screws			*			
14	Abnormal vibration or sound	*					
15	carbon on delivery pipe, inter cooler & joints				*		*
16	carbon on valve set & cylinder air head					*	*
17	Check operating pressure of pressure switch			*			
18	Frame oil change every					*	
19	Drain Air Receiver	*					
20	Check Frame Oil Level		*				
21	Air intake Filter inspects and cleans		*				