II Shree Umiya Matay Namah II



Water Technology (Guj.) Pvt. Ltd

GSTIN 24AAECR3013M1ZJ

MUMBAI OFFICE: 116-D, Govt. Industrial Estate, Charkop, Kandiwali (West), Mumbai - 400067,

Maharashtra.

Cell : <u>+91 73595 95577</u> E-mail : <u>inquiry@rajwater.com</u>

info@rajwater.com

AHMEDABAD OFFICE :

B/9, Sumel-7, Business Park, Opp. Soni ni Chal,

BRTS Bus Stop, N.H.-8 Ahmedabad - 382325.

Cell: <u>+91 70432 55777</u> E-mail: <u>inquiry@rajwater.com</u>

info@rajwater.com

HEAD OFFICE:

Plot No.: 27, Survey No. 47, Jivraj Industrial Area, Nr. Falcon Pump, Vavdi, Gondal Road, Rajkot - 360004.

Tel : +91 281 - 2922777 Telefax : +91 281 - 2922481

Cell : +91 74050 50444 / +91 70439 55777

Website: www.rajwater.com

Email: inquiry@rajwater.com / info@rajwater.com

RFC Machine Maintenance Details

- 1) Apply Grease to main Gear of the machine every month, which is in the machine connected with Gear Box.
- 2) Use Coconut oil for oiling of square block which is below the filling tank having an Up-Down motion in two rod.
- 3) Apply little bit grease to Rinsing case.
- 4) Oil the bushing which is in the capping unit and Grease to the Gear.
- 5) Oil every Gear shaft of the machine.