



SAUNA TURN-ON INSTRUCTIONS

1. To start (turn on) the sauna, perform the following steps:

- 1.1. Enter the four-digit code on the **electronic keypad (A)** and confirm by pressing #. Each code is for one-time use and **turns on the power** to the sauna for two hours. After this time, the sauna will turn off automatically. The indication that the sauna is working (turned on) is the glowing LEDs inside the sauna. Two hours are optimal for heating up the sauna (which happens quite quickly) and completing the entire sauna cycle. Next, to **start the stove and heat up the sauna**, perform the actions described in section 1.2.

Depending on the case, you can obtain the required **code**:

- from the Property Manager, if they provide it at check-in and the use of the sauna is included in the price of your stay,
- from the Operator, if you did not receive it at check-in because the use of the sauna is not included in the price of your stay. For this purpose, you should call +48 502747177 and then transfer the required amount to the phone number provided above. The code will be generated remotely and sent to the phone of the guest booking the sauna.

1.2. Control panel operation (B):

- press the button (knob) once to turn on the control panel and to start or end the heating process,
- the number displayed in the center of the screen is the current temperature inside the sauna,
- the number displayed in the upper right corner of the screen indicates the set, i.e., desired (target) temperature in the sauna. To set and adjust the temperature, turn the knob. The maximum setting is 80°C (the temperature in the upper part of the sauna may then reach up to 100°C).

1.3. Turn on the **wall player (C)** (if you wish) to play music:

- relaxing music, specifically dedicated to the sauna, is pre-loaded into the player,
- set a volume level comfortable for everyone using the sauna.

1.4. While using the sauna, please follow the sauna rules.

