HeyStar App user manual

HeyStar face recognition App user manual 1
1. Main interface 2
1.1 Main interface information introduction 2
1.2 password access 4
2.set up 6
2.1 set center 6
2.2 User Management 7
2.2.1 User List 7
2.2.2 Add new users 7
2.2.3 Face Registration 8
2.2.4 Fingerprint Registration 9
2.2.5 Palmvein Registration 11
2.2.6 User deletion 11
2.2.7 User Query 12
2.3 Communication Settings 13
2.4 Access control management 14
2.4.1 Access control group management 15
2.4.2 Time period management 17
2.5 Record query 20
2.6 Personality settings 20
2.7 Data Management 21
2.8 System Settings 21
2.8.1 Identification mode configuration 22
2.8.2 Identification configuration 23
2.8.3 Peripheral Settings 26
2.8.4 Display settings 27
2.8.4.1 Set Company Icon 28
2.8.5 Password setting 29
2.8.6 Upgrade settings 29
2.9 System information 29
2.9.1 Device information 30
2.9.2 System information 30

1. Main interface

1.1 Main interface information introduction

1. Person password：

When a person uses a password to verify attendance, enter the person ID and password here

2. App settings：

Default password： HFSecurity


3. Device information


3.1“Number of people”

3.2“Device IP”: Used to connect to background software


3.3”edition ”:Device app version ,00XA0_V1.01.0.2

3.4”SN”: Serial Number,Used to connect to background software






1. The middle part of the interface is the identification area. When someone enters this area, the device will identify the person and prompt the identification information and related information of the person.




1.2 password access

The user can use the [user ID] plus password to access, and the steps for the user to use the password to access are as follows:


① Add a new user in [User Management], fill in a six-digit password, and select [Face/Swipe Card/Fingerprint/Password] or [Password Only] as the verification method.



② The password button in the lower right corner of the main interface displays the user ID input interface, and enter the user ID filled in when adding a new user.




③ Click OK to display the password input interface, and enter the password you filled in when adding.



2.set up

2.1 set center


Click the setting button in the upper right corner of the main interface to display the password login interface. The default password is 123456. After entering the correct password, the setting center interface will be displayed. The setting center includes user management, communication settings, access control management, record query, personality settings, and data management. , System Settings, System Information.



2.2 User Management


2.2.1 User List

The user list displays the user's number, name, face, password, and fingerprint information.




2.2.2 Add new users

Click the plus sign on the upper right to display the new user interface. When adding a new user, you need to fill in the user ID, name, personnel type (internal employees, visitors, blacklist (forbidden)), password (six digits), card number, ID number, Face, fingerprint, access control group (added in Access Control Management->Access Control Group Management), verification method, passing time period (passing is allowed within the set time period, and prohibited outside the time period), all information needs to be clicked after filling in Click the save button in the upper right corner to save the user information successfully .



2.2.3 Face Registration


When adding a new user, click the face row to display the face registration interface. The user needs to move the face to the middle position to take a face photo. After the registration is successful, it will automatically return to the new user interface.



2.2.4 Fingerprint Registration

2.2.4.1 Fingerprint Registration

Before entering the fingerprint, you need to open the system settings-"recognition mode setting-"fingerprint recognition switch, click the fingerprint line, the fingerprint entry interface will be displayed, select the finger to be entered, and enter the user's fingerprint. The fingerprint of each finger of a user needs four confirmations , after the fingerprint is recorded, it will jump to the finger selection interface, click the arrow in the upper left corner to return to the user information interface and save the fingerprint.



,


2.2.4.2 Fingerprint deletion

Click the registered finger (the border is blue) to delete the fingerprint.




2.2.5 Palmvein Registration

Before inputting the palm vein, you need to open the system settings - "Identification Mode Settings" - the "Palmvein" switch,
then go back to the person registration interface, click "Palm Vein Number", and then you will enter the registration interface. Then, position your palm within the palm frame and follow the instructions provided to complete the registration.




2.2.6 User deletion

Click the red delete button next to the user in the user list to delete the user.




2.2.7 User Query

Click the query input box at the bottom of the user list interface, and enter the user ID or name to query the specified user.




2.3 Communication Settings

Device communication settings can set server connection configuration including connection method (LAN, cloud), connection protocol, server IP, server port, upload address of identification record, device heartbeat address, device heartbeat interval, data reporting address when registering personnel, fingerprint Data reporting address and other reporting switches.




Local area network choose HTTP and server IP
Cloud choose TCP、Password（custom）、Server IP、Server Port（default 10010）



2.4 Access control management


Access control management includes access control group management and time zone management, setting user access rights.



2.4.1 Access control group management


To manage the access control group, you can select the corresponding access control when creating a new user to control the user's access authority.

2.4.1.1 Access control group list




2.4.1.2 New access control group

Click the plus sign in the upper right corner to display the new access control group interface, enter the access control group ID, group name, verification method, time period (create a new one in time period management), and the time period selection cannot be repeated. Users who select this access control group can only The access control group can pass within the time period selected in the access control group. The default access control group can pass all day. After filling in the information, click the button in the upper right corner to save. A maximum of 50 access control groups can be added.



2.4.1.3 Delete access control group


Click the red button in the access control list to delete the access control group.



2.4.2 Time period management


Set the user's access time period, which can be selected in the user addition or access control group to control the user's access authority. The user can pass during the time period, and the user is not allowed to pass during the non-time period. The default time period is selected as the whole day. .

2.4.2.1 List of time periods




2.4.2.2 New time period

Click the plus sign in the upper right corner of the time zone list to display the new time zone interface. You can choose the available time from Monday to Sunday. The default is 00:00-23:59 all day.




2.4.2.3 Delete time period


Click the red button in the access control group list to delete the time zone.



2.4.3 Holiday management

If holiday management is configured, the personnel can be identified only within the specified time range






2.5 Record query

Check the user's pass record information, including pass time, passer's name, verification method, identification status and other information. Click on the record to delete it.




2.6 Personality settings

Set custom parameters for the device.




2.7 Data Management

To delete various data of the device, click the red button to delete, please operate with caution .




2.8 System Settings

Including recognition mode settings, recognition settings, peripheral settings, display settings, password settings, upgrade settings.



2.8.1 Identification mode configuration

- Face swiping mode switch: Face detection will be performed after it is turned on.
- Card swiping mode switch: After it is turned on, the card number detection will be performed.
  - Transmission interface: the interface of the card swiping device
  - X05 choose interface_ NFC
- Fingerprint identification switch: fingerprint detection will be performed after it is turned on.
- PalmVein switch: PalmVein detection will be performed after it is turned on.




2.8.2 Identification configuration

- Portrait recognition threshold (1vN): A score for the comparison between the live face and the bottom library photo (can be set from 0-100), the higher the score, the higher the accuracy (it is recommended to set around 65).
- Portrait recognition threshold (1v1): A score for the comparison between the live face and the base library photo (can be set from 0-100), the higher the score, the higher the accuracy (it is recommended to set around 65).
- Recognition Interval: The time interval for repeated recognition of the same face by the device (default 3 seconds, maximum 60 seconds).
- Recognition distance: The device detects and recognizes faces within the recognition distance range, and faces beyond the recognition distance will not be detected (it is recommended to set 0.5M for temperature measuring devices, and 1.5M for non-temperature measuring devices).

- Identification level:
  - level 1: Do not enable liveness recognition.
  - level 2: Enable monocular liveness recognition (default).
  - level 3: Enable binocular liveness recognition, and the recognition distance is up to 1.5 meters.
- Voice mode:
  - no voice
  - announce name
  - custom: use with custom
    - For custom content, only the {name} field is allowed, and the format of the {name} field is fixed. For other content, only numbers, English and Chinese characters are allowed, symbols are not allowed, and the length is limited to 255 characters. Such as: {name} welcome.
- display mode:
  - Name
  - do not display content
  - Custom: For use with custom displays
    - Display custom content. Only the {name} field is allowed. The format of the {name} field is fixed. Other content only allows numbers, Chinese and English, and Chinese and English symbols. The length is limited to 255 characters. Such as: {name}, sign in successfully!
- Stranger identification:
  - Open: Do not recognize strangers, that is, only registrants are recognized, and detected strangers (non-registered persons) will not be recognized
  - Close: Identify strangers
  - After opening, the stranger voice and stranger judgment configuration items will take effect.


- Stranger voice:
  - no voice
  - The broadcaster is not registered, please contact the administrator
  - Customization: Use with strangers' custom voice
    - Broadcast custom content, only numbers, English and Chinese characters are allowed, symbols are not allowed, and the length is limited to 255 characters. Such as: pay attention to strangers.
- Stranger identification:
  - Open: Do not recognize strangers, that is, only registrants are recognized, and detected strangers (non-registered persons) will not be recognized
  - Close: Identify strangers
  - After opening, the configuration items of stranger voice and stranger judgment will take effect
- Stranger voice:
  - On: Voice Announcement "Stranger Alert"
  - closure
  - Customization: Use with strangers' custom voice
    - Broadcast custom content, only numbers, English and Chinese characters are allowed, symbols are not allowed, and the length is limited to 255 characters. Such as: pay attention to strangers.
- Whitelist switch for witness comparison:
  - Closed: After the ID card is read, the process of face-to-face comparison is carried out directly.
  - Enable: Read the ID number and compare it with the ID numbers of all personnel in the database. If it exists, it will compare the ID number; if it does not exist, it will prompt that the authority is insufficient.
- Recognition record storage days: 7 days by default, up to 30 days.

- Save the snapshot switch, after it is turned off, the recognition record will not save the picture.
- Recognize strangers to open the door, and stranger recognition will also open the door after opening.




2.8.3 Peripheral Settings

Configure the peripheral settings of the device connection. If you need to configure, please contact the after-sales personnel.




2.8.4 Display settings

Set the information of the main interface, including the company name, whether to display the device IP, serial number, number of personnel information, and set the time to enter the screen saver.




2.8.4.1 Set Company Icon

In the "Display settings", click on the Company Icon, select the PNG image, and then save.
（The pictures must be placed in the internal folder path of the device. Do not use a USB drive to directly select and add them.Image suggestion:PNG Transparent format，Width x Height: 1700 x 500）
After the settings are completed, you can see the logo of the settings on the app's startup interface and in the upper left corner of the app's main interface.




2.8.5 Password setting

Set the login password when entering the settings center.




2.8.6 Upgrade settings

Turn off the online upgrade switch, after it is turned off, online upgrade cannot be performed.



2.9 System information

Including device information and system information




2.9.1 Device information

Contains the number of personnel, photos, fingerprints,Palm vein of the device.



2.9.2 System information

Various information of the display device system includes serial number, version number, channel number, system version, firmware version, face algorithm version, MAC address, IP, memory and storage space.


System Info
SN
020e70969d3097b266
App version
v10102
Channel Code
00XA0
System Version
11
Firmware Version
v1.1.0-20241119
Face Algorithm Version
V3.8.2
Ethernet MAC
02:00:00:00:00:00
WiFi MAC
a6:5d:86:0c:39:f5
IP
192.168.10.217