
Oscilloscope

Settings of the oscilloscope:

- 1.0V
- 0.1 ms/div.
- ±200 mV
- Sound Sensor (1 cm apart from Pinger)



Distance from Pinger	9 cm	11 cm	11.5 cm
Frequency	4.88 KC	3.39 KC	3.78 KC
Length of wave (L)	4.0 div.	4.1 div	4.0 div.
Width of wave (W)	2.2 div.	2 div.	1.7 div.

Pinger

