
# MEASUREMENT OF MASS FLOW RATE

#### DIFFERENTIAL PRESSURE DEVICES

#### Bernoulli's equation

$$\frac{P_1}{\rho} + \frac{V_1^2}{2} = \frac{P_2}{\rho} + \frac{V_2^2}{2} \Longrightarrow \frac{V_2^2}{2} - \frac{V_1^2}{2} = \frac{P_1}{\rho} - \frac{P_2}{\rho}$$



#### Continuity gives $A_1V_1 = A_2V_2$ as fluid is incompressible

$$V_{2}^{2}\left[1-\left(\frac{A_{2}}{A_{1}}\right)^{2}\right] = \frac{2(P_{1}-P_{2})}{\rho} \Rightarrow V_{2} = \sqrt{\frac{2(P_{1}-P_{2})}{\rho\left[1-\left(\frac{A_{2}}{A_{1}}\right)^{2}\right]}}$$

$$\dot{m} = \rho A_2 V_2 = \rho A_2 \frac{2(P_1 - P_2)}{\rho \left[1 - \left(\frac{A_2}{A_1}\right)^2\right]} = A_2 \sqrt{\frac{2\rho(P_1 - P_2)}{1 - \beta^4}}$$

$$\beta = \frac{d_2}{d_1}$$

#### **Differential Pressure Devices**


- Orifice Plate
- Nozzle
- Venturimeter

$$C_d = rac{\dot{m}_{actual}}{\dot{m}_{Theoretical}}$$


 $\dot{m}_{Theoretical} = A_2 \sqrt{\frac{2\rho(P_1 - P_2)}{1 - \beta^4}}$  Coefficient of discharge is less than one because of


separation losses and frictional losses

#### ORIFICE PLATE WITH D-D/2 TAPPINGS – BS 1042



#### **BS 1042**







(a) Orifice plate with corner tappings

(b) Orifice plate with D and D/2 tappings

D and D/2 tappings





rifice plate with flange tappings

Flange tappings

**Nozzle** 

#### **STOLZ EQUATION**

$$C_d = 0.5959 + 0.0312\beta^{2.1} - 0.184\beta^8 + 0.0029\beta^{2.5} \left(\frac{10^6}{Re_D}\right)^{0.73} + 0.09L_1\beta^4 (1-\beta^4)^{-1} - 0.0337L_2'\beta^3$$

#### Values of $L_1$ and $L_2'$

**Corner Tappings** 

$$L_1 = L_2' = 0$$

D - D/2 Tappings

$$L_1 = 1.0 \ L_2' = 0.47$$

**Flange Tappings** 

$$L_1 = L_2' = \frac{25.4}{D \text{ in mm}}$$


If  $L_1 \ge \frac{0.039}{0.09} = 0.4333$  use 0.039 for the coefficient of  $\beta^4 (1 - \beta^4)^{-1}$ 


#### **Conditions of validity**

	Corner taps	Flange taps	D and $D/2$ taps
$d \text{ (mm)}$ $D \text{ (mm)}$ $\beta$ $Re_D$	$d \ge 12.5$ $50 \le D \le 1000$ $0.23 \le \beta \le 0.80$ $5000 \le Re_D \le 10^8$ for $0.23 \le \beta \le 0.45$ $10\ 000 \le Re_D \le 10^8$ for $0.45 < \beta \le 0.77$ $20\ 000 \le Re_D \le 10^8$ for $0.77 \le \beta \le 0.80$	$d \ge 12.5$ $50 \le D \le 760$ $0.2 \le \beta \le 0.75$ $1260\beta^2 D^{\dagger} \le Re_D \le 10^8$	$d \ge 12.5$ $50 \le D \le 760$ $0.2 \le \beta \le 0.75$ $1260\beta^2 D^{\dagger} \le Re_D \le 10^8$


#### **VENTURIMETER - BS 1042**

Radius between zero and 1.8*D* 





#### DALL TUBE - BS 1042




# d and d/2 pressure taps Orifice plate Pipe flanges 25.4 mm (1 in.) Relative pressure differential $(\Delta p)_{\mathsf{loss}}$

## IRRECOVERABLE PRESSURE DROP FOR ORIFICE PLATE

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{\sqrt{1 - \beta^4 (1 - C_d^2)} - C_d \beta^2}{\sqrt{1 - \beta^4 (1 - C_d^2)} + C_d \beta^2}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = 1 - \beta^{1.9}$$


#### IRRECOVERABLE PRESSURE DROP FOR VENTURIMETER




# Throat pressure tap Upstream Pipe flanges pressure tap

#### IRRECOVERABLE PRESSURE DROP FOR NOZZLE

$$\frac{\Delta P_{Loss}}{\Delta P} = 1 + 0.014\beta - 2.06\beta^2 + 1.18\beta^3$$





#### IRRECOVERABLE PRESSURE DROP FOR DIFFERENTIAL PRESSURE DEVICES

Parameter/meter	Venturi	Nozzle	Dall tube	Orifice plate
Approximate value of C	0.99	0.96	0.66	0.60
Relative values of measured differential pressure $(\Delta P)_M$ Permanent $\Delta P$ as % of $(\Delta P)_M$	1.0	1.06	2.25	2.72
i.e. $\frac{(\Delta P)_P}{(\Delta P)_M} \times 100\%$	10-15%	40-60%	4-6%	50-70%

#### **Installation Requirements for Differential Pressure Devices**

- Fully Developed Flow is essential
- Minimum Pipe lengths are essential to achieve fully developed flow condition

TURN DOWN RATIO – RANGE DP transmitters are usually available over a range of 1:100. ∴ Turn Down Ratio of DP devices is around 10.

Consider water flowing at a flow rate of 10 kg/s through an orifice/venturi/nozzle whose  $\beta$  = 0.5 in a pipe of 100 mm. Calculate the pumping power required for each case and comment on the results

$$\beta = 0.5 D = 100 \text{ mm}$$
  $d = 50 \text{ mm}$   $\dot{m}_{actual} = 10 \text{ kg/s}$ 

$$\dot{m}_{actual} = C_d A_2 \sqrt{\frac{2\rho(P_1 - P_2)}{1 - \beta^4}} \quad 10 = 0.6 \frac{\pi}{4} (50 \times 10^{-3})^2 \sqrt{\frac{2 \times 1000 \Delta P}{1 - (0.5)^4}}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{\sqrt{1 - \beta^4 (1 - C_d^2)} - C_d \beta^2}{\sqrt{1 - \beta^4 (1 - C_d^2)} + C_d \beta^2} \qquad \frac{\Delta P_{Loss}}{\Delta P} = \frac{\sqrt{1 - 0.5^4 (1 - 0.6^2)} - 0.6(0.5)^2}{\sqrt{1 - 0.5^4 (1 - 0.6^2)} + 0.6(0.5)^2}$$

$$\frac{\Delta P_{Loss}}{33.774} = 0.7345 \qquad \Delta P_{Loss} = 24.81 \, kPa$$

$$\frac{\Delta P_{Loss}}{33.774} = 0.$$
 $\frac{ss}{2} = 0.732$ 

$$\frac{\Delta P_{Loss}}{\Delta P} = 1 - \beta^{1.9} = 1 - 0.5^{1.9} \qquad \frac{\Delta P_{Loss}}{\Delta P} = 0.732$$

$$P_{pump} = \frac{\dot{Q}\Delta P_{Loss}}{\eta_{pump}} = \frac{\dot{m}_{actual}\Delta P_{Loss}}{\rho\eta_{pump}} = \frac{10 \times 24.81 \times 1000}{1000 \times 0.7}$$

 $P_{pump} = 354.43 W$ 

 $\Delta P = 33.774 \, kPa$ 

#### Venturimeter

$$\dot{m}_{actual} = C_d A_2 \sqrt{\frac{2\rho(P_1 - P_2)}{1 - \beta^4}} \quad 10 = 0.99 \frac{\pi}{4} (50 \times 10^{-3})^2 \sqrt{\frac{2 \times 1000 \Delta P}{1 - (0.5)^4}} \quad \Delta P = 12.158 \, kPa$$

$$\Delta P_{Loss} = 1.8663 \, kPa$$

For 
$$7^{o}$$
,  $\frac{\Delta P_{Loss}}{\Delta P} = 0.436 - 0.86\beta + 0.59\beta^{2}$   $\frac{\Delta P_{Loss}}{12.158} = 0.436 - 0.86(0.5) + 0.59(0.5)^{2} = 0.1535$ 

$$P_{pump} = \frac{\dot{Q}\Delta P_{Loss}}{\eta_{pump}} = \frac{\dot{m}_{actual}\Delta P_{Loss}}{\rho\eta_{pump}} = \frac{10 \times 1.8663 \times 1000}{1000 \times 0.7}$$
 $P_{pump} = 26.6 W$ 

#### Nozzle

$$\dot{m}_{actual} = C_d A_2 \sqrt{\frac{2\rho(P_1 - P_2)}{1 - \beta^4}} \quad \mathbf{10} = 0.96 \frac{\pi}{4} \left(50 \times 10^{-3}\right)^2 \sqrt{\frac{2 \times 1000 \Delta P}{1 - (0.5)^4}} \quad \Delta P = 13.19 \ kPa$$


$$\Delta P_{Loss} = 8.44 \ kPa$$

$$\frac{\Delta P_{Loss}}{\Delta P} = 1 + 0.014\beta - 2.06\beta^2 + 1.18\beta^3 \frac{\Delta P_{Loss}}{13.19} = 1 + 0.014(0.5) - 2.06(0.5)^2 + 1.18(0.5)^3 = 0.6255$$

$$P_{pump} = \frac{\dot{Q}\Delta P_{Loss}}{\eta_{pump}} = \frac{\dot{m}_{actual}\Delta P_{Loss}}{\rho\eta_{pump}} = \frac{10 \times 8.44 \times 1000}{1000 \times 0.7}$$
 $P_{pump} = 120.53 W$ 

$$P_{pump} = 120.53 W$$

Item	$\dot{m}_{actual}$	$\Delta P$	$\Delta P_{Loss}$	$P_{pump}$
	kg/s	kPa	kPa	W
Orifice	10	33.774	24.81	354.43
Venturi	10	12.158	1.8663	26.66
Nozzle	10	13.19	8.4368	120.53



#### **IDEAL FLOW IN A NOZZLE**

#### Bernoulli's principle between 1 and 2

$$p_1 + \frac{\rho}{2}u^2 = p_2 + \frac{\rho}{2}u_2^2$$

$$p_1 - p_2 = \frac{\rho}{2}u_2^2 - \frac{\rho}{2}u^2$$

#### Momentum theorem between 2 and 3


$$p_2A_3 - p_3A_3 = (-\dot{m})u_2 + (+\dot{m})u$$

$$\dot{m} = \rho A_3 u$$

$$p_2A_3 - p_3A_3 = (-\rho A_3 u)u_2 + (\rho A_3 u)u$$

$$p_2 + \rho u u_2 = p_3 + \rho u^2$$

$$p_3 - p_2 = \rho u u_2 - \rho u^2$$



$$\Delta P_{Loss} = p_1 - p_3 \qquad \Delta P = p_1 - p_2$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{p_1 - p_3}{p_1 - p_2} = \frac{(p_1 - p_2) - (p_3 - p_2)}{p_1 - p_2}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{p_1 - p_3}{p_1 - p_2} = \frac{(p_1 - p_2) - (p_3 - p_2)}{p_1 - p_2} \qquad p_1 - p_2 = \frac{\rho}{2}u_2^2 - \frac{\rho}{2}u^2$$

$$p_1 - p_2 = \frac{\rho}{2}u_2^2 - \frac{\rho}{2}u^2$$

$$p_3 - p_2 = \rho u u_2 - \rho u^2$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{\left(\frac{\rho}{2}u_2^2 - \frac{\rho}{2}u^2\right) - \left(\rho u u_2 - \rho u^2\right)}{\frac{\rho}{2}u_2^2 - \frac{\rho}{2}u^2} = \frac{\frac{\rho}{2}u_2^2 + \frac{\rho}{2}u^2 - \rho u u_2}{\frac{\rho}{2}u_2^2 - \frac{\rho}{2}u^2} = \frac{\frac{\rho}{2}(u_2^2 + u^2 - 2u u_2)}{\frac{\rho}{2}(u_2^2 - u^2)}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{\left(u_2^2 + u^2 - 2uu_2\right)}{\left(u_2^2 - u^2\right)} = \frac{(u_2 - u)^2}{(u_2 - u)(u_2 + u)} = \frac{(u_2 - u)}{(u_2 + u)} = \frac{1 - \frac{u}{u_2}}{1 + \frac{u}{u_2}}$$

#### ITRACTION COEFFICIENT

$$\varphi = \frac{A_c}{A_2}$$

$$\varphi = \frac{A_c}{A_c}$$
  $A_c$  Area at the vena contracta

$$\frac{u}{u_2} = \frac{A_c}{A} = \frac{A_c}{A_2} \frac{A_2}{A} = \varphi \beta^2$$

$$\frac{u}{u_2} = \frac{A_c}{A} = \frac{A_c}{A_2} \frac{A_2}{A} = \varphi \beta^2$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{1 - \frac{u}{u_2}}{1 + \frac{u}{u_2}} = \frac{1 - \varphi \beta^2}{1 + \varphi \beta^2}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{1 - \varphi \beta^2}{1 + \varphi \beta^2}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{1 - \varphi \beta^2}{1 + \varphi \beta^2}$$

#### A relation for Contraction Coefficient ( $\varphi$ ) in terms of $C_d$ and $\beta$


$$\dot{m}_{actual} = C_d A_2 \sqrt{\frac{2\rho(P_1 - P_2)}{1 - \beta^4}} \quad \frac{A_2}{A} = \beta^2$$

$$\dot{m}_{actual} = \frac{C_d \beta^2 A}{\sqrt{1 - \beta^4}} \sqrt{2\rho(P_1 - P_2)}$$

$$\dot{Q}_{actual} = \frac{\dot{m}_{actual}}{\rho} = \frac{C_d \beta^2 A}{\sqrt{1 - \beta^4}} \sqrt{\frac{2\rho(P_1 - P_2)}{\rho^2}}$$

$$\dot{Q}_{actual} = \frac{C_d \beta^2 A}{\sqrt{1 - \beta^4}} \sqrt{\frac{2(P_1 - P_2)}{\rho}}$$

$$\dot{Q}_{theoretical} = \frac{1}{\sqrt{1 - \left(\frac{A_2}{A}\right)^2}} A_2 \sqrt{\frac{2(P_1 - P_2)}{\rho}} \quad \dot{Q}_{actual} = \frac{1}{\sqrt{1 - \left(\frac{A_c}{A}\right)^2}} A_c \sqrt{\frac{2(P_1 - P_2)}{\rho}}$$



$$\dot{Q}_{actual} = \frac{1}{\sqrt{1 - \left(\frac{A_c}{A}\right)^2}} A_c \sqrt{\frac{2(P_1 - P_2)}{\rho}}$$

$$\frac{A_c}{A} = \varphi \beta^2$$

$$\dot{Q}_{actual} = \frac{\varphi \beta^2}{\sqrt{1 - \varphi^2 \beta^4}} A \sqrt{\frac{2(P_1 - P_2)}{\rho}}$$

#### A relation for Contraction Coefficient ( $\varphi$ ) in terms of $C_d$ and $\beta$

$$\dot{Q}_{actual} = \frac{C_d \beta^2 A}{\sqrt{1 - \beta^4}} \sqrt{\frac{2(P_1 - P_2)}{\rho}}$$

$$\dot{Q}_{actual} = \frac{C_d \beta^2 A}{\sqrt{1 - \beta^4}} \sqrt{\frac{2(P_1 - P_2)}{\rho}} \qquad \dot{Q}_{actual} = \frac{\varphi \beta^2}{\sqrt{1 - \varphi^2 \beta^4}} A \sqrt{\frac{2(P_1 - P_2)}{\rho}}$$

$$\frac{C_d \beta^2 A}{\sqrt{1 - \beta^4}} \sqrt{\frac{2(P_1 - P_2)}{\rho}} = \frac{\varphi \beta^2}{\sqrt{1 - \varphi^2 \beta^4}} A \sqrt{\frac{2(P_1 - P_2)}{\rho}} \qquad \frac{C_d}{\sqrt{1 - \beta^4}} = \frac{\varphi}{\sqrt{1 - \varphi^2 \beta^4}}$$

$$\frac{C_d}{\sqrt{1-\beta^4}} = \frac{\varphi}{\sqrt{1-\varphi^2\beta^4}}$$

$$\frac{C_d^2}{1-\beta^4} = \frac{\varphi^2}{1-\varphi^2\beta^4} \quad \frac{C_d^2 - C_d^2 \varphi^2 \beta^4}{1-\varphi^2 \beta^4} \quad C_d^2 = \varphi^2 (1-\beta^4 + C_d^2 \beta^4)$$

$$C_d^2 - C_d^2 \varphi^2 \beta^4 = \varphi^2 - \varphi^2 \beta^4$$

$$C_d^2 = \varphi^2 (1 - \beta^4 + C_d^2 \beta^4)$$

$$\varphi^2 = \frac{C_d^2}{\left(1 - \beta^4 + C_d^2 \beta^4\right)}$$

Brandt proposed this relation for contraction coefficient

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{1 - \varphi \beta^2}{1 + \varphi \beta^2}$$

$$\boldsymbol{\varphi}^2 = \frac{\boldsymbol{C}_d^2}{\left(1 - \boldsymbol{\beta}^4 + \boldsymbol{C}_d^2 \boldsymbol{\beta}^4\right)}$$

$$\varphi = \frac{C_d}{\sqrt{1 - \beta^4 + C_d^2 \beta^4}}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{1 - \frac{C_d}{\sqrt{1 - \beta^4 + C_d^2 \beta^4}}}{1 + \frac{C_d}{\sqrt{1 - \beta^4 + C_d^2 \beta^4}}} \beta^2} = \frac{\sqrt{1 - \beta^4 + C_d^2 \beta^4} - C_d \beta^2}{\sqrt{1 - \beta^4 + C_d^2 \beta^4}}$$

$$\frac{\Delta P_{Loss}}{\Delta P} = \frac{\sqrt{1 - \beta^4 (1 - C_d^2) - C_d \beta^2}}{\sqrt{1 - \beta^4 (1 - C_d^2) + C_d \beta^2}}$$

#### MPRESSIBLE FLOWS

For ideal gas

$$PV^{\gamma} = K$$

$$\frac{PV^{\gamma} = K}{\rho^{\gamma}} = K \qquad \frac{P^{\frac{1}{\gamma}}}{P^{\frac{1}{\gamma}}} = K^{\frac{1}{\gamma}}$$

$$\int_{1}^{2} V dV + \int_{1}^{2} \frac{dP}{\rho} + \int_{1}^{2} g dz = 0 \quad \int_{1}^{2} V dV + \int_{1}^{2} \frac{dP}{\rho} = 0 \quad \int_{1}^{2} V dV = -\int_{1}^{2} \frac{dP}{\rho}$$

$$\int_{1}^{2} V dV + \int_{1}^{2} \frac{dP}{\rho} = 0$$

$$\int_{1}^{2} V dV = -\int_{1}^{2} \frac{dP}{\rho}$$

$$\int_{1}^{2} \frac{dP}{\rho} = K^{\frac{1}{\gamma}} \int_{1}^{2} \frac{dP}{P^{\frac{1}{\gamma}}} = K^{\frac{1}{\gamma}} \frac{P^{-\frac{1}{\gamma}+1}}{-\frac{1}{\gamma}+1} \bigg|_{1}^{2} = K^{\frac{1}{\gamma}} \frac{P^{\frac{\gamma-1}{\gamma}} - P^{\frac{\gamma-1}{\gamma}}_{1}}{\frac{\gamma-1}{\gamma}} \bigg|_{1}^{2}$$

$$\int_{1}^{2} V dV = -\int_{1}^{2} \frac{dP}{\rho}$$

$$\int_{1}^{2} V dV = -\int_{1}^{2} \frac{dP}{\rho} \frac{V_{2}^{2} - V_{1}^{2}}{2} = -K^{\frac{1}{\gamma}} \frac{P_{2}^{\frac{\gamma-1}{\gamma}} - P_{1}^{\frac{\gamma-1}{\gamma}}}{\frac{\gamma-1}{\gamma}} = K^{\frac{1}{\gamma}} \frac{P_{1}^{\frac{\gamma-1}{\gamma}} - P_{2}^{\frac{\gamma-1}{\gamma}}}{\frac{\gamma-1}{\gamma}} = \frac{\gamma}{\gamma-1} \frac{P_{1}^{\frac{1}{\gamma}}}{\rho_{1}} \left[ P_{1}^{\frac{\gamma-1}{\gamma}} - P_{2}^{\frac{\gamma-1}{\gamma}} \right]$$

$$\frac{V_{2}^{2} - V_{1}^{2}}{2} = -K_{1}^{\frac{1}{\gamma}} \frac{P_{2}^{\frac{\gamma-1}{\gamma}} - P_{1}^{\frac{\gamma-1}{\gamma}}}{\frac{\gamma-1}{\gamma}} = K_{1}^{\frac{\gamma-1}{\gamma}} \frac{P_{1}^{\frac{\gamma-1}{\gamma}} - P_{2}^{\frac{\gamma-1}{\gamma}}}{\frac{\gamma-1}{\gamma}} = \frac{\gamma}{\gamma-1} \frac{P_{1}^{\frac{1}{\gamma}}}{\rho_{1}} \left[ P_{1}^{\frac{\gamma-1}{\gamma}} - P_{2}^{\frac{\gamma-1}{\gamma}} \right]$$

$$\frac{V_2^2 - V_1^2}{2} = \frac{\gamma}{\gamma - 1} \frac{P_1^{\frac{1}{\gamma}}}{\rho_1} P_1^{\frac{\gamma - 1}{\gamma}} \left[ 1 - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma - 1}{\gamma}} \right] \qquad \frac{V_2^2 - V_1^2}{2} = \frac{\gamma}{\gamma - 1} \frac{P_1}{\rho_1} \left[ 1 - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma - 1}{\gamma}} \right]$$

$$\frac{V_2^2 - V_1^2}{2} = \frac{\gamma}{\gamma - 1} \frac{P_1}{\rho_1} \left[ 1 - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma - 1}{\gamma}} \right]$$

$$\rho_1 A_1 V_1 = \rho_2 A_2 V_2$$

$$V_1 = \frac{\rho_2}{\rho_1} \frac{A_2}{A_1} V_2$$

$$\rho_1 A_1 V_1 = \rho_2 A_2 V_2$$

$$V_1 = \frac{\rho_2}{\rho_1} \frac{A_2}{A_1} V_2$$

$$V_1 = \left(\frac{P_2}{P_1}\right)^{\frac{1}{\gamma}} \frac{A_2}{A_1} V_2$$

$$V_{2}^{2} - \left(\frac{P_{2}}{P_{1}}\right)^{\frac{2}{\gamma}} \left(\frac{A_{2}}{A_{1}}\right)^{2} V_{2}^{2} = \frac{2\gamma}{\gamma - 1} \frac{P_{1}}{\rho_{1}} \left[1 - \left(\frac{P_{2}}{P_{1}}\right)^{\frac{\gamma - 1}{\gamma}}\right]$$

$$V_{2} = \sqrt{\frac{\frac{2\gamma}{\gamma - 1} \frac{P_{1}}{\rho_{1}} \left[1 - \left(\frac{P_{2}}{P_{1}}\right)^{\frac{\gamma - 1}{\gamma}}\right]}{1 - \left(\frac{P_{2}}{P_{1}}\right)^{\frac{2}{\gamma}} \left(\frac{A_{2}}{A_{1}}\right)^{2}}}$$

$$V_{2} = \sqrt{\frac{\frac{2\gamma}{\gamma - 1} \frac{P_{1}}{\rho_{1}} \left[1 - \left(\frac{P_{2}}{P_{1}}\right)^{\frac{\gamma - 1}{\gamma}}\right]}{1 - \left(\frac{P_{2}}{P_{1}}\right)^{\frac{2}{\gamma}} \left(\frac{A_{2}}{A_{1}}\right)^{2}}}$$

$$\dot{m}_{th} = \rho_2 A_2 V_2 = A_2 \rho_1 \left( \frac{P_2}{P_1} \right)^{\frac{1}{\gamma}} \frac{2\gamma}{\gamma - 1} \frac{P_1}{\rho_1} \left[ 1 - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma - 1}{\gamma}} \right]}{1 - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma}{\gamma}} \left( \frac{A_2}{A_1} \right)^2}$$

$$\dot{m}_{th} = A_2 \sqrt{\frac{\frac{2\gamma}{\gamma - 1}\rho_1 P_1 \left[ \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma + 1}{\gamma}} \right]}{1 - \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} \left( \frac{A_2}{A_1} \right)^2}} \qquad P_1 = \frac{P_1}{P_1 - P_2} (P_1 - P_2) = (P_1 - P_2) \frac{1}{1 - \frac{P_2}{P_1}}$$

$$P_1 = \frac{P_1}{P_1 - P_2} (P_1 - P_2) = (P_1 - P_2) \frac{1}{1 - \frac{P_2}{P_1}}$$

$$\dot{m}_{th} = A_2 \frac{\frac{2\gamma}{\gamma - 1} \rho_1 (P_1 - P_2) \frac{1}{1 - \frac{P_2}{P_1}} \left[ \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma + 1}{\gamma}} \right]}{1 - \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} \beta^4}$$

$$\dot{m}_{th} = A_2 \sqrt{\frac{\frac{2\gamma}{\gamma-1}\rho_1(P_1-P_2)\frac{1}{1-\frac{P_2}{P_1}}\left[\left(\frac{P_2}{P_1}\right)^{\frac{2}{\gamma}}-\left(\frac{P_2}{P_1}\right)^{\frac{\gamma+1}{\gamma}}\right]}{1-\beta^4\left(\frac{P_2}{P_1}\right)^{\frac{2}{\gamma}}}}$$

$$\dot{m}_{th} = A_2 \sqrt{\frac{2\rho_1(P_1 - P_2)}{1 - \beta^4}} \sqrt{\frac{\frac{\gamma}{\gamma - 1}(1 - \beta^4) \frac{1}{1 - \frac{P_2}{P_1}} \left[ \left(\frac{P_2}{P_1}\right)^{\frac{2}{\gamma}} - \left(\frac{P_2}{P_1}\right)^{\frac{\gamma + 1}{\gamma}} \right]}{1 - \beta^4 \left(\frac{P_2}{P_1}\right)^{\frac{2}{\gamma}}}}$$

$$\dot{m}_{th} = \varepsilon A_2 \sqrt{\frac{2\rho_1(P_1 - P_2)}{1 - \beta^4}}$$

$$\varepsilon = \sqrt{\frac{\frac{\gamma}{\gamma - 1}(1 - \beta^4) \frac{1}{1 - \frac{P_2}{P_1}} \left[ \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma + 1}{\gamma}} \right]}{1 - \beta^4 \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}}}$$

#### **For Compressible flows**

$$\dot{m}_{th} = A_2 \sqrt{\frac{2\rho_1(P_1 - P_2)}{1 - \beta^4}} \sqrt{\frac{\frac{\gamma}{\gamma - 1}(1 - \beta^4) \frac{1}{1 - \frac{P_2}{P_1}} \left[ \left(\frac{P_2}{P_1}\right)^{\frac{\gamma}{\gamma}} - \left(\frac{P_2}{P_1}\right)^{\frac{\gamma + 1}{\gamma}} \right]}{1 - \beta^4 \left(\frac{P_2}{P_1}\right)^{\frac{2}{\gamma}}}}$$

$$\dot{m}_{th} = \varepsilon A_2 \sqrt{\frac{2\rho_1(P_1 - P_2)}{1 - \beta^4}}$$

$$\varepsilon = f\left(\frac{P_2}{P_1}, \gamma, \beta\right)$$

$$\varepsilon = \sqrt{\frac{\frac{\gamma}{\gamma - 1}(1 - \beta^4) \frac{1}{1 - \frac{P_2}{P_1}} \left[ \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma + 1}{\gamma}} \right]}$$

$$1 - \beta^4 \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}}$$

The above equation for  $\epsilon$  is never used in practice. In BS 1042 and ISO 5167,  $\epsilon$  is for square edged orifice is given as a regression equation

$$\varepsilon = 1 - (0.41 + 0.35\beta^4) \frac{1}{\gamma} \left(1 - \frac{P_2}{P_1}\right)$$

Air flows at 20 deg C through a 6-cm pipe. A square-edged orifice plate with  $\beta$  = 0.4 is chosen to meter the flow rate. A pressure drop of 250 cm H<sub>2</sub>O is measured at the flange taps with an upstream pressure of 93.7 kPa abs. Find the flow rate.

$$P_1 = 93.7 \ kPa = 93.7 \times 1000 Pa$$
  
 $P_1 - P_2 = 1000 \times 9.81 \times 250 \times 10^{-2} = 24.525 \ kPa$   
 $93.7 - P_2 = 24.525 \ P_2 = 69.175$   
 $\beta = 0.4$ 

$$\varepsilon = \sqrt{\frac{\frac{\gamma}{\gamma - 1}(1 - \beta^4) \frac{1}{1 - \frac{P_2}{P_1}} \left[ \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma + 1}{\gamma}} \right]} \frac{\frac{P_2}{P_1} = \frac{69.175}{93.7} = 0.7383}{\gamma = 1.4}$$

$$\gamma = 1.4 \qquad \beta = 0.4$$

$$\varepsilon = \sqrt{\frac{\frac{1.4}{1.4 - 1}(1 - 0.4^4)\frac{1}{1 - 0.7383}\left[(0.7383)^{\frac{2}{1.4}} - (0.7383)^{\frac{1.4 + 1}{1.4}}\right]}{1 - 0.4^4(0.7383)^{\frac{2}{1.4}}}}$$

 $\varepsilon = 0.8442$ 


$$\dot{m}_{th} = \varepsilon A_2 \sqrt{\frac{2\rho_1(P_1 - P_2)}{1 - \beta^4}}$$


$$\rho = \frac{P}{RT} = \frac{93.7 \times 1000}{287(273 + 20)} = 1.1143 \frac{kg}{m^3}$$

$$P_1 = 93.7 \ kPa = 93.7 \times 1000Pa$$
  
 $P_1 - P_2 = 24.525 \ kPa$   
 $\beta = 0.4$   
 $d = \beta D = 0.4 \times 60 = 24 \ mm$ 

$$\dot{m}_{th} = 0.8442 \times \frac{\pi}{4} (24 \times 10^{-3})^2 \sqrt{\frac{2 \times 1.1143(24.525 \times 10^3)}{1 - 0.4^4}}$$

 $\dot{m}_{th} = 0.09045 \ kg/s = 90.45 \ gms/s$ 





## **Expansion factors for common obstruction meters**

Experimentally determined expansion factors are lower than that of that computed from isentropic conditions.

#### **Orifice**


$$\frac{p_1 - p_2}{p_1} = 0.4 \beta = 0.4$$

$$\varepsilon_{\rm exp} = 0.87$$
  $\varepsilon_{theory} = 0.7517$ 

#### Venturi or nozzle?

$$\frac{p_1 - p_2}{p_1} = 0.4, = 0.5$$

$$\varepsilon_{\rm exp} = 0.74$$
  $\varepsilon_{theory} = 0.744$ 




## **Experimental results are for nozzle and venturi**

$$\frac{\frac{\gamma}{\gamma - 1} (1 - \beta^4) \frac{1}{1 - \frac{P_2}{P_1}} \left[ \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}} - \left( \frac{P_2}{P_1} \right)^{\frac{\gamma + 1}{\gamma}} \right]}{1 - \beta^4 \left( \frac{P_2}{P_1} \right)^{\frac{2}{\gamma}}}$$

#### Recommended placements for flow meters in a pipeline


**TURN DOWN RATIO** – RANGE DP transmitters are usually available over a range of 1:100. ∴ Turn Down Ratio of DP devices is around 10.




#### Recommended placements for flow meters in a pipeline

#### **Installation Requirements for Differential Pressure Devices**

- Fully Developed Flow is essential
- Minimum Pipe lengths are essential to achieve fully developed flow condition



#### **LAMINAR FLOWMETERS**



$$f=\frac{64}{Re}$$

$$f = \frac{64}{Re} \qquad \Delta p = \rho \frac{fLV^2}{2D} = \frac{64}{Re} \frac{\rho LV^2}{2D} = \frac{64}{\frac{\rho VD}{\mu}} \frac{\rho LV^2}{2D} = \frac{32\mu LV}{D^2} \Rightarrow V = \frac{D^2}{32\mu L} \Delta p$$

$$\dot{Q} = AV = \frac{\pi D^2}{4} \frac{D^2}{32\mu L} \Delta p = \frac{\pi D^4}{128\mu L} \Delta p \qquad Re < 2000$$

$$\dot{Q} = \frac{\pi D^4}{128\mu L} \Delta p$$


#### **Advantages**

- 1. A high sensitivity even at low flow rates
- 2. An ability to measure flow from either meter direction
- 3. A wide usable flow range
- 4. The ability to indicate an average flow rate in pulsating flows
- 5. The instrument systematic uncertainty in flow rate determination is as low as 0.25% (95%) of the flow rate.

#### **Disadvantages**


- 1. These meters are limited to clean fluids due to clogging potential.
- 2. All of the measured pressure drop remains a system pressure loss.


### **CONICAL FLOWMETER**




S. V. Prabhu, R. Mascomani, K. Balakrishnan and M. S. Konnur, Effects of upstream pipe fittings on the Performance of orifice and conical flowmeters, Flow Measurement and Instrumentation, Vol. 7, No. I, pp. 49-54, 1996

# Less upstream distance (5D) and downstream distance (2D)






### **CONICAL FLOWMETER**




Kishor Borkar, A. Venugopal, S.V. Prabhu, Pressure measurement technique and installation effects on the performance of wafer cone design, Flow Measurement and Instrumentation 30 (2013) 52–59

### **CONICAL FLOWMETER - BIDIRECTIONAL FLOWMETER**



Kishor Borkar, A. Venugopal, S.V. Prabhu, Study on the design and performance of a bi-directional cone flowmeter, Flow Measurement and Instrumentation 34 (2013) 151–159

### **ROTAMETER - Turndown is 10:1; Accuracy of 2% (95%) of flow rate**



 $C_D$ - Coefficient of Drag

ρ - Density of fluid

 $\rho_R$  – Density of float material

 $A_h$  – Area of the bob or float

 $V_h$  - Volume of the bob or float

A – Annular area

## **Drag Force + Buoyancy Force = Weight**

$$F_D + F_B = W$$

$$W - F_B = \frac{1}{2} C_D \rho A_b V^2$$

$$\rho_b V_b g - \rho V_b g = \frac{1}{2} C_D \rho A_b V^2$$

$$\frac{1}{2}C_{D}\rho A_{b}V^{2} = V_{b}g(\rho_{b} - \rho)$$

$$V^{2} = \frac{2V_{b}g}{C_{D}\rho A_{b}}(\rho_{b} - \rho)$$

$$V^{2} = \frac{2V_{b}g}{C_{D}\rho A_{b}}(\rho_{b} - \rho)$$

$$V^2 = \frac{2V_b g}{C_D \rho A_b} \frac{(\rho_b - \rho)}{\rho}$$

$$V = \sqrt{\frac{2V_b g}{C_D A_b}} \left(\frac{\rho_b}{\rho} - 1\right)$$

$$V = \sqrt{\frac{2V_b g}{C_D A_b} \left(\frac{\rho_b}{\rho} - 1\right)}$$

$$\dot{Q} = (A_t - A_b)V = (A_t - A_b)\sqrt{\frac{2V_b g}{C_D A_b}}\left(\frac{\rho_b}{\rho} - 1\right)$$

C<sub>D</sub> – coefficient of drag is a function of Reynolds number


$$Re = \frac{\rho V D_h}{\mu}$$

 $\mu$  – Viscosity of the fluid

For a given dimension of the bob and a given fluid, coefficient of

drag is assumed constant

$$K = \sqrt{\frac{2V_b g}{C_D A_b}} \left(\frac{\rho_b}{\rho} - 1\right) - \text{Constant}$$




$$Q = (A_t - A_b)K$$

 $\dot{Q} = (A_t - A_h)K$   $(A_t - A_h)$  varies linearly with height y, then the readings on the scale can be marked linearly

The floats of rotameters may be made of various materials to obtain the desired density difference in the following equation

$$K = \sqrt{\frac{2V_b g}{C_D A_b}} \left(\frac{\rho_b}{\rho} - 1\right)$$

for metering a particular liquid or gas.




Some float shapes such as spheres require no guiding in the tube; others are kept central by guide wires or by internal ribs in the tube.


Floats shaped to induce turbulence can give viscosity insensitivity over a 100: 1 range.

The tubes are made of high strength glass (Perspex) to allow direct observation of the float position.

If pneumatic or electrical signal related to the flow rate is desired, the float motion can be measured with a suitable displacement transducer.

### **ELECTROMAGNETIC FLOWMETER**





Emf of electrical potential e, is induced in a conductor of length L which moves with a velocity, U, through a magnetic field of magnetic flux, B

$$e = \overline{U} B L Sin\theta$$
  
 $e = \overline{U} B L Sin\theta = f(\overline{U})$ 

 $\theta$  - Angle between the mean velocity vector and the magnetic flux vector, usually at 90° L - Distance between two electrodes – of the order of diameter of the pipe

$$\dot{Q} = \overline{U}\frac{\pi D^2}{4} = \frac{e}{BL}\frac{\pi D^2}{4} = K_1 e$$

$$K_1 = \frac{1}{BL} \frac{\pi D^2}{4}$$


 $K_1$  - Meter Constant


### CHARACTERISTICS OF ELECTROMAGNETIC FLOWMETER

- No pressure loss
- Attractive for metering corrosive and dirty fluids
- Operating principle of independent of fluid density and viscosity, responding only to average velocity
- Limited only to fluids having high thermal conductivity
- ullet Minimum thermal conductivity required is 0.1 cm/M $\Omega$


# **Vortex flowmeter - Principle of Operation**

# Shedding of vortices behind bluff body immersed in metered flow






# Strouhal Number Variation with Reynolds Number



Venugopal, A., Agrawal, A., and Prabhu, S.V., "Review on vortex flowmeter - Designer perspective," Sensors & Actuators A, to appear, 2011


### **Typical vortex flowmeter**




Piezoelectric Sensor

Transient Pressure Sensor

# **Experimental Facility**



1. Pump 2. Gate valve 3. Vortex flowmeter 4. Differential Pressure Transmitter/Piezo Sensor 5. Ultrasonic flowmeter 6. Measuring tank 7. Load cell 8. Data acquisition system



DETAIL A

Dye – KMnO<sub>4</sub> & Ujjala blue (Liquid fabric whitener)


Camera – Canon 550D (DSLR) @ 60 f/s

Dye – Turbulent flow "Shear thickening dye"

Flow measurement  $Re_D = 3000-30000$ "Ultrasonic flow meter" Uncertainty 2%  $Re_D < 3000$ "Coriolis mass flow meter" Uncertainty 0.67%


- 1. Pump 2. Sump 3. Gate Valve 4. Ultrasonic flow meter
- 5. Over Flow Line 6. Constant Head Tank 7. Camera


### Strouhal number and Reynolds number Relationship (Linearity & Turndown ratio)



- **I Steady Regime**
- **II Unsteady Laminar Regime**
- **III Transition Regime**
- **IV Unsteady Turbulent Regime**

- I Steady Regime
- II Chaotic Regime
- **III Transition Regime**
- **IV Unsteady Turbulent Regime**






# Unique Features of vortex flowmeter

- No Moving parts
- Large Turndown ratio (1:20)
- Low Maintenance
- High operating pressure & Temperature (30 bar, 450° C)
- Low Cost
- Specially Suitable for Steam
- Good Accuracy (± 0.75 1.5%)
- Versatility Same meter can be used in any compatible medium

### **CORIOLIS MASS FLOWMETER**



A slider of mass m is moving with velocity v along a rod; the rod itself is moving with angular velocity  $\omega$  about the axis XY.

The mass experiences a Coriolis force of magnitude

$$F_{cor} = 2m(\omega \times V) = 2m\omega V$$


m - mass of the fluid

 $\omega$ - Excitation frequency

*V* – Fluid velocity

and the direction perpendicular to both linear and angular velocity vectors.

Fluid flows through the U-tube ABCD which is rotating with an angular velocity  $\omega$  about the axis XY.



Total coriolis force in BC is zero (velocity and angular velocity are parallel to each other)

The total force of limb AB with length *l* is

 $F = 2\rho AV\omega l$ 

 $F = -2\rho AV\omega l$ 

The total force of limb CD with length  $\boldsymbol{l}$  is

## The U-tube experiences a resultant deflecting torque

$$T = F(2r) = 2\rho AV\omega l(2r)$$




$$\dot{m} = \rho AV$$

m - mass of the fluid

 $\omega$ - Excitation frequency

*V* – Fluid velocity



$$T = 4\dot{m}\omega lr$$

$$\frac{T}{I} = \frac{C\theta}{L}$$


$$\theta = \frac{TL}{CJ} = \frac{(4\dot{m}\omega lr)l}{CJ} = \frac{4\omega r l^2}{CJ}\dot{m}$$

$$\theta = constant \dot{m}$$

**J** - Polar moment of inertia


**C** – Shear modulus

 $\theta$  – Angle of twist



$$\theta = \frac{4\omega r l^2}{CJ} \dot{m}$$

$$\theta = constant \dot{m}$$



### 2r is the separation distance between two arms

At time t' sensor P' detects the tube in position CB and emits the voltage pulse.

At a later time ' $t + \Delta t$ ', sensor P detects the tube in position C'B' and again emits a pulse.

The time interval  $\Delta t$  is small compared with the period of oscillation 1/f of  $\theta$ 


The distance BB' = CC' travelled by the tube in  $\Delta t$  is  $u \Delta t$ , where u is the velocity of the tube at BC.


This depends on the angular velocity  $\omega$ ;  $u = \omega l$  $BB' = CC' = u\Delta t = 2r\theta \Rightarrow$ 

$$\theta = \frac{4\omega r l^2}{CI} \dot{m} = \frac{\omega l}{2r} \Delta t \qquad \dot{m} = \frac{CJ}{8r^2 l} \Delta t$$

$$\dot{m} = \frac{CJ}{8r^2l} \Delta t$$


$$Tan\theta = \theta = \frac{u\Delta t}{2r} = \frac{\omega l}{2r} \Delta t$$






Pradeep Gupta, K. Srinivasan, S.V.Prabhu, Tests on various configurations of Coriolis mass flowmeters, May 2006, Measurement 39(4):296-307

# Natural frequencies 15, 24, 50, 123 Hz





# **Phase Shift versus Mass Flow Rate Curves for Various Lengths of PVC Tubes**

