

Materials Selection : Engineering Materials, Properties and Selection Methodology




ME 423: Machine Design
Instructor: Ramesh Singh

Outline


- Engineering Materials
- Material Properties
 - Mechanical Properties
 - Thermal Properties
 - Electrical Properties
 - Optical Properties
 - Eco-Properties



Evolution of Materials



Classes of Engineering Materials



Materials

- Metals: Stiff materials with relatively high elastic moduli and exhibit ductility. Can be made strong by alloying, mechanical and heat treatments
- Ceramics and glasses: Materials with high moduli, but, brittle.
 - Tensile strength means the brittle fracture strength;
 - Compresssive strength is the brittle crushing strength (15x fracture strength).
 - Low tolerance for stress concentrations (like holes or cracks) or for high contact stresses (at clamping points, for instance)
 - Finds application in bearings and cutting tools
 - Large scatter in the properties



Materials

- *Polymers and elastomers:* Materials with low moduli
 - High strength can be as strong as metals
 - Elastic deflections can be large due to low moduli
 - They exhibit creep (time dependent deformation under constant load) even at room temperature
 - Very high strength-to-weight ratio
 - Can be made into complex shapes



Materials:Composites



A composite material consists of two phases:

- Primary
 - Forms the matrix within which the secondary phase is imbedded
 - Any of three basic material types: polymers, metals, or ceramics
- Secondary
 - Referred to as the imbedded phase or called the reinforcing agent
 - Serves to strengthen the composite (fibers, particles, etc.)
 - Can be one of the three basic materials or an element such as carbon or boron



Types of composite materials

There are five basic types of composite materials: **Fiber, particle, flake, laminar or layered and filled composites.**



Classification of composite material

- **Metal Matrix Composites (MMCs)**
 - Mixtures of ceramics and metals, such as cemented carbides and other cermets
 - Aluminum or magnesium reinforced by strong, high stiffness fibers
- **Ceramic Matrix Composites (CMCs)**
 - Least common composite matrix
 - Aluminum oxide and silicon carbide are materials that can be imbedded with fibers for improved properties, especially in high temperature applications
- **Polymer Matrix Composites (PMCs)**
 - Thermosetting resins are the most widely used polymers in PMCs.
 - Epoxy and polyester are commonly mixed with fiber reinforcement



Classification of composite material

- Matrix material serves several functions in the composite
 - Provides the bulk form of the part or product
 - Holds the imbedded phase in place
 - Shares the load with the secondary phase



The reinforcing phase

- The imbedded phase is most commonly one of the following shapes:
 - Fibers, particles, flakes
- Orientation of fibers:
 - **One-dimensional:** maximum strength and stiffness are obtained in the direction of the fiber
 - **Planar:** in the form of two-dimensional woven fabric
 - **Random or three-dimensional:** the composite material tends to possess isotropic properties



The reinforcing phase

Types of phases

- Currently, the most common fibers used in composites are glass, graphite (carbon), boron and Kevlar 49.
 - Glass – most widely used fiber in polymer composites called glass fiber-reinforced plastic (GFRP)
 - E-glass – strong and low cost, but modulus is less than other (500,000 psi)
 - S-glass – highest tensile strength of all fiber materials (650,000 psi). UTS \sim 5 X steel ; $\rho \sim 1/3 \times$ steel



The reinforcing phase

- Carbon/Graphite –Graphite has a tensile strength three to five times stronger than steel and has a density that is one-fourth that of steel.
- Boron – Very high elastic modulus, but its high cost limits its application to aerospace components
- Ceramics – Silicon carbide (SiC) and aluminum oxide (Al₂O₃) are the main fiber materials among ceramics. Both have high elastic moduli and can be used to strengthen low-density, low- modulus metals such as aluminum and magnesium
- Metal – Steel filaments, used as reinforcing fiber in plastics



CFRP

GFRP

Hybrid (G+C)

GLARE®




Plate 1: A380 composite materials application. Not shown: CFRP passenger floor panels and struts. *Some composite parts are bonded others are not.* Several metal parts are also bonded in modern civil and military aircrafts.

Automotive sectors



ME 423: Machine Design
Instructor: Ramesh Singh






Lamborghini




ME 423: Machine Design
Instructor: Ramesh Singh



Mechanical Properties



- General
 - Weight
 - Expense
- Mechanical
 - Stiffness: E (Gpa)
 - Strength: yield strength
 - Tensile strength: σ_t
 - Fracture toughness: K_{IC}
- Thermal
 - Expansion coefficient
 - Thermal conductivity
- Electrical
 - Conductivity
- Wear corrosion and Oxidation




Thermal conduction



Fracture Toughness

- Fracture toughness ($MPa\sqrt{m}$) measure of the crack resistance of the material




- $K_{Ic} = \beta \sigma_t \sqrt{\pi c}$
- The fracture toughness is determined by loading a sample with a known crack of length $2c$
- Fracture toughness are typically well defined for brittle materials




Illustration of Mechanical Properties




- All right(Stiff, strong, tough, light)




- Not stiff enough (needs higher E)



- Not strong enough (needs higher σ_y)




- Not tough enough (needs higher K_{IC})



- Too heavy needs (needs lower density)

Materials





Characterization


Selection and Implementation



Material Property Chart




Property charts: Stiffness/weight



- Straight lines are the elastic wave speeds $\sqrt{\frac{E}{\rho}}$




Modulus to Density



ME 423: Machine Design
Instructor: Ramesh Singh


Strength to Density




INSTRUCTOR: Rakesh Singh



Fracture Toughness to Density




Modulus to Strength




ME 423: Machine Design
 Instructor: Ramesh Singh



Specific Modulus to Specific Strength




Fracture Toughness to Modulus



Instructor: Ramesh Singh




Fracture Toughness to Strength



ME 423: Machine Design
 Instructor: Ramesh Singh




Thermal conductivity to diffusivity



ME 423: Machine Design
Instructor: Ramesh Singh




Expansion to conductivity



Instructor: Ramesh Singh




Expansion to Modulus




ME 423: Machine Design
 Instructor: Ramesh Singh





Normalized Strength to Expansion




Strength at High Temperature



Relative Cost




Design for Impact



ME 423: Machine Design
Instructor: Ramesh Singh




Wear Rate



Material Selection

- Identifying the desired attribute for objectives and constraints (*Translation*)
- Comparing with real engineering materials for the best match (*Screening and Ranking*)



Mapping Design Requirements to Materials

“Translation”

Design concept

Analyse: Function

What does the component do ?

Objective(s)

What is to be maximised or minimised ?

Constraints

What essential conditions must be met ?

Free variables

Which design variables are free ?

From which we obtain ...

- **Screening criteria** expressed as numerical limits on material property-values
Or expressed as requirements for processing, corrosion,
- **Ranking criteria** based on material indices that characterise performance




Screening by Attributes and Links

Screen on attributes

Requirements: must

- operate at 100°C
- be electrical insulator
- conduct heat well

Example: heat exchanger tubes



Retain materials with:


- max operating temp > 100C
- resistivity $R > 10^{20} \mu\Omega.cm$
- T-conduct. $\lambda > 100 W/m.K$

Screen on links

Example: cheap metal window frame

Requirements: must

- be extrudable




Retain materials with:

- links to “extrusion”

Screen on both attributes and links





Screening on Attributes




Ranking by Performance

- Objective: Metric of performance which can be maximized or minimized, such as mass, volume, cost per unit attribute



Material Indices: Tie Rod

- Minimizing mass for a light strong tie rod



Function

Tie-rod

Constraints

Length L is specified
Must not fail under load F

- Objective

Objective

Minimise mass m

Free variable

Cross-section area A is free

Minimize $m = AL\rho$ where L is length, A is cross-sectional area and ρ is density

- Constraint: $\frac{F^*}{A} \leq \sigma_f$ where F^* is the force and σ_f is the failure strength

$$m \geq (F^*)(L) \left(\frac{\rho}{\sigma_f} \right)$$

Material Properties

Functional Constraint

Geometric Constraint

Minimize this material index or $\frac{\sigma_f}{\rho}$ specific strength can be maximized

For stiffest tie choose high $\frac{E}{\rho}$



Light Stiff Panel

- Function: Panel
- Objective: Minimize m of the panel
- Constraints: Bending Stiffness, S^* (functional constraint)
Length L and width b specified (geometric constraint)
- Free Variables: Panel thickness h and material

$$m = AL\rho = bhL\rho$$

The bending stiffness S can be given by, $S = \frac{c_1 EI}{L^3} \geq S^*$ and $I = \frac{bh^3}{12}$

$$m = hbL\rho = \left(\frac{12L^3S^*}{c_1Eb}\right)^{\frac{1}{3}} bL\rho = \left(\frac{12S^*}{c_1b}\right)^{\frac{1}{3}} (bL^2) \left(\frac{\rho}{E^{\frac{1}{3}}}\right) \rightarrow \text{Material Properties}$$

$$Mp = \frac{E^{\frac{1}{3}}}{\rho} \text{ (For stiffness); } Mp = \frac{\sigma y^{\frac{1}{2}}}{\rho} \text{ (For strength)}$$



Light Stiff Beam

- Function: Beam
- Objective: Minimize m of the panel
- Constraints: Bending Stiffness, S^* (functional constraint)
square cross-section (geometric constraint)
- Free Variables: Area A and material

$$m = AL\rho = b^2 L \rho$$


The bending stiffness S can be given by, $S = \frac{c_2 EI}{L^3} \geq S^*$ and $I = \frac{b^4}{12} = \frac{A^2}{12}$

$$m = AL\rho = \left(\frac{12L^3S^*}{c_1E}\right)^{\frac{1}{2}} L \rho = \left(\frac{12L^3S^*}{c_2}\right)^{\frac{1}{2}} (L) \left(\frac{\rho}{\frac{1}{E^2}}\right) \quad \text{Material Properties}$$

$$Mp = \frac{E^{\frac{1}{2}}}{\rho} \text{ (For stiffness); } Mp = \frac{\sigma y^{\frac{2}{3}}}{\rho} \text{ (For strength)}$$



Ashby's Methodology



Material Indices

Material properties --

the “Physicists” view of materials, e.g.

Cost,	C_m
Density,	ρ
Modulus,	E
Strength,	σ_y
Endurance limit,	σ_e
Thermal conductivity,	λ
T-expansion coefficient,	α

Material indices --

the “Engineers” view of materials

Objective: minimise mass

Function	Stiffness	Strength
Tension (tie)	ρ/E	ρ/σ_y
Bending (beam)	$\rho/E^{1/2}$	$\rho/\sigma_y^{2/3}$
Bending (panel)	$\rho/E^{1/3}$	$\rho/\sigma_y^{1/2}$

Minimise these!



Selection Using Charts


$$C = \frac{\rho}{\sigma_y}$$


$$\rightarrow \sigma_y = \rho/C$$

$$\log(\sigma_y) = \log(\rho) - \log(C)$$


$$\frac{\rho}{\sigma_y} = C$$

Contours of constant C are lines of slope 1 on an σ_y - ρ chart





Materials, Shapes and Processes



Process Material Compatibility

		Material Class															
		Metals				Ceramics & Glasses				Polymers & Elastomers			Composites				
Process Class	Casting	Ferrous	Refractory	Precious	Heavy	Light	Cementitious	Vitreous	Fine	Glasses	Thermosets	Thermoplastics	Elastomers	PMCs	MMCs	CMCs	
	Gravity	2	1	2	2	2	0	0	0	1	0	0	0	0	0	0	
	Low pressure	2	0	2	2	2	0	0	0	2	0	0	0	0	1	0	
	High pressure	1	0	2	2	2	0	0	0	1	0	0	0	0	2	0	
	Investment	2	2	2	2	2	0	0	0	0	0	0	0	0	0	0	
	Moulding	Injection	0	0	2	0	0	0	0	2	2	2	2	2	0	0	
	Compress	0	0	2	0	0	0	0	0	2	2	2	2	2	1	0	
	Blow	0	0	0	0	0	0	0	0	2	0	2	0	0	0	0	
	Foam	0	0	0	0	0	0	0	0	0	2	2	2	0	0	0	
	Deformation	Cold	2	0	2	2	2	0	0	0	0	0	0	0	0	0	
	Warm	2	0	2	2	2	0	0	0	0	0	0	0	0	0	0	
	Hot	2	2	2	2	2	0	0	0	2	0	0	0	0	0	0	
	Sheet	2	1	2	2	2	0	0	0	0	0	2	0	0	1	0	
	Machining	Turn	2	2	2	2	2	0	1	0	0	2	2	0	2	2	0
	Mill	2	2	2	2	2	0	1	0	0	2	2	0	2	2	0	
	Grind	2	2	1	2	2	0	2	2	2	0	0	0	0	2	2	
	Polish	2	2	2	2	2	0	2	2	2	0	0	0	0	1	2	
	Powder Methods	Sinter/HIP	2	2	2	2	2	0	2	2	1	0	2	0	0	2	2
	Slip cast	0	0	0	0	0	0	2	2	1	0	0	0	0	0	1	
	Spray forming	2	2	2	2	2	0	2	2	2	2	2	2	0	0	0	
	Hydration	0	0	0	0	0	2	0	0	0	0	0	0	0	0	0	
	Composite Forming	Lay-up	0	0	0	0	0	0	0	0	0	0	0	2	0	2	
	Mould	0	0	0	0	0	0	0	0	0	2	2	2	2	0	0	
	Squeeze-cast	1	0	0	2	2	0	0	0	0	0	0	0	0	2	0	
	Filament wind	0	0	0	0	0	0	0	0	0	0	0	0	2	0	0	
	Molecular Methods	PVD	0	2	2	2	0	0	0	2	0	0	0	0	1	0	
	CVD	0	2	2	2	0	0	0	2	0	0	0	0	0	1	2	
	Sputtering	2	2	2	2	2	0	0	0	0	0	0	0	0	0	0	
	Electroforming	1	0	2	2	0	0	0	0	0	0	0	0	0	0	0	
	Special Methods	Electrochemical	2	2	2	2	2	0	0	0	0	0	0	0	2	0	
	Ultrasonic	1	2	0	0	0	0	2	2	2	0	0	0	0	0	2	
	Chemical	2	2	2	2	2	0	2	2	2	0	0	0	0	0	0	
	Thermal Beam	2	2	2	2	2	0	2	2	2	2	2	2	2	2	2	
	Fabrication	Weld/braze	2	2	2	2	2	0	0	0	0	0	2	0	0	0	
	Adhesive	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	
	Fasten	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	
	Microfabrication	2	2	2	2	2	0	2	2	2	2	2	2	2	2	2	






FIGURE 13.22

The process-material matrix. A colored dot indicates that the pair are compatible.




FIGURE 14.5

The process-shape compatibility matrix, showing the requirements of the case studies. A summary of the material compatibility appears at the left. The intersection of this selection stage and the last one narrows the choice.




Selection by Technical Analysis

Select on material properties alone

Find material that has

- Attribute 1 $< C_1$ (Density, ρ)
 - Attribute 2 $> C_2$ (Modulus, E)
 - Attribute 3 $> C_3$ (Strength, σ)
 - Attribute 4 $= C_4$ (Poisson, ν)
- Multiple constraints




Process Material Relationship

Select on processability and material properties

Find material that of type
“INJECTION MOULDABLE”
and has

- Attribute 1 > C₁
- Attribute 2 > C₂
- Attribute 3 < C₃
- Attribute 4 < C₄

Multiple constraints



Selection on Similarity

Select on similarity (and innovative substitution)

Find material that is like
Material X, or like that of
Product Z


but has

- Attribute 1 > C₁
- Attribute 4 < C₄

} Additional
constraints

and is of type

"SAND-CASTABLE"




- How balance objectives ? eg

Performance, P }
Cost, C } Conflicting
 objectives

- Plot performance metric P against cost metric C


- A “solution”, is a material with a given combination of cost and performance

- Dominated and non-dominated solutions



Multi-objective Optimization


- **Solution:** a viable choice, meeting constraints, but not necessarily optimum by either criterion.
- **Dominated solution (A):** some other solution is better by both metrics
- **Non-dominated solution (B):** no one other solution is better by both metrics



- The **trade-off surface** (or Pareto front) is the surface on which the non-dominated solutions lie
- Use **intuition** to select
- Form a **value function**: a composite objective



Multi-objective Optimization



Summary

- Engineering Materials
- Material Property Charts
- Material Indices
- Material Selection Methodology by Ashby
- Multi-objective Optimization

