• Search about AVR micro-controller' clock details. How can its internal clock be used?

To setup clock sources, we should use CKSEL0, CKSEL1, CKSEL2 and CLSEL3 pins. By generating custom inputs, we can get 5 different results from the clock. This clock can generate 1Mhz, 2Mhz, 4Mhz and 8Mhz waves. Also, it is important to mention that the CKOPT pint should be disable when using these 4 pins.

| Device Clocking Option | CKSEL30 |
|------------------------------------|-------------|
| External Clock | 0000 |
| External RC Oscillator | 1000 – 0101 |
| Calibrated Internal RC Oscillator | 0100 – 0001 |
| External Low-Frequency Crystal | 1001 |
| External Crystal/Ceramic Resonator | 111 - 1010 |

On this account, required settings for using Internal Calibrated RC oscillator have been mentioned in the following table.

| CLSEL30 | Nominal Frequency |
|---------|-------------------|
| 0001 | 1.0Mhz |
| 0010 | 2.0Mhz |
| 0011 | 4.0Mhz |
| 0100 | 8.0Mhz |

Kaveh Shahedi

Microprocessors Laboratory – Fall 2020

Kharazmi University, Iran