

Check to see if one of the blades did not return to stop position

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- **Explanation**

If one of the blades wasn't able to pitch to stop when the turbine stopped, but the hydraulic pressure is fine, use the guide for alarm 432, 433, and 434 instead.

If the hydraulic pressure is too low to return the blade to stop, use the guide for alarm 323 and 359.

Add more hydraulic oil

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

- **Explanation**

If the system is low on oil, check for leaks and repair them before adding more oil.

Mobile SHC 524 hydraulic oil part [60096947](#)

AERO HF hydraulic oil part [60049423](#)