




Retighten the switch and its wiring connection

Does this solve the problem?


- 1] Yes
- 2] No
- 3] I don't know

● **Explanation**

Loose connection in the wiring or loose in the switch fixing screw could also trigger this error.



HUB HATCH CLOSED
HUB HATCH OVERRIDE



Check the Moon Light Door for proper closing, the gap between door and switch will trigger this error.



Check and Replace the defective switch

Does this solve the problem?

- 1] Yes
- 2] No
- 3] I don't know

• **Explanation**

The Defective Switch will trigger this error.

Check for switch operation and replace, if it is not operating as intended.







Relevant spare parts	
Description	Item No.
ENDSTOP S 6086117050 I88U1Z	60009256