

UNIT 1: RADIO CONVENTIONS

LETTERS

The phonetic alphabet must be used when giving call-signs, when spelling a word or when saying individual letters. Listen twice and repeat during the second reading. NOTE: The stress falls on the underlined syllable.

Letter	Word	Pronunciation guide
A	Alfa	<u>AL</u> FAH
B	Bravo	<u>BRAH</u> VOH
C	Charlie	<u>CHAR</u> LEE
D	Delta	<u>DELL</u> TAH
E	Echo	<u>ECH</u> OH
F	Foxtrot	<u>FOKS</u> TROT
G	Golf	<u>GOLF</u>
H	Hotel	HOH <u>TELL</u>
I	India	<u>IN</u> DEE AH
J	Juliett	<u>JEW</u> LEE <u>ETT</u>
K	Kilo	<u>KEY</u> LOH
L	Lima	<u>LEE</u> MAH
M	Mike	<u>MIKE</u>
N	November	NO <u>VEM</u> BER
O	Oscar	<u>OSS</u> CAH
P	Papa	PAH <u>PAH</u>
Q	Quebec	KEH <u>BECK</u>
R	Romeo	<u>ROW</u> ME OH
S	Sierra	SEE <u>AIR</u> RAH
T	Tango	<u>TANG</u> GO
U	Uniform	<u>YOU</u> NEE FORM
V	Victor	<u>VIK</u> TAH
W	Whiskey	<u>WISS</u> KEY
X	Xray	<u>ECKS</u> RAY
Y	Yankee	<u>YANG</u> KEY
Z	Zulu	<u>ZOO</u> LOO

Some common abbreviations spoken as initial letters:

ETA	Estimated Time of Arrival
ETD	Estimated Time of Departure
IMO	International Maritime Organization
SAR	search and rescue
UTC	universal time co-ordinated
VHF	very high frequency

Some common abbreviations spoken as words:

AMVER	Automated mutual vessel system
IALA	International Association of Lighthouse Authorities
LASH	Lighter Aboard Ship system
RoRo	Roll On – Roll Off

NUMBERS

Always transmit all numbers as separate digits!

Figure	Spelling	Pronunciation guide
0	zero	<u>ZERO</u>
1	one	<u>WUN</u>
2	two	<u>TOO</u>
3	three	<u>TREE</u>
4	four	<u>POWER</u>
5	five	<u>FIFE</u>
6	six	<u>SIX</u>
7	seven	<u>SEVEN</u>
8	eight	<u>AIT</u>
9	nine	<u>NINER</u>
1000	thousand	<u>TOUSAND</u>

Figure	Spoken	Pronunciation guide
2	two	TOO
15	one-five	WUN-FIFE
34	three-four	TREE-POWER
217	two-one-seven	TOO-WUN-SEVEN
25 000	two-five-thousand	TOO-FIFE-TOUSAND
25 256	two-five-two-five-six	TOO-FIFE-TOO-FIFE-SIX
250 000	two-five-zero-thousand	TOO-FIFE-ZERO-TOUSAND
36.04	three-six decimal zero-four	TREE-SIX- DAYSEEMAL ZERO-POWER

OTHER IMPORTANT EXPRESSIONS

In ordinary English we use expressions like:

The fairway is 23 metres **deep**. The mast is 9 metres **high**.

In radio communication we use the following expressions:

First a noun denoting quantity or unit of measurement **and after that the numbers**.

For example:

Depth *Fairway depth is: 6m. (six metres)*

Distance *Distance to scene of accident is 120 [one-two-zero] miles. (120 nautical miles)*

Draught *My draught forward is: 7.2 [seven decimal two] metres.
(7.2m)*

Height *Height of seas in the area is three metres... (3m)*

Speed *My speed is 15 [one-five] knots. (15 knots)*

Temperature *Temperature is 23 [two-three] degrees Celsius. (23°)*

Tonnage DWT/deadweight tonnes
NRT/net tonnes
GRT/gross tonnes

*My tonnage is 30,000 [three-zero-thousand] gross tonnes.
(30,000 tonnes)*

VHF frequency

Ohima Maru, this is Bravery. Change to VHF channel 72 [seven-two]. Over. (VHF 72)

Visibility to one mile

*Visibility at Helsinki Lighthouse is 500 [five-zero-zero] metres.
(500m)*

Visibility over one mile

Visibility is 1.5 [one-decimal-five] miles. (1.5 nautical miles)

Weight kilograms/kilograms
tonnes/metric tonnes

Wind speed

*Wind is Force 10 [one-zero]. (Indicating the Beaufort scale)
Wind is 23m/s [two-three metres per second].
Wind is 18 [one-eight] knots.*

DATE AND TIME

Time UTC/universal time coordinated
local time

Time is given in UTC at sea, before entry to a port, harbour or other terminal facility.
Time is given as local time inside a port, harbour or other terminal facility.

Time: 1500 [one-five-zero-zero] UTC.

Notice how coast radio stations give date and time at the end of messages:

Pan-Pan Pan-Pan Pan-Pan.

This is Scheveningen Radio, Scheveningen Radio, Scheveningen Radio.

Following received from DIANA 5 call sign PDQE.

Message reads: Engine trouble in position 3 miles north of Northhinder lightvessel... Need immediate tug assistance.

Date and time: 010138 UTC Scheveningen Radio.

01 = date: first day of the month

0138 = time: one thirty eight a.m. (in the morning)

POSITION

Methods of giving a position

Which method to use:

1. Latitude and Longitude:

- when clear of land, when near a clear coast
- when geographical names may be confusing

Example: 30° 50' N 018° 25' 02 E

Position: Latitude: three-zero degrees five-zero minutes North;

Longitude: zero-one-eight degrees two-five decimal zero-two minutes East.

2. Bearing and Distance:

- when near land or sea mark
- when there is a possibility of charts with different datums being used

Notice that the correct order is **bearing from...distance...**

Examples:

*My position is: **bearing**: one-niner-four degrees true from Cape Fantasia, **distance** one two decimal four miles.*

*Oil clearance operations in position: **bearing** 160° [one-six-zero] degrees from Barwater Pier **distance** four miles (160°; 4 nautical miles).*

3. Reference to a Navigation Mark

- when approaching ports or harbours

Example: *Position: I am approaching / passing / leaving Harmaja lighthouse.*

Using Cardinal Points / North, South, East, West, also Northeast, Southwest etc., example:



Education and Culture

Leonardo da Vinci

4. By Reporting Points

- in areas where reporting points have been marked on the charts

Example: *I am approaching reporting point number 2.*

NOTE: In a distress, safety or urgency situation the position is always to be transmitted in the form in which it was observed!

NOTE: Bearings and courses are always given in three figures:

Pilot boat is bearing 215° (T) from you.

Buoy 030° on your port bow.

[Pilot boat is bearing two-one-five degrees true from you.]

[Buoy zero-three-zero degrees on your port bow.]

NOTE: Rudder angles in steering orders are given as follows.

Starboard 15! (fifteen, NOT five-one)

Port 20! (twenty)

STANDARD PHRASES ON THE RADIO

Ocean King SOZZ, Ocean King SOZZ

This is Bravery OGSY

On VHF channel 16.

Over.

Bravery OGSY,

This is Ocean King SOZZ

Over.

This is... (to identify yourself)

On channel...

Over. (you expect respondent to transmit)

Ocean King SOZZ. This is Bravery OGSY.

Stand by on Channel 13. Over.

Bravery. This is Ocean King.

Standing by on Channel 13.

Stand by...
(listen on channel)

Standing by...
(complying)

MarEng Radio Communication

*Ocean King SOZZ.
This is Bravery OGSY.
Please switch to channel 13.
Over.*

*Bravery OGSY
This is Ocean King SOZZ
Agree channel 13.
Over.*

Switch to channel... **(you indicate channel)**
Agree channel... **(you comply)**

*Finncarrier OHJA.
This is Bravery OGSY.
Please switch to channel 13.
Over.*

*Bravery OGSY.
This is Finncarrier OHJA.
Channel 13 not available.
Please try channel 12.
Over.*

Channel ... **(you cannot use**
not available **suggested channel)**

*Ocean King SOZZ.
This is Bravery OGSY.
Do not overtake. I repeat: Do not overtake.
Over.*

*Bravery OGSY
This is Ocean King SOZZ.
Understood. I will not overtake.
Over.*

I repeat... **(to stress the importance of a message)**
Understood. **(to acknowledge)**

*Friedrich Russ.
This is Finnish Coast Guard vessel Merikarhu.
Please say again your position.
Over.*

*Merikarhu.
This is Friedrich Russ.
My position is 59° 40' North
024° 45' East
Over.*

Say again... **(when a message is not properly heard)**



Education and Culture

Leonardo da Vinci

MarEng Radio Communication

*Viking Cinderella OHZZ, Viking Cinderella OHZZ.
This is Friedrich Russ OGAA.
Calling on channel 10.
Over.*

*Friedrich Russ OGAA.
This is Cinderella OHZZ.
Please spell your name.
Over.*

*Cinderella. This is Friedrich Russ.
I spell:
First name: Foxtrot Romeo India Echo Delta Romeo India Charlie Hotel
Second name: Romeo Uniform Sierra Sierra
Over.*

Please spell... (to ensure clarity)
I spell...

*Ocean King.
This is Bravery.
How do you read me?*

*Bravery.
This is Ocean King.
I read you with signal strength five.*

- How do you read me? - I read you with signal strength 1/2/3/4/5

*All ships, all ships, all ships.
This is Finnish Coast Guard, Finnish Coast Guard
Calling unknown ship in position
59° 37' North
019° 37' East.*

*Finnish Coast Guard
This is Ocean King SOZZ
in position 59° 37' North
019° 37' East.*

All ships, all ships all ships...
Calling unknown ship in position...

*My present speed is 15 knots – mistake.
Correction: My present speed is 12 knots.*

When a mistake is made say:
Mistake...
Correction...



Education and Culture

Leonardo da Vinci

MarEng Radio Communication

Star Vega.
This is Kotka VTS.
Advice: Slow down to speed 4 knots before buoy number 6.
Over.

Kotka VTS.
This is Star Vega
Advice – received:
Buoy number 6.
Over.

Star Vega.
This is Kotka VTS.
Advice: Slow down to speed 4 knots before buoy number 6.
Please read back.
Over.

Kotka VTS.
This is Star Vega
Advice: Slow down to speed 4 knots before buoy number
6.
Over.

Star Vega.
This is Kotka VTS.
Readback is correct.
Out.

Advice:
Please read back...
Readback...
Readback is correct...
Out. (When you wish to end the communication)

MESSAGE MARKERS

In ship to ship or ship to shore radio communication the following Message Markers may be used.
The markers are used regularly in VTS radio communication. (See: Vessel Traffic Service.)

MARKERS:
Instruction
Advice
Warning
Information
Question
Answer
Request
Intention



Education and Culture

Leonardo da Vinci

EXAMPLES:

*Ocean King
This is Marina
QUESTION: What is your ETA?*

*Marina
This is Ocean King
ANSWER: My ETA is 1430 UTC.*

*Ohima Maru
This is Finnish Coast Guard
INSTRUCTION: Stop your engines immediately.*

*Finnish Coast Guard
This is Ohima Maru
Yes, I will stop my engines immediately.*

When answering an Advice, Request or Instruction say:
Yes, I will ... and say again the instruction or advice in full.

Or: *Say No, I cannot*and say again the advice, request or instruction in full.

ADVICE: *Advise you alter course to port.
Yes, I will alter course to port.
No, I cannot alter course to port. Another vessel is approaching.*

REQUEST: *I require oil-clearance assistance.
Yes, we will send oil-clearing assistance. Oil-clearance vessel on its way. ETA 1600 UTC.*

In the following responses the word UNDERSTOOD is used and a repetition of the message sent.

INFORMATION: *Pilotage is compulsory.*
UNDERSTOOD: *Pilotage is compulsory.*

WARNING: *Buoy number 12 in Helsinki approach channel unlit.*
UNDERSTOOD: *Buoy number 12 in Helsinki approach channel unlit.*

INTENTION: *I intend to reduce speed to 8 knots.*
UNDERSTOOD: *You intend to reduce speed to 8 knots.*

UNIT 2: ROUTINE COMMUNICATION

ROUTINE TRAFFIC - GENERAL

Routine is the name used for all radio communication, which is not distress, urgency or safety communication. To identify a vessel either its name, call sign or other identification (for example the MMSI number of the vessel) can be used. In routine communication identification of vessels can be given 1-3 times. In continued radio traffic between the same vessels once is normally enough.

ROUTINE EXCHANGE - THE WHOLE COMMUNICATION EXAMPLE - WHAT IS YOUR ETA?

Ocean Prince SHAJ,
Ocean Prince SHAJ.
This is Bravery OGSY,
Bravery OGSY.
On VHF channel 16 .
Over.

Bravery OGSY.
This is Ocean Prince SHAJ.
Over.

Ocean Prince.
This is Bravery.
Switch to channel 06.
Over.

Bravery.
This is Ocean Prince.
Agree channel 06.
Over.

Ocean Prince.
This is Bravery.
QUESTION: What is your ETA at rendez-vous?
Nothing more.
Over.

Bravery.
This is Ocean Prince.
ANSWER: My ETA at rendez-vous is 1540 UTC.
Over.

Ocean Prince.
This is Bravery.
UNDERSTOOD: ETA at rendez-vous:1540 UTC.
Thank you.
Out.



Education and Culture

Leonardo da Vinci

ROUTINE CALL AND RESPONSE

EXAMPLE:

Rattler GXXX is contacting a vessel named Kyriakou P3UT. Call on channel 16.

Initial Call

Kyriakou P3UT, Kyriakou P3UT.
This is Rattler GXXX, Rattler GXXX.
On channel 16.
Over.

Response

Rattler GXXX.
This is Kyriakou P3UT.
Over.

INITIAL CALL AND RESPONSE (structure)

Let us go through radio conventions when sending a routine communication to another vessel or coast station.

INITIAL CALL:

CALL	Name, call sign or other identification (e.g. the MMSI number) of the vessel you are calling 1-3 x
IDENTIFY YOURSELF	This is + name, call sign or other identification (e.g. the MMSI number) of your own vessel 1-3 x
ON VHF CHANNEL 16	
OVER	

The message ends in the word “Over”, which means that the transmission is turned over to the other party.

RESPONSE:

CALL	Name, call sign or other identification (e.g. the MMSI number) of the vessel you are answering 1-3 x
IDENTIFY YOURSELF	This is + name, call sign or other identification (e.g. the MMSI number) of your own vessel 1-3 x
OVER	

The message ends in the word “Over”, which means that the transmission is turned over to the other party.

CHANGING CHANNELS

EXAMPLE:

Rattler GXXX is asking Kyriakou P3UT to change channels.

Kyriakou.
This is Rattler.
Switch to channel 04.
Over.

Rattler.
This is Kyriakou.
I am switching to channel 04.
Over.

CHANGING CHANNELS (STRUCTURE)

Switching VHF Channel:

CALL	Name, call sign or other identification (e.g. the MMSI number) of the vessel you are calling 1-3 x. Usually once is enough.
IDENTIFY YOURSELF	This is + name, call sign or other identification (e.g. the MMSI number) of your own vessel 1-3 x. Usually once is enough.

Switch to VHF channel ...

OVER.

Agree VHF Channel:

CALL	Name, call sign or other identification (e.g. the MMSI number) of the vessel you are answering 1-3 x. Usually once is enough.
IDENTIFY YOURSELF	This is + name, call sign or other identification (e.g. the MMSI number) of your own vessel 1-3 x. Usually once is enough.

Agree channel...

OVER

MESSAGE, ANSWER, ENDING TRANSMISSION

Example:

Kyriakou.
This is Rattler.
INFORMATION: Your navigation lights are not visible.
Over.

Rattler.
This is Kyriakou.
INFORMATION RECEIVED: My navigation lights are not visible. I am switching on lights.
Over.

Kyriakou
This is Rattler.
UNDERSTOOD: You are switching on lights.
Out.

MESSAGE, ANSWER, ENDING TRANSMISSION (STRUCTURE)

Message:

CALL	Name, call sign or other identification (e.g. the MMSI number) of the vessel you are calling 1-3 x. Usually once is enough.
IDENTIFY YOURSELF	This is + name, call sign or other identification (e.g. the MMSI number) of your own vessel 1-3 x. Usually once is enough.
MESSAGE (MARKER) OVER	(Message marker and) message

Answer:

CALL	Name, call sign or other identification (e.g. the MMSI number) of the vessel you are answering 1-3 x. Usually once is enough.
IDENTIFY YOURSELF	This is + name, call sign or other identification (e.g. the MMSI number) of your own vessel 1-3 x. Usually once is enough.
ANSWER OVER	ANSWER marker and answer message

Answer / end transmission:

CALL	Name, call sign or other identification (e.g. the MMSI number) of the vessel you are calling/answering 1-3 x. Usually once is enough.
IDENTIFY YOURSELF	This is + name, call sign or other identification (e.g. the MMSI number) of your own vessel 1-3 x. Usually once is enough.
UNDERSTOOD OUT	Understood + repeat answer

UNIT 3: DISTRESS, URGENCY AND SAFETY COMMUNICATION

MAYDAY EXAMPLE AND STEPS IN DISTRESS COMMUNICATION

Mayday, mayday, mayday.
This is Ocean King, Ocean King, Ocean King
Mayday
Ocean King, SOZZ.
Position: Latitude 50° 35' North
Longitude: 001° 28' West.
I have heavy leakage, I am sinking.
I require immediate assistance.
Over.

Mayday
Ocean King, Ocean King, Ocean King SOZZ.
This is Utopia, Utopia, Utopia KLOA.
Received Mayday.
Over.

Mayday.
Ocean King
This is Utopia
Position: Latitude: 50° 10' North
Longitude: 0° 15' West
Speed: 18 knots.
ETA: 1530 UTC.
Over.

Mayday.
Utopia.
This is Ocean King.
Understood.
Position: Latitude: 50° 10' North
Longitude: 0° 15' West
Speed: 18 knots.
ETA: 1530 UTC.
Over.

Distress communication indicates that a vessel or person is threatened by grave and imminent danger and requests immediate assistance. Examples of distress situations are fire and explosion, heavy leakage and risk of sinking and risk of capsizing. Distress communication takes priority over all radio communication on channel 16. The distress signal consists of the words MAYDAY MAYDAY MAYDAY.

The distress message in this unit was sent according to the traditional procedure before the introduction of GMDSS and Digital Selective Call. Even today it is important for every seafarer to know how to send a mayday without the help of DSC. So let us study how the message is built up. It consists of four main parts:

- 1) The Initial Distress Call and Message
- 2) Acknowledgement
- 3) Assistance Information Message
- 4) Acknowledge Response

Let us go through these parts step by step.



Education and Culture

Leonardo da Vinci

Step 1

Distress call and Message

Mayday 3 x
This is + name, call sign or other
Identification of vessel in
distress 3 x

Mayday, mayday, mayday
This is Ocean King, Ocean King, Ocean King.

(a slight pause)

Mayday 1x
Ship's name and call sign 1x
Position

Mayday
Ocean King, Sierra Oscar Zulu Zulu.
Position: Latitude 50° 35' North
Longitude: 001° 28' West

Nature of distress

I have heavy leakage, I am sinking.

Request: What assistance
is required
Over.

Request: I require immediate assistance.
Over.

Step 2

Distress Acknowledgement

Mayday (only once)

Mayday

Name, call sign or other
identification of vessel in
distress 3 x

Ocean King, Ocean King, Ocean King
Sierra Oscar Zulu Zulu

This is + name and call sign
of answering vessel 3x

This is Utopia, Kilo Lima Oscar Alfa.

Received Mayday

Received Mayday.

Over

Over.

Step 3

Assistance Information message

Mayday
Name of station in distress
"This is" + name of
answering vessel

Mayday
Ocean King

This is Utopia.

Position of
answering vessel

Position: Latitude: 50° 10' North
Longitude: 0° 15' West

Speed of answering vessel

Speed: 18 knots

ETA at distress position

ETA: 1530 UTC

Over

Over.



Education and Culture

Leonardo da Vinci

MarEng Radio Communication

Step 4

Acknowledge Response

Mayday (once)	Mayday.
Name of answering vessel	Utopia.
This is + name of station in distress (once)	This is Ocean King.
Understood	Understood.
Position of answering vessel	Position: Latitude: 50° 10' North Longitude: 0° 15' West
Speed of answering vessel	Speed: 18 knots
ETA at distress position	ETA: 1530 UTC
Over	Over.

NOTE. Steps 1 and 4 are sent by the vessel in distress A and steps 2 and 3 by the answering and assisting vessel B, the order being ABBA.

NOTE. Most vessels have the GMDSS and DSC systems so in reality a communication like this would most likely happen by means of DSC. For examples of distress communication with DSC Click here to Digital Selective Call.

PAN-PAN EXAMPLE AND STEPS IN URGENCY COMMUNICATION

Pan-Pan Pan-Pan Pan-Pan
All stations, all stations, all stations
This is Vera Vera Vera 7VAT
Position: bearing 090° true from Ras Sarkan, distance 17 miles.
Lost propeller.
I require tug assistance.
Over.

Vera, Vera, Vera 7VAT.
This is Rose Maru JAAA.
Received Pan-Pan.
Over.

Urgency communication indicates that a station has an urgent message concerning the safety of a ship or a person which is not a pure distress situation. The urgency signal consists of the words PAN-PAN, PAN-PAN, PAN-PAN.

A mayday message is sent if the safety of a whole vessel and its crew is endangered. Another important distress message is the Pan-Pan or the Urgency Communication. A Pan-Pan message should be sent in, for example, the following situations:

- red rockets have been observed
- signals have been observed that might be distress signals
- when reporting on missing vessels
- if a person on board a vessel needs immediate medical assistance



NOTICE

- message is sent on channel 16
- the first answer to a Pan-Pan message can be a simple acknowledgement, by the Rescue Centre (or a vessel) in the vicinity. The Rescue Centre then usually relays the Pan-pan message with instructions to ships in the vicinity to give assistance if so required.

PAN-PAN STRUCTURE

ON CHANNEL 16:

PAN-PAN 3 X
ALL STATIONS 3 X
This is + name, call sign
or other identification of
vessel 3 x

Pan-Pan Pan-Pan Pan-Pan
All stations, all stations, all stations

This is Vera Vera Vera 7VAT.

POSITION:

Position: bearing 090° true from Ras Sarkan, distance 17 miles.

PAN-PAN MESSAGE:
REQUEST
OVER

Lost propeller.
I require tug assistance.
Over.

ANSWER ON CHANNEL 16:

Name, call sign or other
identification of vessel 3 x
THIS IS + Name, call sign
or other identification of
answering vessel (1-3 x):
RECEIVED PAN
OVER

Vera, Vera, Vera 7VAT

This is Rose Maru JAAA.
Received Pan-Pan.
Over.

SECURITE EXAMPLE AND STEPS IN SAFETY COMMUNICATION

Securite, Securite, Securite.
All ships, all ships, all ships.
This is Turku Radio, Turku Radio, Turku Radio,
With navigational warning number 2. Please listen to traffic channels.

Securite, Securite, Securite.
All ships, all ships, all ships.
This is Turku Radio, Turku Radio, Turku Radio.
Navigational warning: West Light buoy Låggharu in Helsinki approach channel in position: 60° 06.9'N 024° 59.2'E is out of order and unlit.
I repeat : West light buoy Låggharu in Helsinki approach channel in position 60° 06.9'N 024° 59.2'E is out of order and unlit.
Date and time 250800 UTC. This is Turku Radio.

MarEng Radio Communication

Radio messages that warn seafarers of dangers to navigation are marked Securite. Very often the warnings are sent by the Coast Radio Stations, like the example you just heard. But it is, of course, the duty of any ship to warn other vessels if she has observed dangers to navigation in the fairway. The safety signal consists of the word SECURITE.

Safety messages may include for example:

- weather warnings, gale warnings, fog, low visibility
- navigational warnings about
 - o beacons, buoys or lighthouses out of order
 - o seamarks, buoys off station
 - o obstructions in the fairway of any kind

NOTE: A safety message that is less than one minute in length can be sent directly on channel 16. Often there is a call on 16 giving the nature of warning. Then the sender switches to another channel for the message.

SAFETY MESSAGE STRUCTURE

ON CHANNEL 16:

SECURITE 3 x
ALL STATIONS 3 x
THIS IS + NAME, CALL SIGN
OR OTHER IDENTIFICATION
OF STATION 3 X

Securite Securite Securite
 All stations, all stations, all stations

KIND OF WARNING:
SWITCH TO CHANNEL

This is Diana, Diana, Diana
 PDQE [Papa Delta Quebec Echo]
 Navigational warning.
 Switch to VHF channel 06.

The safety message is then read on a traffic channel (here, channel 06)

SECURITE 3 x
ALL STATIONS 3 x
THIS IS NAME OF STATION 3 X
SECURITE
WARNING :

Securite Securite Securite
 All stations, all stations, all stations
 This is Diana Diana Diana
 Securite

Navigational warning: Drifting timber sighted in Turku approach channel in position: 60° 19' North, 022° 03.5' East.

I REPEAT:

I repeat: Drifting timber sighted in position: 60° 19' North, 022° 03.5' East. Dangerous to navigation.

OUT.

Out.

UNIT 4: BROADCASTS FROM COAST STATIONS

The following are examples of Coast Station messages:

PAN PAN

Pan-Pan Pan-Pan Pan-Pan
All stations, all stations, all stations
This is Scheveningen Radio, Scheveningen Radio, Scheveningen Radio

Following received from DIANA 5, call sign PDQE. Message reads: Engine trouble in position bearing north of Northinder lightvessel, distance 3 miles. Need immediate tug assistance. Ships in area, please keep sharp lookout and report to Scheveningen Radio.
Date and time: 010138. Scheveningen Radio - Good afternoon.

SECURITE

Securite Securite Securite
All stations, all stations, all stations
This is Portpatrick Radio, Portpatrick Radio, Portpatrick Radio with gale warning No 32. Please listen traffic channels.

Securite Securite Securite
All stations, all stations, all stations
This is Portpatrick Radio, Portpatrick Radio, Portpatrick Radio with gale warning No 32.
Viking: Severe gale force 9 backing southerly soon.
Fisher German Bight: Severe gale force 9 backing southwesterly soon.
Fair Isles: Southwesterly severe gale force 9 decreasing. Gale force 8 imminent
Date and time 051205 UTC. Portpatrick Radio. Good afternoon.

MAYDAY RELAY

And finally here is an example of a Mayday message which is received by Rescue Centre Turku, which then relays the message:

Mayday
Diana PDQE Diana PDQE Diana PDQE
My position is Latitude: 59° 45 'North
Longitude 021°29 'East
Heavy leakage amidships. Abandoning ship. Crew of 15.
Request: Immediate assistance.

Mayday
Diana Diana Diana PDQE
This is Rescue Centre Turku, Rescue Centre Turku, Rescue Centre Turku.
Received Mayday. I will relay your message.

MarEng Radio Communication

Mayday Relay Mayday Relay Mayday Relay

All stations, all stations, all stations

This is Rescue Centre Turku, Rescue Centre Turku, Rescue Centre Turku

Following received from Diana at 12 10 UTC on channel 16.

Begins:

Mayday

Diana

In position 59° 45 'North 021° 29' East.

Heavy leakage amidships. Abandoning ship. Crew of 15.

Request: Immediate assistance.

Ends.

Ships in area report to Rescue Centre Turku.

Date and time 251215 UTC. This is Rescue Centre Turku.

Over.