

VocaLens — print day

Two jobs, different materials. **Start the PETG first** — it is the long one, and the TPU can run after it or on a second machine.

JOB 1 · PETG · the two pods ~2–3 h

File	FINAL_petg_plate.stl Only if your 2×7 pin headers are still soldered to the XIAO, print FINAL_petg_plate_HEADERS.stl instead — it is the same parts, taller.
What is on it	4 parts: front pod base, front pod lid, rear pod base, rear pod lid
Material	PETG (PLA is acceptable if PETG is not free — it is stiffer and more brittle, but it fits)
Layer height	0.2 mm
Infill	25 %
Perimeters / walls	3
Supports	OFF
Brim	ON — the pods are tall and narrow and can be knocked over
Plate size	113 × 46 × 37 mm — fits any printer at the venue

Why supports off: the plate is already arranged so nothing overhangs. The pods sit cavity-up and the lids sit flat face down. If your slicer warns about overhangs, something imported wrong — do not switch supports on to silence it.

JOB 2 · TPU · the four rings ~40 min

File	FINAL_tpu_rings.stl
What is on it	4 copies of one small ring — 2 per pod, plus spares
Material	TPU / flexible filament. This one cannot be substituted
Layer height	0.2 mm
Infill	20 %
Perimeters / walls	2 — not 3. The wall is only 1.2 mm; more perimeters make it too stiff to stretch
Print speed	20–25 mm/s. TPU jams if pushed fast
Retraction	Near zero (0.5 mm or less)
Supports	OFF
Plate size	68 × 10 × 11 mm

If the venue has no TPU, print the rings anyway in the softest filament available and expect them to grip poorly, then say so — but ask around first. The rings are the only part that has to flex, and a rigid ring will crack rather than stretch onto the arm.

WHEN THEY COME OFF THE BED — check in this order

1. **Slide a ring onto your glasses temple arm.** It should need a firm push and then stay put on its own.

If it is loose: that is the one failure that matters, and it is a 10-minute reprint. Reduce `RING_IN_VERT` and `RING_IN_OUT` in `vocalens_ring.scad` by 0.5 mm each and print one ring again. **Make the opening smaller, never larger** — this part grips by stretching, like a hair tie.

2. **Slide a pod base onto a ring's dovetail rail,** along the arm. It should need real effort and should not rattle or lift off sideways.

If it will not go on at all, lower `DT_SQUISH` from 0.45 to 0.35. **If it rattles,** raise it to 0.55.

3. **Drop a lid onto its base.** The rib should sit inside the cavity and the lid should sit flush.
4. **Check the front lid has two openings:** a round hole near one end for the camera, and a long oval recess near the other for the touch pad, with a small hole through the middle of the oval.

The small hole is for the touch wire. Solder the wire to the **back** of the pad *before* gluing the pad into the recess — afterwards you cannot reach it, and nothing conductive should be exposed where a finger touches.

5. **Check the rear lid** has a ring of small holes — that is the speaker grille.

TAKE WITH YOU

- ☐ Laptop with the STL files on it (or the GitHub repo open)
- ☐ USB stick or SD card — most venue printers will not take a network job
- ☐ **The glasses you are mounting to** — the ring fit test is the whole point and cannot be done later
- ☐ Your assembled XIAO + camera, to check it drops into the front pod cavity
- ☐ The speaker and amplifier, to check they drop into the rear pod cavity
- ☐ Superglue or double-sided tape for the touch pad

Print the TPU rings even if you are short on time. The pods are useless without them, and they are the fastest part on the list.