

Эксперимент с четырехсторонним автоответчиком


Введение устройства

Значение порта цифрового ввода-вывода - это интерфейсы INPUT и OUTPUT.В предыдущем эксперименте со светодиодной лампой мы использовали только функцию OUTPUT в GPIO. Теперь давайте попробуем использовать функцию ввода / вывода ввода / вывода в Arduino, то есть эта функция предназначена для чтения выходного значения с внешнего устройства в этом эксперименте. Мы используем кнопки и светодиодные индикаторы, чтобы завершить эксперимент, используя INPUT и OUTPUT как комбинацию.



Ключевая структурная схема





Светодиодная схема

Цель эксперимента

Например, здесь был проведен конкурс знаний, поэтому в качестве простого автоответчика использовался светодиод. Основным принципом является то, что цепь включается при нажатии кнопки ответа, диод включен, а цепь, в которой расположен другой диод, отключается. После кнопки другие люди нажимают недействительно.


Компоненты



- Четыре светодиодных индикатора (красный, желтый, зеленый, синий)
- Четыре клавишных переключателя,
- 1К резистор 8
- Макетная плата
- Несколько перемычек
- пульт управления Arduino

Экспериментальная схема подключения

LED	Arduino UNOR3
Buleled (+)	11
Redled (+)	10
Yellow (+)	9
Green(+)	8
Button1	7
Button2	6
Button3	5
Button4	4



Программа




```
// Set blue led to pin11
int blueled=11;
int redled=10; // Set red led to pin10
int yellowled=9; // Set yellow led to pin9
int greenled=8; // Set green led to pin8
                    // Set blue button to pin7
int bluebutton =7;
                     // Set red button to pin6
int redbutton=6;
int yellowbutton=5; // Set yellow button to pin5
int greenbutton=4; // Set green button to pin4
int blue;
int red;
int yellow;
int green;
void setup()
 // Set the blue led, red led, yellow led, green led interface as output mode
   pinMode(blueled, OUTPUT);
   pinMode(redled, OUTPUT);
   pinMode(yellowled, OUTPUT);
   pinMode(greenled, OUTPUT);
   // Set the blue led, red led, yellow led, green led interface as output mode
   pinMode(bluebutton, INPUT);
   pinMode(greenbutton, INPUT);
   pinMode(redbutton, INPUT);
   pinMode(yellowbutton, INPUT);
void loop()
   blue=digitalRead(bluebutton); // Read the bluebutton value
   if (blue == HIGH)
                     // Determine whether the bluebutton is pressed
               // light blueled and turn off other lights
    digitalWrite(blueled, HIGH);
     digitalWrite(redled, LOW);
     digitalWrite(yellowled, LOW);
     digitalWrite(greenled, LOW);
   }
```



```
red=digitalRead(redbutton);// Read the redbutton value
                       // Determine whether the redbutton is pressed
   if (red == HIGH)
         // light redled and turn off other lights
     digitalWrite(blueled, LOW);
     digitalWrite(redled, HIGH);
    digitalWrite(yellowled, LOW);
     digitalWrite (greenled, LOW);;
   }
   yellow=digitalRead(yellowbutton); // Read the yellowbutton value
   if (yellow == HIGH) // Determine whether the yellowbutton is pressed
        // light yellowled and turn off other lights
     digitalWrite(blueled, LOW);
     digitalWrite(redled, LOW);
     digitalWrite(yellowled, HIGH);
     digitalWrite(greenled, LOW);
   green=digitalRead(greenbutton); // Read the greenbutton value
   if (green == HIGH) // Determine whether the greenbutton is pressed
          // light greenled and turn off other lights
     digitalWrite(blueled, LOW);
     digitalWrite(redled, LOW);
     digitalWrite(yellowled, LOW);
     digitalWrite (greenled, HIGH);
   }
}
```



• Результаты эксперимента




Пример программы Mblock




```
sensor Program
 set Blue ▼ to Read Digital Pin 7
       Blue = 1 then
    set digital pin 11 output as (HIGH*)
    set digital pin 10 output as LOW*
    set digital pin 9 output as LOW*
    set digital pin 8 output as LOW*
 set red ▼ to Read Digital Pin 6
 if (red) = 1 then
    set digital pin (11) output as (HIGHY
    set digital pin 10 output as LOW*
    set digital pin 9 output as LOW*
    set digital pin 8 output as LOW*
 set yellow ▼ to Read Digital Pin (5)
 if (yellow) = 1 then
   set digital pin (11) output as (HIGH*
    set digital pin 10 output as LOW*
    set digital pin 9 output as LOW*
    set digital pin 8 output as LOW*
 set green ▼ to < Read Digital Pin 4
       green = 1 then
    set digital pin (11) output as (HIGHY
    set digital pin 10 output as LOW*
    set digital pin 9 output as LOW*
    set digital pin 8 output as LOWY
```



Пример программы Mixly







Программа графического программирования MagicBlock

MagicBlock пишет программу автоответчика, как показано ниже:



