




```
# NangateOpenCellLibrary.macro.lef  
# Within MACRO INV_X1
```

```
PIN A
```

```
    DIRECTION INPUT ;
```

← electrical role

```
    ANTENNAGATEAREA 0.05225 ;
```

```
    # Other antenna attributes omitted
```

```
    PORT
```

```
        LAYER metal1 ;
```

```
        POLYGON 0.06 0.525 0.165 0.525
```

← pin geometry

```
        0.165 0.7 0.06 0.7 ;
```

```
    END
```

```
END A
```