D-STAR Host (dstar_host) - flow chart

OpenMT - Rick KD0OSS

Talks to the Modem Host on :18000+N-1 and to the D-STAR gateway on :18100+N-1 (the gateway links to ircDDB).

main() - start-up

Modem -> gateway (traffic from the radio)



Gateway -> modem (traffic from the reflector)



Timers, dashboard commands and the database



Key

The slow data header is checked by its type, so a header split across frames is complete only when all of it has arrived. Errors go to the error log with reportError().