

111 Deer Lake Road, Suite 120 Deerfield, Illinois 60015

Phone: (847) 405-0771 Fax: (847) 405-0776

Web site: www.visiplex.com Email: sales@visiplex.com

Programming Instructions for VP-4AW

1. Enter the program mode: Press and hold the "Shift Left" and "Shift Right" keys for 2 seconds simultaneously. The LCD will then display "0000" (Password, 0000 is the default password). Input the correct password by using "Shift Left/Shift Right" key and "Function" key. Then press the "Ready" key into the main program menu screen as shown below:

"ADLVSYLGSBQT"

AD: Pager Capcode Setting

LV: Testing Only

SY: System Parameter Setting LG: Power On LCD Display Setting

SB: Reserved (Not in use now)

QT: Save & Quit

2. Use the "Shift" key and "Function" key to select and set "AD", then the LCD will display as shown below:

"A: 1234567 B"

A: Number of Capcode 1 to 6

1234567: Pager Capcodes

B: Message Receiving Type (0) --- Normal Message

(1) --- Mail Drop (Public) Message

After capcode setting, press the "Read" key to return to the main program menu screen.

- 3. "LV" is the software self testing function only.
- 4. Use the "Shift" key and "Function" key to select and set "SY", then the LCD will display 19 digits as shown below:

"ABCDEFGH I X J K LMNO PQRS"

DIGITS	FUNCTION		
Α	Signal Polarity 0	Normal (20.945 MHz)	
	1	Inverse (21.855 MHz)	
BC	Reserved 0	0—Default	
D	Key Tone 0	Disable	
	1	Enable	
Ε	Unread Alarm 0	Disable	
	1	Enable	
F	Reserved 0	Default	
G		Default	
Н	,	o" on the LCD	
		No "o" ICOM	
		with "o" ICOM	
I Sequential Lock Out Time			
	_	Disable	
		to 91 to 9 minutes	
J		User Language Selection	
		Mandarin Chinese	
		English	
		Simplified Chinese	
1.6		Russian	
K	BPS, 0-512, 1-1200	, 2-2400	
LMNC		N. sasta Oal	
		Numeric Only	
		Canned Chinese Message	
		Taiwan CNS	
		Russian or English	
DODG		GB2312, China	
PQRS X	<u> </u>		
^	-	st character of received message	
		No space ~9Add 1~9 "Space"	
There	I are as the "Dood" key to return		

Then press the "Read" key to return to the Main Menu Screen.

- 5. Use the "Shift" key and "Function" key to select and set "LG". You can set 16 characters to be the power on logo. (The first 16 characters of any message in the pager's memory can be set as power on logo.) First, select the correct message in the pager's memory. Then go into the programming procedure and select function "LG" to set this message as the power on logo (first 16 characters). Then press the "Read" key to return to the program menu screen.
- 6. Use the "Shift" key and "Function" key to select and set "QT". Save parameters and quit this program.
- 7. END