



Partner: Sharp

Model: LC-80LE657U

Device Type: LCD Display



| GENERAL INFORMATION | | |
|-----------------------------|---|--|
| SIMPLWINDOWS NAME: | Sharp LC-80LE657U IP v1.1 | |
| CATEGORY: | TV/Video Projector | |
| VERSION: | 1.1 | |
| SUMMARY: | This module provides TCP/IP control and feedback for the Sharp LC-80LE657U. | |
| GENERAL NOTES: | This module provides control of the Sharp LC-80LE657U LCD Display. It also provides true feedback. It was developed and tested with the Sharp LC-80LE657U. It should also control the following models (other model series listed inside module) LC-90LE657U LC-80LE657U LC-70LE657U LC-60LE657U Note: Not all functions are available on all models. This module is System Builder Compatible. | |
| CRESTRON HARDWARE REQUIRED: | C2ENET-*, C2I-CP3CNET-1 | |
| SETUP OF CRESTRON HARDWARE: | TCP/IP Client Port: 10002 | |
| VENDOR FIRMWARE: | N/A | |
| VENDOR SETUP: | To initially enable IP control, the unit should manually be turned on while connected to the control processor. The processor will then send a command to the unit to enable its TCP/IP port. From that point on control will be enabled. | |
| CABLE DIAGRAM: | Cat5e | |

| CONTROL: | | |
|-----------------------------------|---|---|
| Power_ <on off="" toggle=""></on> | D | Pulse to turn the display on and off. |
| Input_* | D | Pulse to select the desired input. |
| AV_Mode_* | D | Pulse to select the desired A/V mode. |
| Aspect_* | D | Pulse to select the desired aspect ratio. |
| Effect_3D_* | D | Pulse to select the desired 3D effect. |





Partner: Sharp Model: LC-80LE657U Device Type: LCD Display



| Keypad_<10/Dot> | D | Pulse to enter the desired TV channel number. The entered number will not be sent until the "Keypad_Enter" is pulsed. |
|---|---|---|
| Keypad_Clear | D | Pulse to clear the channel number entered using the Keypad_<10/Dot> inputs. |
| Keypad_Enter | D | Pulse to send the channel number entered using the Keypad_<10.Dot> inputs. |
| Channel_ <up down=""></up> | D | Pulse to change the channel. |
| Air | D | Pulse to set the TV to the analog antenna. |
| Cable | D | Pulse to set the TV to cable. |
| Volume_ <up down=""></up> | D | Press and hold to adjust the volume level. |
| Volume_Mute_ <on off="" toggle=""></on> | D | Pulse to turn the volume mute on and off. |
| Sleep_Off | D | Pulse to turn the sleep timer off. |
| Sleep_<30/60/90/120>_Minutes | D | Pulse to set the sleep time. |
| Audio_Mode | D | Pulse to cycle through the audio modes. |
| Surrond_Mode | D | Pulse to cycle through the surround modes. |
| Closed_Caption | D | Pulse to cycle through the closed caption settings. |
| IR_Emulation_* | D | Pulse to send IR Emulation command. |
| {{TCP/IP_Client_>>Connect-F}} | D | Digital signal to be routed from the Connect-F output on the TCP/IP client symbol. |
| {{TCP/IP_Client_>>_status}} | Α | Analog signal to be routed from the status output on the TCP/IP client symbol. |
| {{TCP/IP_Client>>RX\$}} | S | Serial signal to be routed from the RX\$ output on the TCP/IP client symbol |
| | | |

| FEEDBACK: | | |
|----------------------------|---|---|
| Power_ls_ <on off=""></on> | D | High to indicate the current power state. |
| Input_ls_* | D | High to indicate the currently selected input. |
| AV_Mode_ls_* | D | High to indicate the currently selected A/V mode. |





Partner: Sharp

Model: LC-80LE657U
Device Type: LCD Display



| Aspect_ls_* | D | High to indicate the currently selected aspect ratio. |
|----------------------------------|---|--|
| Effect_3D_ls_* | D | High to indicate the currently selected 3D effect. |
| Channel_Request_Text | S | Serial signal indicating the currently entered channel request to be sent to the display. |
| <air cable="">_Selected</air> | D | High to indicate the current TV tuner selection. |
| Volume_Level | Α | Analog signal indicating the volume level. |
| Volume_Gauge | A | Analog signal indicating the volume level. To be displayed using a gauge on a touch panel. |
| Volume_Mute_Is_ <on off=""></on> | D | High to indicate the current volume mute setting. |
| Sleep_ls_* | D | High to indicate the current sleep timer setting. |
| Connected | D | High to indicate that the TCP/IP client is connected |
| Connection_Status_Text | S | Serial signal indicating the connection status. |
| {{Connect_>>_TCP/IP_Client}} | D | Digital signal to be routed to the connect input on the TCP/IP client symbol. |
| {{TX\$_>>_TCP/IP_Client}} | S | Serial signal to be routed to the TX\$ input on the TCP/IP client symbol. |

| TESTING: | |
|----------------------------------|--|
| OPS USED FOR TESTING: | 2-Series: v4.007.0004 3-Series: v1.005.0007 |
| SIMPL WINDOWS USED FOR TESTING: | v4.02.20 |
| DEVICE DB USED FOR TESTING: | v54.00.003.00 |
| CRES DB USED FOR TESTING: | v43.05.006.00 |
| SYMBOL LIBRARY USED FOR TESTING: | v888 |
| SAMPLE PROGRAM: | 2 Series: Sharp LC-80LE657U v1.1 Demo PRO2.smw 3 Series: Sharp LC-80LE657U v1.1 Demo PRO3.smw |
| REVISION HISTORY: | v1.0 – Original release v1.1 – Optimized for use with 3-Series Processors. Resolved issue with empty string being issued upon triggering the "Keypad_Enter" signal with no number entered. |