Pre-requisites and Installation of ${\tt Microsystems}$ 1.1 Module in ${\tt NISA}$



Kunal D. Patil (kdp@mecheng.iisc.ernet.in) CoNe Lab, IISc

November 17, 2014

ii CONTENTS

Contents

1	Pre-requisites to Microsystems module	1
2	Installation instructions for Microsystems module	3
3	Opening Microsystems module in DISPLAYIV of NISA	4

Pre-requisites to Microsystems module

The Microsystems (version 1.1) module ¹ is developed by Computational Nano engineering (CoNe) Lab at the Indian Institute of Science (IISc) in collaboration with Cranes Software International Limited (CSIL). The module is available with the Numerically Integrated elements for System Analysis (NISA) software, which is the product of CSIL.

Following are the pre-requisites to Microsystems module:

- NISA software with the valid license of DISPLAYIV (pronounced as display 4). Note that the NISA is only available on Windows platform and do not have Linux or any other distributions.
- Sufficient computer memory and processor requirements, of course. (read installation section from NISA CD/DVD).

Installation of NISA is simple and straight forward from the valid CD/DVD provided by CSIL. After installation, click on "NISA Application Launcher" (locate it on Desktop or find it in the Start menu) which will open following GUI (Figure (1.1)).



Figure 1.1. GUI of NISA Application Launcher

From "NISA Application Launcher", click on the DISPLAYIV menu. This should open following GUI (Figure (1.2)):

¹Development of Microsystems module at CoNe Lab, IISc was funded by the National Programme on Micro and Smart Systems (NPMASS). We are very thankful for their generous support.



Figure 1.2. GUI of DISPLAYIV

This marks the completion of pre-requisites to Microsystems module.²

NOTE:

- Please read the licensing instructions from NISA CD/DVD and particularly related to "Environment variables" setting. If the machine is used as license server then one should install license manager, like WlmAdmin (read license manager settings).
- The NISA software is a commercial software which has to be purchased in order to use Microsystems module.

 $^{^2\}mathrm{If}$ you get error then please check your NISA license settings.

Installation instructions for Microsystems module

Following are the instructions for installation of Microsystems module within DISPLAYIV of NISA;

- Find the Microsystems.rar (or in any other format) file from CD supplied by CSIL.
- Extract the compressed Microsystems.rar file. This will generate Microsystems folder.
- Copy the Microsystems folder to the location (default³) C:\Program Files(x86)\NISAV17 (see Figure (2.1))




Figure 2.1. Folder location of Microsystems module

• Open Microsystems folder and run installer.bat file.

This completes the installation of Microsystems module in NISA.

 $^{^3}$ If any other location is specified during NISA installation then select the appropriate directory (.\NISAV17). This documentation is for NISA version 17. For higher versions, please check the corresponding directory.

--3---

Opening Microsystems module in DISPLAYIV of NISA

Now open DISPLAYIV GUI by clicking NISA Application Launcher. The Microsystems module appears in the menu bar of DISPLAYIV (see Figure (3.1)) By clicking on Microsystems, a list of currently available analysis types is dis-




Figure 3.1. Microsystems module in NISA

played.

Now, you are ready to use Microsystems module.

NOTE:

- Check in the C:\NISARUN directory, the Microsystems directory is created or not. If yes, then open it and check for following directory structure;
 - error
 - results
 - $*\ 2dplots$
 - * fields
 - status

else, run the installer.bat again. If problem persists, let us know.