MCAPI\_ERR\_MEM\_LIMIT No memory available.

MCAPI\_ERR\_PRIORITY Incorrect priority

level.MCAPI\_ERR\_TRANSMISSION

Transmission failure. This error code is optional, and if supported by an implementation, its functionality shall be described.

MCAPI\_ERR\_PARAMETER

NULL and buffer\_size > 0) parameter.

Incorrect request or buffer (applies if buffer =

Implementation specific error not covered by other MCAPI\_ERR\_GENERAL

status codes. Specifics must be documented.

## NOTE

Use the  $mcapi\_test()$ ,  $mcapi\_wait()$  and  $mcapi\_wait\_any()$  functions to query the status of and  $mcapi\_cancel()$  function to cancel the operation.