4.1.4 MCAPI_NODE_ID_GET

NAME

mcapi_node_id_get - Returns the node id associated with the local node.

SYNOPSIS

DESCRIPTION

Returns the node id associated with the local node.

RETURN VALUE

On success the node_id is returned, *mcapi_status is set to MCAPI_SUCCESS. On error, *mcapi_status is set to the appropriate error defined below and the return value is set to MCAPI_NODE_INVALID.

ERRORS

MCAPI_ERR_NODE_NOTINIT

The node is not initialized.

MCAPI_ERR_GENERAL

Implementation specific error not covered by other status codes. Specifics must be documented.

NOTE

SEE ALSO