MCAPI_ERR_CHAN_OPENPENDING An open request is pending.

MCAPI_ERR_CHAN_CLOSEPENDING A close request is pending.

MCAPI_ERR_CHAN_OPEN The channel is already open.

MCAPI_ERR_ENDP_DELETED The endpoint has been deleted.

MCAPI_ERR_PARAMETER Incorrect handle or request parameter.

MCAPI_ERR_GENERAL Implementation specific error not covered by other

status codes. Specifics must be documented.

NOTE

Use the $mcapi_test()$, $mcapi_wait()$ and $mcapi_wait_any()$ functions to query the status and $mcapi_cancel()$ function to cancel the operation.