MCAPI_ERR_NODE_NOTINIT	The node is not initialized.
MCAPI_ERR_ENDP_INVALID	Argument is not a valid endpoint descriptor, or both endpoints are the same.
MCAPI_ERR_CHAN_CONNECTED	A channel connection has already been established for one or both of the specified endpoints.
MCAPI_ERR_CHAN_CLOSEPENDING	A close request is pending.
MCAPI_ERR_ATTR_INCOMPATIBLE	Connection of endpoints with incompatible attributes not allowed.
MCAPI_ERR_REQUEST_LIMIT	No more request handles available.
MCAPI_ERR_ENDP_GET_LIMIT	Thee endpoint get reference count is to high.
MCAPI_ERR_PARAMETER	Incorrect request parameter.
MCAPI_ERR_GENERAL	Implementation specific error not covered by other status codes. Specifics must be documented.

NOTE

Use the $mcapi_test()$, $mcapi_wait()$ and $mcapi_wait_any()$ functions to query the status of and $mcapi_cancel()$ function to cancel the operation.